Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Paladone 12729

Paladone Peppa Pig Figure Alarm Clock (Model 12729) User Manual

Your guide to setting up and using your Peppa Pig Alarm Clock.

Introduction

The Paladone Peppa Pig Figure Alarm Clock is designed to help children wake up with the official Peppa Pig theme song and provides a comforting night light function. This digital alarm clock features a Peppa Pig figurine that also serves as the snooze and night light activator.



Image: Front view of the Paladone Peppa Pig Figure Alarm Clock, displaying the digital time and control buttons.

Setup

Battery Installation

1. Locate the battery compartment on the back of the alarm clock.

2. Using a small screwdriver, open the battery compartment cover.
3. Insert 3x AA batteries (not included), ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.



Image: Rear view of the alarm clock, highlighting the battery compartment location.

Operating Instructions

Setting the Time

Refer to the control buttons located on the front panel below the digital display. Specific button functions are typically indicated by icons.

1. Press the 'Time Set' button (often indicated by a clock icon) to enter time setting mode.
2. Use the '+' and '-' buttons to adjust the hours.
3. Press the 'Time Set' button again to move to minute adjustment.
4. Use the '+' and '-' buttons to adjust the minutes.
5. Press the 'Time Set' button one more time to confirm and exit time setting mode.

Setting the Alarm

1. Press the 'Alarm Set' button (often indicated by an alarm bell icon) to enter alarm setting mode.
2. Use the '+' and '-' buttons to adjust the alarm hours.
3. Press the 'Alarm Set' button again to move to alarm minute adjustment.
4. Use the '+' and '-' buttons to adjust the alarm minutes.
5. Press the 'Alarm Set' button one more time to confirm and exit alarm setting mode.
6. Ensure the alarm is activated. There is usually a separate button or a toggle within the alarm setting mode to turn the alarm ON/OFF. An alarm icon on the display indicates it is active.

Snooze Function

When the alarm sounds, gently tap the head of the Peppa Pig figure to activate the snooze function. The alarm will temporarily pause and sound again after a short interval (typically 5-10 minutes).

Night Light Function

To activate the night light, press down on the head of the Peppa Pig figure. The figure will illuminate, providing a gentle glow. Press the head again to turn off the night light.



Image: The alarm clock with the Peppa Pig figure illuminated, demonstrating the night light function.

Maintenance

Cleaning

To clean the alarm clock, gently wipe it with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the unit in water.

Battery Replacement

When the display dims or the alarm function becomes unreliable, it is time to replace the batteries. Follow the battery installation steps outlined in the 'Setup' section. Always use fresh AA batteries and dispose of old batteries responsibly.

Troubleshooting

- **Clock not turning on or display is blank:** Ensure batteries are correctly installed and are fresh. Check for proper polarity.
- **Alarm not sounding:** Verify that the alarm time is set correctly and that the alarm function is activated (check for the alarm icon on the display). Ensure batteries are not depleted.
- **Night light not working:** Press the Peppa Pig figure's head firmly. If it still doesn't work, check battery levels.
- **Incorrect time display:** Reset the time following the 'Setting the Time' instructions.

Specifications

Feature	Detail
Brand	Paladone
Model Number	12729
Display Type	Digital
Special Features	Alarm, Night Light
Product Dimensions	4.92"W x 7.09"H (12.5cm W x 18cm H)
Power Source	Battery Powered
Batteries Required	3 x AA (not included)
Material	Plastic
Item Weight	0.25 Kilograms (8.8 ounces)

Warranty and Support

Specific warranty details for the Paladone Peppa Pig Figure Alarm Clock are not provided within this manual. For warranty information, technical support, or further assistance, please refer to the official Paladone website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DFHMXS5Z

More documents and user manuals: **https://manuals.plus/**