Manuals+
Q & A | Deep Search | Upload

Best Choice Products SKY8403

Best Choice Products 9ft Flocked Aspen Noble Fir Pre-Lit Christmas Tree Instruction Manual

Model: SKY8403

Introduction

This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your Best Choice Products 9ft Flocked Aspen Noble Fir Pre-Lit Christmas Tree. Please read all instructions carefully before setup and retain this manual for future reference.

Product Overview

The 9ft Flocked Aspen Noble Fir Christmas Tree features snow-touched, realistic-style branches and pre-strung LED lights. It is designed for indoor use and includes a sturdy folding metal stand.

Image: The 9ft Flocked Aspen Noble Fir Pre-Lit Christmas Tree, fully assembled and lit.

9ft
58in

Image: Diagram illustrating the dimensions of the 9ft Flocked Aspen Noble Fir Christmas Tree, showing a height of 9ft and a diameter of 58 inches.

Setup Instructions

1. **Assemble the Stand:** Unfold the metal stand and ensure it is stable and securely locked into place.
2. **Insert Tree Sections:** The tree features a simple 3-step assembly with an instant cordless light system. Carefully insert the bottom section of the tree into the stand. Ensure it is firmly seated.
3. **Connect Middle and Top Sections:** Stack the subsequent tree sections, aligning them properly. The cordless connection system will automatically connect the lights as each section is placed.
4. **Fluff the Branches:** Once all sections are assembled, gently spread out and shape the branches to achieve a full, natural appearance. Start from the bottom and work your way up.
5. **Plug In:** Plug the tree's power cord into a standard electrical outlet. The lights will illuminate automatically.

Image: A close-up view of the cordless quick-connect system, showing how tree sections easily connect without manual wiring for lights.

Your browser does not support the video tag.

Video: Official product video demonstrating the assembly process, light modes, and overall appearance of the Best

Operating Instructions

Your pre-lit Christmas tree features integrated LED lights with multiple functions, controlled by an included foot pedal switch.

Light Functions

The tree offers nine unique light functions, allowing you to switch between warm white and multicolor LED lights. Use the foot pedal switch to cycle through the different modes:

Image: Close-up of the foot pedal switch and a detailed list of the nine available light functions, including combinations of warm white and multicolor, steady-on, flashing, and slow fade options.

Image: The Christmas tree illuminated with warm white LED lights on one side and multicolor LED lights on the other, demonstrating the switchable light options.

1. **Combo All Light Functions:** Cycles through all available light modes.
2. **Steady On - Warm White Lights:** Constant warm white illumination.
3. **Steady On - Multi Colors Lights:** Constant multicolor illumination.
4. **Flashing - Warm White Flashing:** Warm white lights flash.
5. **Flashing - Multi Colors Flashing:** Multicolor lights flash.
6. **Flash - Warm White + Multi:** Alternating flash between warm white and multicolor.
7. **Fast Flash - Warm White + Multi:** Rapid alternating flash between warm white and multicolor.
8. **Slow Fade - Warm White:** Warm white lights slowly fade in and out.
9. **Slow Fade - Multi Colors:** Multicolor lights slowly fade in and out.

Press the foot pedal to advance to the next light function. Continue pressing until you reach your desired setting or to turn the lights off.

Maintenance

Cleaning and Care

- To clean the tree, gently wipe branches with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- The flocked branches may shed some material during initial setup and handling. This is normal and will decrease over time.
- Ensure the tree is unplugged before any cleaning or maintenance.

Storage

- Before storing, ensure the tree is completely dry.
- Disassemble the tree by reversing the assembly steps.
- Store the tree sections in their original packaging or a suitable storage bag in a cool, dry place away from direct sunlight and extreme temperatures.

Image: A detailed close-up of the snow-flocked branches, highlighting the texture and appearance of the artificial snow.

Troubleshooting

- **Lights Not Working:**
  - Ensure all tree sections are properly connected and the power cord is securely plugged into a working outlet.

- Check the foot pedal switch to ensure it is in the 'on' position or cycle through the light functions.
- Inspect for any loose or damaged bulbs. While LED lights are durable, individual bulbs can sometimes fail.

- **Tree Instability:**
  - Verify that the metal stand is fully extended and all locking mechanisms are engaged.
  - Ensure the bottom tree section is inserted correctly and securely into the stand.
  - Check that the tree is placed on a flat, level surface.
- **Excessive Flocking Shedding:**
  - Some shedding is normal, especially during the first assembly and fluffing. Use a vacuum cleaner to clean up any fallen flocking.
  - Avoid excessive handling of the flocked branches once the tree is set up.

Specifications

Feature	Detail
Brand	Best Choice Products
Model Number	SKY8403
Product Dimensions	58"D x 58"W x 108"H (9ft Height)
Color	Flocked Green
Material	Polyethylene, Polyvinyl Chloride
Item Weight	36.5 Pounds
Number of Tips	3088
Number of Lights	600
Light Color Options	Warm White, Multicolor
Special Features	Flocked, Pre-Lit, Cordless Quick-Connect, 9 Light Functions, Folding Metal Stand
Recommended Use	Indoor

Warranty and Support

For any questions, concerns, or issues regarding your Best Choice Products Christmas tree, please refer to the contact information provided with your purchase or visit the official Best Choice Products website for customer support. Please retain your proof of purchase for any warranty claims.

Related Documents - SKY8403

	Best Choice Products Christmas Tree Instruction Manual - Version 9 Comprehensive guide for assembling, fluffing, and maintaining Best Choice Products artificial Christmas trees. Includes safety warnings, parts identification, assembly steps for Type A and Type B trees, light replacement, cleaning, storage, and warranty information.
	Best Choice Products Christmas Tree Instruction Manual - Assembly and Care Guide Comprehensive instruction manual for Best Choice Products artificial Christmas trees. Covers assembly for Type A and Type B models, fluffing techniques, light repair, cleaning, storage, and important safety warnings. Includes details on product warranty and customer support.
	Best Choice Products Christmas Tree Instruction Manual Comprehensive instruction manual for assembling and maintaining your Best Choice Products Christmas Tree, including fluffing tips, warranty information, and safety guidelines.
	Best Choice Products Artificial Christmas Tree Instruction Manual Detailed instruction manual for assembling, fluffing, and maintaining Best Choice Products' snow flocked artificial pine Christmas trees. Includes safety guidelines, parts list, assembly steps for different types and sizes, light troubleshooting, and warranty information.
	Best Choice Products Christmas Tree Instruction Manual Comprehensive instruction manual for assembling and caring for your Best Choice Products artificial Christmas tree, including fluffing tips, warranty information, and safety guidelines.
	Best Choice Products Christmas Tree Instruction Manual - Assembly, Fluffing & Care Guide Comprehensive instruction manual for Best Choice Products Christmas Trees, detailing assembly steps for Type A and Type B models, fluffing techniques, cleaning and storage advice, warranty information, and customer support contacts. Includes warnings and product specifications.