Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HeroSet 5066H

HeroSet Office Chair User Manual

Model: 5066H

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your HeroSet Ergonomic Big and Tall Computer Desk Chair, Model 5066H. Designed for optimal comfort and support during long hours, this chair features adjustable functions, durable materials, and a robust construction. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your chair.

Important Safety Information

For safe use, this chair has a maximum weight capacity of**400 pounds**. Improper assembly may lead to instability or other hazards. Please follow assembly instructions carefully. Always ensure all components are securely fastened before use. Regularly inspect the chair for any loose parts or damage.

Setup and Assembly

The assembly process for the HeroSet Office Chair Model 5066H is designed to be straightforward and typically takes approximately 20 minutes. Detailed instructions and all necessary tools are provided in the packaging.
For a visual guide, please refer to the official installation manual available as a PDF document:Installation Manual (PDF).
Key Assembly Steps:

1. Unpack all components and verify against the parts list.
2. Attach the casters to the chair base.
3. Insert the gas lift into the center of the base.
4. Assemble the seat and backrest according to the provided diagrams.
5. Attach the assembled seat and backrest to the gas lift.
6. Ensure all screws are tightened securely.



Image: Overview of product dimensions and included installation tools. The image shows various measurements of the chair, including seat width, depth, and backrest height, along with an icon indicating that installation tools are included and a weight capacity of 400 lbs.

Operating Instructions

Your HeroSet office chair offers several adjustable features to customize your seating experience:

- **Adjustable Height:** Use the lever located under the seat to raise or lower the chair to your desired height. This allows for optimal positioning relative to your desk.
- **90-120° Tilt Adjustment & Rocking Function:** The chair's backrest can be adjusted between 90 and 120 degrees. Use the tilt adjustment function to recline for reading or relaxing, or lock it in an upright position for working. The rocking function provides dynamic movement for comfort.
- **Flip-up Armrests:** The armrests can be flipped up by 90 degrees. This feature allows you to push the chair closer to your desk, saving space, and provides flexibility for different activities.
- **360° Swivel:** The chair features smooth-gliding casters and a 360-degree swivel function, allowing for easy movement and rotation in your workspace.
- **Lumbar Support:** The ergonomic design includes built-in lumbar support to promote a healthy spine position and

reduce physical fatigue.



Image: Diagram illustrating the chair's adjustable features, including 120° rocking function, lumbar support, 360° smoothly castors, and 10cm/4.0" adjustable height. It highlights the chair's flexibility and stability.



Image: Detailed view of the reclining function, showing positions for 90° work/study, 105° reading/listening, and 120° relaxing. It also illustrates the tilt tension knob and recline lock lever for customized comfort.

Maintenance

Proper maintenance will extend the life and appearance of your HeroSet office chair:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the PU leather upholstery.
- **Screw Tightening:** To improve product safety, stability, and durability, tighten all screws every three months.
- **Caster Care:** Periodically check the casters for any debris (hair, dust, etc.) that may hinder smooth movement. Clean as necessary.



Image: Close-up of the durable PU leather, highlighting its wear resistance, breathability, waterproof properties, and ease of cleaning. A cat is shown sitting on the chair, emphasizing the material's durability.

Troubleshooting

If you encounter any issues with your HeroSet office chair, please consider the following common solutions:

- **Chair not adjusting height:** Ensure the height adjustment lever is fully engaged and the gas lift is not obstructed. Check if the gas lift is properly seated in the base.
- **Chair wobbles or feels unstable:** Verify that all assembly screws are tightened securely. Ensure the chair is on a flat, even surface.
- **Casters not rolling smoothly:** Inspect casters for trapped debris (hair, lint) and clean them. Ensure the casters are properly inserted into the base.
- **Squeaking noises:** Apply a small amount of lubricant to moving parts or joints if persistent squeaking occurs. Check for any loose screws and tighten them.

If the problem persists after attempting these steps, please contact HeroSet customer support for further assistance.

Specifications

Feature	Detail
Brand	HeroSet
Model Name	5066H
Color	Matte Black
Product Dimensions	11"D x 25"W x 20"H (Package Box)
Seat Dimensions	Height 22", Depth 22.8", Length 22.8"
Maximum Weight Recommendation	400 Pounds
Material	PU Leather, Sponge, PP Cotton, Spring Packs
Back Style	Breathable Lumbar Support Back
Special Features	Adjustable Backrest, Adjustable Height, Flip-up Armrests, Ergonomic, Rolling, Rocking Function
Item Weight	30 pounds
Date First Available	December 12, 2023

Warranty and Support

HeroSet high back office chairs offer a **3-year service**. Any issues or concerns can be promptly resolved through our dedicated after-sales service team. Please retain your proof of purchase for warranty claims.
For customer support, please visit the HeroSet Store on Amazon or contact their customer service directly.

© 2024 HeroSet. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DFWPRZ85

More documents and user manuals: **https://manuals.plus/**