Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DERCASS GX000525A

DERCASS Upholstery Daybed with Trundle and USB Charging Design

Model: GX000525A (Twin Beige)

1. Introduction

Thank you for choosing the DERCASS Upholstery Daybed with Trundle and USB Charging Design. This manual provides essential information for the safe assembly, operation, and maintenance of your new daybed. Please read these instructions carefully before beginning assembly and retain them for future reference.

2. Safety Information

- Always follow assembly instructions precisely.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as needed.
- Do not exceed the recommended weight capacity for the daybed or trundle.
- Keep small parts away from children during assembly to prevent choking hazards.
- Use on a flat, stable surface.
- Do not stand or jump on the daybed.
- Ensure the USB charging port is not exposed to liquids.

3. Package Contents

Before assembly, verify that all components are present. If any parts are missing or damaged, please contact customer support.

- Daybed Frame Components (Upholstered sections, backrest, armrests)
- Trundle Bed Frame Components
- Wooden Slats for Daybed and Trundle (10 for each)
- Hardware Pack (Screws, bolts, Allen wrench, etc.)
- USB Charging Cable and Power Adapter

- Assembly Manual

4. Assembly Instructions

Assembly is required for this daybed. It is recommended to have two people for assembly. All necessary parts and pre-drilled holes are provided for straightforward installation. Please refer to the detailed step-by-step manual included in the package for specific instructions.

General Assembly Steps:

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Attach the side armrests to the main backrest frame using the provided hardware.
3. Assemble the main daybed frame, ensuring all connections are secure.
4. Install the wooden slats onto the daybed frame.
5. Assemble the trundle bed frame separately.
6. Install the wooden slats onto the trundle frame.
7. Insert the assembled trundle into the daybed frame.
8. Connect the USB charging cable to the integrated port on the right armrest.
9. Ensure all bolts are tightened before placing mattresses or using the daybed.



Image 1: Daybed dimensions diagram. This image illustrates the overall length, width, and height of the daybed and trundle, including specific measurements for various components.



Image 2: Front view of the assembled daybed, showcasing the upholstered backrest and armrests.

5. Operating Instructions

Using the Trundle Bed:

The trundle bed is designed for versatility. It can be used in two configurations:

- **Flat Position:** Simply pull the trundle out from under the daybed. It will rest on the floor, providing an additional sleeping surface at a lower height.
- **Erected Position:** To raise the trundle to the same height as the daybed, pull it out completely. Then, lift the trundle frame until its legs lock into the upright position. Ensure the legs are securely locked before use.



Image 3: The trundle bed partially pulled out from beneath the main daybed frame.



Image 4: The trundle bed fully extended and elevated to match the height of the main daybed.

Using the USB Charging Port:

The daybed features a convenient USB charging port located on the right armrest. To use, simply plug the provided power adapter into a wall outlet and connect it to the daybed's integrated cable. You can then plug your USB-compatible devices into the port for charging.



Image 5: Close-up view of the USB charging port integrated into the right armrest of the daybed.

6. Maintenance and Care

- **Cleaning:** Wipe the upholstered fabric and wooden surfaces with a dry cloth. Avoid using harsh chemicals or abrasive cleaners, which may damage the finish.
- **Hardware Check:** Periodically inspect all bolts and screws to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Mattress Care:** Follow the care instructions provided with your mattress.

7. Troubleshooting

- **Wobbly Frame:** Ensure all assembly bolts are securely tightened. If the issue persists, disassemble and reassemble, paying close attention to each connection.
- **Trundle Not Sliding Smoothly:** Check for any obstructions under the daybed or on the trundle's wheels. Ensure the trundle is properly aligned within its tracks.
- **USB Port Not Charging:** Verify that the power adapter is securely plugged into both the wall outlet and the daybed's cable. Test with a different USB device or power outlet if possible.
- **Missing Parts:** If you discover missing parts during assembly, refer to the 'Package Contents' section and contact customer support immediately.

8. Specifications

Model Number	GX000525A
Brand	DERCASS
Size	Twin
Color	Beige
Overall Product Dimensions	80.7"L x 78.7"W x 34"H
Upper/Down Bed Dimension	76" x 39.2"
Total Height	34"
Number of Daybed/Trundle Slats	10/10 pcs
Recommended Mattress Thickness	6"
Product Weight	114 lbs
Material	Pine Wood, MDF, Woven Fabric
Assembly Required	Yes
Special Features	No Box Spring Needed, Trundle, USB Charging, Upholstery
Care Instructions	Wipe with Dry Cloth

9. Warranty and Support

For any questions, concerns, or assistance with your DERCASS Upholstery Daybed, please contact our customer

support team. We are committed to providing solutions and ensuring your satisfaction. Please have your model number (GX000525A) and purchase information ready when contacting support.
Specific warranty details are typically provided with your purchase documentation. Please refer to those documents for information regarding warranty coverage and terms.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DG27PJT1

More documents and user manuals: **https://manuals.plus/**