Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER SCPH-1001, SCPH-5001, 5501, 7001, 7501, 9001

PKPOWER AC Power Cord User Manual

For Sony PlayStation 1 Consoles (SCPH-1001, SCPH-5001, 5501, 7001, 7501, 9001)

1. Introduction and Overview

The PKPOWER AC Power Cord is a replacement power cable designed to supply electrical power to compatible Sony PlayStation 1 (PS1) console models. This manual provides essential information for the safe and effective use of your power cord.

Compatible Models: Sony PlayStation 1 (PS1) SCPH-1001, SCPH-5001, SCPH-5501, SCPH-7001, SCPH-7501, SCPH-9001.



Image 1.1: The PKPOWER AC Power Cord, shown coiled. This cord is designed to replace or supplement the original power cable for compatible Sony PlayStation 1 consoles.

2. Product Features

- **Cable Length:** 6 feet (approximately 1.8 meters) for flexible placement.
- **Input Voltage:** Supports a wide range of input voltages from 100-240V, suitable for various electrical standards.
- **Compatibility:** Specifically designed for Sony PlayStation 1 console models SCPH-1001, SCPH-5001, 5501, 7001, 7501, and 9001.
- **Safety Performance:** Manufactured to meet FCC safety standards, ensuring a safe charging experience.
- **Durability:** Constructed from durable materials to ensure a long product lifespan and reliable performance.

3. Setup Instructions

Follow these steps to properly connect your PKPOWER AC Power Cord to your Sony PlayStation 1 console.

1. **Identify Power Port:** Locate the AC power input port on the back of your Sony PlayStation 1 console.
2. **Connect to Console:** Take the female (two-hole) end of the PKPOWER AC Power Cord and firmly insert it into the console's AC power input port.
3. **Connect to Outlet:** Plug the male (two-prong) end of the PKPOWER AC Power Cord into a standard, functional electrical wall outlet. Ensure the outlet provides 100-240V AC power.
4. **Verify Connection:** Confirm that both ends of the power cord are securely seated to prevent intermittent power supply.



Image 3.1: A close-up view of the male (wall plug) and female (console connector) ends of the PKPOWER AC Power Cord, illustrating the connection points.

4. Operating Instructions

Once the PKPOWER AC Power Cord is correctly connected, your Sony PlayStation 1 console is ready for operation.

- **Power On:** Press the power button on your Sony PlayStation 1 console to turn it on.
- **Power Off:** To turn off the console, press the power button again. It is recommended to power off the console before disconnecting the power cord.

5. Maintenance

Proper maintenance ensures the longevity and safe operation of your power cord.

- **Storage:** When not in use, store the power cord in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Handling:** Avoid kinking, twisting, or sharply bending the cord, especially near the connectors, as this can damage internal wires.
- **Inspection:** Periodically inspect the entire length of the cord for any signs of damage, such as cuts, fraying, or exposed wires.
- **Cleaning:** If necessary, gently wipe the cord with a dry, soft cloth. Do not use liquid cleaners or immerse the cord in water.
- **Discontinue Use:** If any damage is observed, discontinue use immediately and replace the cord to prevent electrical hazards.

6. Troubleshooting

If you encounter issues with your power cord, refer to the following troubleshooting steps:

- **Console Not Powering On:**
  - Ensure the power cord is fully inserted into both the console and the wall outlet.
  - Test the wall outlet with another device (e.g., a lamp) to confirm it is supplying power.
  - Verify that the console's power button is functioning correctly.
- **Intermittent Power Supply:**
  - Check all connections to ensure they are tight and secure.
  - Inspect the power cord for any visible damage or kinks that might be disrupting the electrical flow.
- **Cord Feels Hot:**
  - A slightly warm cord during operation is normal. However, if the cord becomes excessively hot to the touch, immediately unplug it from the wall and the console.
  - Ensure the cord is not covered or obstructed, which could lead to overheating.
  - If the issue persists, discontinue use and contact support.

7. Specifications

Brand	PKPOWER
Manufacturer	Shenzhen AiNaU Technology Co.,Ltd
Cable Length	6 feet (72 inches)
Input Voltage	100-240 Volts AC
Connector Gender	Male-to-Female
Color	Black
Number of Outlets	1

8. Warranty Information

This PKPOWER AC Power Cord is covered by a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

The warranty does not cover damage caused by misuse, accident, unauthorized modification, or improper installation. Please retain your proof of purchase for warranty claims.

9. Support

For technical assistance, warranty claims, or any questions regarding your PKPOWER AC Power Cord, please contact PKPOWER customer service. Refer to your product packaging or the retailer's website for specific contact details.
We are committed to providing reliable products and support to our customers.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DGL12TCF

More documents and user manuals: **https://manuals.plus/**