Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER ETB001

PKPower AC Power Cord User Manual

For Rotai ETB001 Under Desk Elliptical Electric Pedal Exerciser Machine

1. Introduction

This manual provides essential instructions for the safe and effective use of your PKPower AC Power Cord. This power cord is specifically designed to provide electrical power to the Rotai ETB001 Under Desk Elliptical Electric Pedal Exerciser Machine. Please read this manual thoroughly before use and retain it for future reference.

2. Safety Information

Your safety is paramount. Adhere to the following guidelines to prevent electrical hazards and ensure proper operation:

- **FCC Certification:** The PKPOWER AC adapter charger has undergone FCC testing and holds relevant certifications, ensuring it meets safety standards.
- **Proper Connection:** Always ensure the power cord is fully and securely inserted into both the wall outlet and the device. Loose connections can cause overheating or electrical arcing.
- **Indoor Use Only:** This power cord is intended for indoor use in dry environments. Do not expose it to moisture, rain, or extreme temperatures.
- **Avoid Damage:** Do not bend, twist, or crimp the cord excessively. Inspect the cord regularly for any signs of damage, such as cuts, fraying, or exposed wires. Discontinue use immediately if damage is observed.
- **Overload Prevention:** Do not plug the cord into an overloaded circuit. Ensure the wall outlet can safely handle the power requirements of your device.
- **Children and Pets:** Keep the power cord out of reach of children and pets to prevent accidental damage or injury.

3. Product Overview

The PKPower AC Power Cord is a 6-foot (1.83 meter) cable designed for reliable power delivery. It features a standard male plug for connecting to a wall outlet and a female receptacle for connecting to compatible devices, such as the Rotai ETB001.



Figure 3.1: Overview of the PKPower AC Power Cord, coiled for storage, displaying both the male plug and female receptacle.



Figure 3.2: Detailed view of the male plug (left) and female receptacle (right) of the power cord, highlighting their design.

4. Setup

Follow these steps to connect your PKPower AC Power Cord:

1. **Identify Connectors:** Locate the male plug (with prongs) and the female receptacle (with slots) on the power cord.
2. **Connect to Device:** Insert the female receptacle end of the power cord firmly into the power input port of your Rotai ETB001 Under Desk Elliptical Electric Pedal Exerciser Machine. Ensure it is fully seated.
3. **Connect to Power Outlet:** Insert the male plug end of the power cord firmly into a standard, grounded AC wall outlet (100-240V).
4. **Verify Connection:** Confirm that both ends of the power cord are securely connected before attempting to power on your device.

5. Operating

Once the PKPower AC Power Cord is correctly connected to both the Rotai ETB001 machine and a live electrical outlet, the machine will receive power. Refer to the Rotai ETB001's own user manual for instructions on how to operate the elliptical machine itself.

6. Maintenance

Proper care and maintenance will extend the life of your power cord:

- **Cleaning:** Disconnect the cord from all power sources before cleaning. Wipe the cord and connectors with a dry, soft cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, coil the cord loosely. Avoid tight coiling or kinking, which can damage the internal wires. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the entire length of the cord and both connectors for any signs of wear, damage, or discoloration.
- **Durability:** The cord is constructed from durable materials designed for flexibility and longevity. However, mishandling can still cause damage.

7. Troubleshooting

If your Rotai ETB001 machine is not receiving power, consider the following:

- **Check Connections:** Ensure both ends of the PKPower AC Power Cord are fully and securely plugged into the wall outlet and the elliptical machine.
- **Test Outlet:** Plug another working appliance into the same wall outlet to confirm the outlet is functional. If the outlet is not working, check your circuit breaker.
- **Inspect Cord:** Examine the power cord for any visible damage (cuts, kinks, exposed wires). If damage is found, discontinue use and replace the cord.
- **Device Power Switch:** Ensure the power switch on the Rotai ETB001 machine itself is in the 'ON' position.

8. Specifications

Feature	Detail
Brand	PKPOWER
Model Compatibility	Rotai ETB001 Under Desk Elliptical Electric Pedal Exerciser Machine
Cable Length	6 feet (approximately 1.83 meters)
Input Voltage	100-240V AC
Connector Gender	Male-to-Female
Color	Black
Product Dimensions	3 x 2 x 0.5 inches (approximate packaging/item size)
Item Weight	2 ounces
Manufacturer	Shenzhen AiNaU Technology Co.,Ltd
ASIN	B0DGX42RDS

9. Product Support

PKPOWER is committed to providing quality products. If you encounter any issues or have questions regarding your AC Power Cord, please contact our customer support team. We stand behind our products and are ready to assist you.

For support, please refer to the contact information provided with your purchase or visit the official PKPOWER website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DGX42RDS

More documents and user manuals: **https://manuals.plus/**