Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC Power Cord

PKPower 6ft AC Power Cord User Manual

For Cen-Tech 4-in-1 Portable Power Pack Jump Starter # 60666 58978

Introduction

This manual provides essential information for the safe and effective use of your PKPower 6ft AC Power Cord. This power cord is designed as a replacement or spare for Cen-Tech 4-in-1 Portable Power Pack Jump Starter models 60666 and 58978. Please read this manual thoroughly before use to ensure proper connection and operation.

Product Overview



Figure 1: The PKPower 6ft AC Power Cord, shown coiled. This image displays the overall length and flexibility of the cord.



Figure 2: The PKPower 6ft AC Power Cord, displaying both the male (wall plug) and female (device connector) ends. This illustrates the standard three-prong design for both connectors.

The PKPower 6ft AC Power Cord is a durable and flexible cable designed to provide power to compatible devices. It features a standard 3-prong male plug for wall outlets and a 3-pin female connector for the device. Its 6-foot length offers flexibility in placement.

Setup

1. **Inspect the Cord:** Before each use, visually inspect the entire length of the power cord for any signs of damage, such as cuts, fraying, or exposed wires. Do not use a damaged cord.
2. **Identify Connectors:** Locate the male end of the power cord (the plug with three prongs) and the female end (the connector with three holes).
3. **Connect to Device:** Insert the female end of the power cord firmly into the AC power input port of your Cen-Tech 4-in-1 Portable Power Pack Jump Starter. Ensure a snug fit.
4. **Connect to Power Source:** Insert the male end of the power cord into a standard, grounded 100-240V AC wall outlet. Ensure the outlet is easily accessible for quick disconnection if needed.

Important Safety Note:

- Always ensure the power source voltage matches the device's requirements.
- Do not force the plug into an outlet.
- Avoid using extension cords unless absolutely necessary, and ensure any extension cord used is rated for the appropriate power requirements.

Operating Instructions

Once the PKPower AC Power Cord is properly connected to both your Cen-Tech Jump Starter and a power outlet, the jump starter will begin to receive power. The operation of the jump starter itself is governed by its own user manual. This power cord serves solely as the conduit for AC power.

- Ensure the power cord is not kinked, pinched, or placed under heavy objects during operation.
- Keep the power cord away from water, excessive heat, and sharp edges.
- Do not unplug the cord by pulling on the cable; always grasp the plug firmly.

Maintenance

Proper maintenance extends the life of your power cord and ensures safe operation.

- **Cleaning:** Disconnect the power cord from both the device and the wall outlet before cleaning. Wipe the cord with a soft, dry cloth. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, coil the power cord loosely. Avoid tight coiling or bending, which can damage the internal wires. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Regular Inspection:** Periodically inspect the cord for any signs of wear, such as cracks in the insulation, exposed wiring, or bent/damaged prongs. If any damage is observed, discontinue use immediately and replace the cord.

Troubleshooting

If you encounter issues with your PKPower AC Power Cord, refer to the following common problems and

solutions:

Problem	Possible Cause	Solution
Device not receiving power.	Cord not fully plugged in.	Ensure both ends of the cord are securely plugged into the device and the wall outlet.
Device not receiving power.	Wall outlet is not active.	Test the wall outlet with another known working appliance. Check circuit breaker if necessary.
Device not receiving power.	Damaged power cord.	Inspect the cord for visible damage. If damaged, discontinue use and replace the cord.
Loose connection.	Worn connectors or improper fit.	Ensure the cord is compatible with your device. If connectors are worn, replace the cord.

If the problem persists after attempting these solutions, contact customer support for further assistance.

Specifications

Feature	Detail
Cable Length	6 feet (approx. 1.8 meters)
Input Voltage	100-240V AC
Connector Type (Male)	US 3-prong grounded plug
Connector Type (Female)	IEC C13 (3-pin)
Color	Black
Product Dimensions	3 x 2 x 0.5 inches (packaging/coiled)
Item Weight	2 ounces
Manufacturer	Shenzhen AiNaU Technology Co.,Ltd

Warranty and Support

PKPOWER AC adapter charger has passed the FCC test with certificates, ensuring high safety performance. The superior quality of this charger totally eliminates all safety hazards which can provide you with an extremely safe and pleased charging experience.
For product support, inquiries, or warranty claims, please refer to the contact information provided with your purchase or visit the official PKPOWER website. Keep your purchase receipt as proof of purchase.

© 2024 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DGX43DNW

More documents and user manuals: **https://manuals.plus/**