Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC Power Cord

PKPOWER AC Power Cord User Manual

For AXV Fr-298 Vibration Plate Exercise Machine

1. Introduction

Thank you for choosing the PKPOWER AC Power Cord. This power cord is designed to provide reliable power to your AXV Fr-298 Vibration Plate Exercise Machine. This manual provides essential information for safe and effective use, including setup, operation, maintenance, and troubleshooting.



An image showing the PKPOWER AC Power Cord, neatly coiled, with one end featuring a three-prong plug visible. This cord is designed for connecting compatible devices to a power outlet.

2. Important Safety Instructions

Please read and understand all safety instructions before using the power cord. Failure to follow these instructions may result in electric shock, fire, or damage to the product or connected equipment.

- **Compatibility:** Use this power cord only with devices that require a 3-prong AC power input and are compatible with the specified voltage range (100-240V). This cord is specifically designed for the AXV Fr-298 Vibration Plate Exercise Machine.
- **Voltage:** Ensure the voltage of your power outlet matches the input voltage requirements of your device. This cord supports 100-240V AC input.
- **Inspection:** Before each use, inspect the power cord for any signs of damage, such as cuts, frayed wires, or bent prongs. Do not use a damaged cord.
- **Placement:** Do not place the power cord in areas where it can be tripped over, pinched, or exposed to excessive heat or moisture.
- **Handling:** Always grasp the plug, not the cord, when connecting or disconnecting from a power outlet or device.
- **Overload:** Do not overload electrical outlets. Ensure the total power draw of connected devices does not exceed the outlet's capacity.
- **Indoor Use:** This power cord is intended for indoor use only.
- **Children:** Keep the power cord out of reach of children.

The PKPOWER AC adapter charger has passed FCC testing, ensuring its safety and quality standards.

3. Setup Instructions

Follow these steps to properly connect your PKPOWER AC Power Cord to your AXV Fr-298 Vibration Plate Exercise Machine.

1. **Ensure Device is Off:** Before connecting the power cord, ensure your AXV Fr-298 Vibration Plate Exercise Machine is turned off and unplugged from any existing power source.
2. **Connect to Device:** Locate the power input port on your AXV Fr-298 Vibration Plate Exercise Machine. Insert the C13 connector end of the PKPOWER AC Power Cord firmly into this port.
3. **Connect to Power Outlet:** Insert the three-prong wall plug end of the PKPOWER AC Power Cord into a standard, grounded electrical wall outlet.
4. **Verify Connection:** Ensure both ends of the power cord are securely connected.
5. **Power On:** You may now turn on your AXV Fr-298 Vibration Plate Exercise Machine according to its own operating instructions.



An image presenting the PKPOWER AC Power Cord with its standard three-prong wall plug and the C13 connector aligned, illustrating the distinct ends of the power cable for proper connection.

4. Operating Instructions

The PKPOWER AC Power Cord functions as a direct power supply for your compatible device. Once properly connected as described in the 'Setup Instructions' section, the power cord will deliver electrical current from the wall outlet to your AXV Fr-298 Vibration Plate Exercise Machine.

- Ensure the power cord is not kinked, twisted, or under any tension during operation.
- Do not cover the power cord with rugs, furniture, or other objects that could impede heat dissipation or cause damage.
- If the device is not in use for an extended period, it is recommended to unplug the power cord from both the device and the wall outlet.

5. Care and Maintenance

Proper care and maintenance will extend the life of your PKPOWER AC Power Cord.

- **Cleaning:** Disconnect the power cord from all power sources before cleaning. Wipe the cord with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.

- **Storage:** When not in use, coil the power cord loosely. Avoid tight coiling or bending at sharp angles, which can damage the internal wires. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the cord for any signs of wear or damage. Replace the cord immediately if any damage is observed.

6. Troubleshooting

If you experience issues with your power cord, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Device does not power on.	Cord not fully plugged in.	Ensure both ends of the power cord are securely connected to the device and the wall outlet.
Device does not power on.	Wall outlet is not active.	Test the wall outlet with another known working device. Check circuit breaker if necessary.
Device does not power on.	Power cord is damaged.	Inspect the power cord for visible damage. If damaged, discontinue use and replace.
Power cord feels warm.	Normal operation or slight overload.	A slight warmth is normal. If the cord becomes excessively hot, unplug immediately and contact support. Ensure the device's power requirements do not exceed the cord's capacity.

7. Product Specifications

Below are the technical specifications for the PKPOWER AC Power Cord.

Feature	Specification
Product Name	PKPOWER AC Power Cord
Model Compatibility	AXV Fr-298 Vibration Plate Exercise Machine
Cable Length	6 feet (approx. 1.8 meters)
Input Voltage	100-240V AC
Color	Black
Connector Type	NEMA 5-15P (Male) to IEC C13 (Female)
Item Weight	2 ounces (approx. 56 grams)
Manufacturer	Shenzhen AiNaU Technology Co.,Ltd

8. Warranty and Customer Support

PKPOWER stands behind the quality of its products. If you encounter any issues or have questions regarding your AC Power Cord, please do not hesitate to contact our customer support team.

For assistance, please refer to the contact information provided with your purchase or visit the official PKPOWER store page on Amazon. Our team is dedicated to providing a satisfactory experience and will assist with product-related inquiries or concerns.

© 2024 PKPOWER. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DGX45HGC

More documents and user manuals: **https://manuals.plus/**