Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YOTMS Q6

YOTMS Wireless Gaming Headset Q6 Instruction Manual

Model: Q6 | Brand: YOTMS

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your YOTMS Wireless Gaming Headset Model Q6. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

What's in the Box




Image: All components included with the YOTMS Q6 Wireless Gaming Headset.

- YOTMS Q6 Wireless Gaming Headset
- Detachable Microphone
- 2-in-1 USB Transmitter (USB-A and USB-C)
- 3.5mm Audio Cable
- USB Charging Cable
- User Manual

Product Overview

Familiarize yourself with the headset's components and controls.



Image: The YOTMS Q6 Wireless Gaming Headset and its USB transmitter.

Headset Controls



Image: Key control buttons on the headset for wireless and Bluetooth modes.

- **Volume +** / **Next Song Button:** Press to increase volume. Hold to skip to the next song (in Bluetooth mode).
- **Power** / **Play/Pause** / **LED Button:** Press and hold to power on/off. Short press to play/pause media. Double press to toggle LED lights.
- **Volume -** / **Previous Song Button:** Press to decrease volume. Hold to go to the previous song (in Bluetooth mode).
- **2.4G** / **Bluetooth Switch Button:** Press to switch between 2.4GHz wireless mode and Bluetooth mode.
- **Microphone Port:** For connecting the detachable microphone.
- **3.5mm Audio Port:** For wired connection.
- **USB-C Charging Port:** For charging the headset.

Detachable Microphone



Image: The detachable microphone and its connection point on the headset.

The omni-directional microphone can be adjusted for optimal voice pickup and can be detached when not needed. Ensure it is inserted into the correct microphone port, not the 3.5mm audio interface, to prevent malfunction.

Setup Instructions

The YOTMS Q6 headset supports multiple connection modes for various devices.

1. 2.4GHz Wireless Mode (for PS4, PS5, PC, Switch, Laptop, Mac, Tablet)



Image: USB transmitter connections for various gaming platforms.

1. Insert the 2-in-1 USB transmitter into an available USB-A or USB-C port on your device (PS4, PS5, PC, Switch, Laptop, Mac, Tablet).
2. Power on the headset by pressing and holding the Power button.
3. Ensure the headset is in 2.4GHz mode (use the 2.4G/Bluetooth switch button if necessary). The headset will automatically connect to the transmitter.
4. Adjust audio settings on your device to select the headset as the input and output device.

Note:

- The 2-in-1 USB transmitter must be used as a single unit; it cannot be separated.
- 2.4GHz mode is not compatible with Xbox One.

2. Bluetooth Mode (for Laptop, Tablet, Handheld Devices)




Image: Visual representation of the two wireless connection modes.

1. Power on the headset.
2. Press the 2.4G/Bluetooth switch button to enter Bluetooth pairing mode. The LED indicator will flash, indicating it's ready to pair.
3. On your device (Laptop, Tablet, Phone), go to Bluetooth settings and search for "YOTMS Q6" (or similar).
4. Select the headset to pair. Once connected, the LED indicator will show a steady light.

Note:

- Bluetooth mode is primarily for non-gaming devices like laptops, tablets, and mobile phones.
- Bluetooth mode is not compatible with gaming consoles for audio and microphone functionality.

3. Wired Mode (for PC, Laptop, PS4, PS5, Switch, Xbox One)

1. Connect the 3.5mm audio cable to the headset's 3.5mm audio port.
2. Connect the other end of the 3.5mm audio cable to your device's 3.5mm audio jack.
3. If your device requires separate audio and microphone jacks (e.g., some PCs), use the included 3.5mm Y-splitter

cable.

4. The headset will function as a wired headset.

Note:

- In wired mode, the headset's internal battery is not used for audio transmission, but it may still be required for LED lighting.



Image: Device compatibility matrix for 2.4GHz, Wired, and Bluetooth modes.

Operating Instructions

Power On/Off

- To power on, press and hold the Power button until the LED indicator lights up.
- To power off, press and hold the Power button until the LED indicator turns off.

Volume Control

- Press the **Volume +** button to increase the audio volume.
- Press the **Volume -** button to decrease the audio volume.

Microphone Mute

The headset features a multi-functional button control that includes a mute function. Refer to the product overview section for the specific button location.

- Press the designated mute button (often integrated with the power/play/pause button or a separate switch) to mute or unmute the microphone.

LED Lights

- Double press the Power button to toggle the LED lights on or off.

Charging the Headset



Image: The headset highlighting its battery life.

- Connect the USB charging cable to the headset's USB-C charging port and the other end to a USB power source (e.g., computer, wall adapter).
- The LED indicator will show charging status (e.g., red for charging, off or blue for fully charged).
- A full charge typically takes approximately 3 hours.
- The headset provides up to 40 hours of battery life, though actual usage time may vary based on volume and LED light usage.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the headset. Do not use abrasive cleaners or solvents.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures. The headset is foldable for compact storage.
- **Battery Care:** To prolong battery life, avoid fully discharging the headset frequently. Charge it regularly, even if not in use for extended periods.

- **Water Resistance:** The headset is not water-resistant. Avoid exposure to liquids.



Image: Features highlighting the headset's comfortable and ergonomic design, including its foldable nature.

Troubleshooting

No Sound / Low Volume:

- Ensure the headset is powered on and connected correctly (2.4GHz, Bluetooth, or wired).
- Check the volume levels on both the headset and your connected device.
- For 2.4GHz mode, ensure the USB transmitter is fully inserted and recognized by the device.
- For Bluetooth mode, ensure the headset is paired and selected as the audio output on your device.
- In wired mode, ensure the 3.5mm cable is securely connected to both the headset and the device.

Microphone Not Working:

- Ensure the detachable microphone is securely inserted into the correct microphone port on the headset.

- Check if the microphone is muted on the headset or in your device's audio settings.
- Verify that the headset is selected as the input device in your device's sound settings.
- For wired connections, ensure the 3.5mm Y-splitter is used correctly if your device has separate mic/audio jacks.

Headset Disconnects / Turns Off Unexpectedly:

- Check the battery level and charge the headset if it is low.
- Ensure the headset is within the operating range of the 2.4GHz transmitter or Bluetooth device.
- Avoid sources of strong electromagnetic interference.

Cannot Connect via 2.4GHz Wireless:

- Ensure the USB transmitter is fully inserted into a compatible USB port.
- Verify the headset is switched to 2.4GHz mode.
- Try restarting both the headset and the connected device.

Cannot Connect via Bluetooth:

- Ensure the headset is in Bluetooth pairing mode (flashing LED).
- Make sure Bluetooth is enabled on your device and it is discoverable.
- Try unpairing and re-pairing the headset from your device's Bluetooth settings.

SPECIFICATIONS

Model Name	Q6
Connectivity Technology	2.4Ghz Wireless, Bluetooth 5.3, 3.5mm Wired
Wireless Communication Technology	2.4Ghz
Bluetooth Version	5.3
Bluetooth Range	10 Meters
Audio Latency (2.4Ghz)	Less than 25 milliseconds (specified as 20ms in specs)
Audio Driver Size	40 Millimeters
Sensitivity	88 dB
Earpiece Shape	Over Ear
Noise Control	Sound Isolation
Battery Life	Up to 40 Hours
Charging Time	Approximately 3 Hours
Item Weight	0.52 Kilograms (1.14 pounds)
Material	Plastic
Compatible Devices	Desktops, Gaming Consoles (PS4, PS5, Switch, Xbox One via wired), Laptops, Tablets, Mobile Phones

Warranty and Support

YOTMS is committed to providing high-quality products and excellent customer service. For any questions, technical support, or warranty inquiries, please contact YOTMS customer service.

- **Customer Service:** YOTMS offers 24-hour contact support. Please refer to the product packaging or the official YOTMS website for specific contact details.
- **After-Sales Service:** YOTMS strives to provide perfect after-sales service for an immersive gaming experience.

© 2025 YOTMS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DH2G2C6F

More documents and user manuals: **https://manuals.plus/**