Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DURACELL Charge 5V

DURACELL Charge 5V Portable Charger User Manual

Model: Charge 5V

1. Introduction

This manual provides comprehensive instructions for the safe and efficient use of your DURACELL Charge 5V Portable Charger. This 5,000mAh mobile power bank is designed to provide portable power for a variety of USB-powered devices, including smartphones and tablets. Please read this manual thoroughly before operating the device and retain it for future reference.

2. Product Overview

The DURACELL Charge 5V Portable Charger features a slimline design and a 5,000mAh battery capacity, offering convenient power on the go. It includes both USB-A and USB-C output ports for broad device compatibility.

2.1. Package Contents

- DURACELL Charge 5V Portable Charger
- USB-C to USB-C Charging Cable
- User Manual

2.2. Device Features

- **5,000mAh Capacity:** Provides extended battery life for mobile devices.
- **Dual Output Ports:** One USB-A port and one USB-C port for charging multiple devices.
- **Compact Design:** Slim and lightweight for easy portability.
- **LED Indicators:** Display current battery level and charging status.

2.3. Component Identification



Figure 1: Front view of the DURACELL Charge 5V Portable Charger, highlighting the USB-A and USB-C output ports, and the LED battery indicators on the side.

The portable charger features a USB-A output port and a USB-C input/output port. On the side, there are four small LED lights that indicate the remaining battery charge and the charging status of the power bank itself.

3. Setup and Initial Charging

Before using your DURACELL Charge 5V Portable Charger for the first time, it is recommended to fully charge it to ensure optimal performance.

3.1. Charging the Power Bank

1. Connect the included USB-C to USB-C cable to the USB-C port on the portable charger.
2. Connect the other end of the USB-C cable to a compatible USB wall adapter (not included) or a powered USB port.
3. The LED indicators on the side of the power bank will illuminate to show the charging progress. When all four LEDs are solid, the power bank is fully charged.



Figure 2: The portable charger connected to a power source via its USB-C port, indicating it is being recharged. The LED lights show the current charge level.

A full charge typically takes several hours, depending on the power source. Disconnect the power bank once fully charged.

4. Operating Instructions

The DURACELL Charge 5V Portable Charger can charge various devices using its USB-A and USB-C output ports.

4.1. Charging Your Device

1. Identify the correct charging cable for your device (e.g., USB-A to Lightning, USB-C to USB-C).
2. Connect one end of your device's charging cable to the appropriate output port (USB-A or USB-C) on the portable charger.
3. Connect the other end of the cable to your device's charging port.

4. The portable charger will automatically begin charging your device. The LED indicators will show the remaining battery level of the power bank.



Figure 3: The DURACELL Charge 5V Portable Charger connected to a smartphone via a charging cable, demonstrating its use as an external power source.

You can charge two devices simultaneously using both the USB-A and USB-C ports. The power bank will distribute power as needed.

4.2. Checking Battery Level

To check the remaining battery level of the portable charger, briefly press the power button (if present, or simply connect a device). The LED indicators will light up:

- **4 LEDs:** 75-100% charge
- **3 LEDs:** 50-75% charge
- **2 LEDs:** 25-50% charge
- **1 LED:** 0-25% charge (recharge soon)

5. Maintenance and Care

Proper maintenance ensures the longevity and optimal performance of your portable charger.

- **Cleaning:** Use a soft, dry cloth to clean the surface of the power bank. Avoid liquid cleaners or abrasive materials.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures. For long-term storage, it is recommended to charge the power bank to about 50-75% every three months.
- **Avoid Damage:** Do not drop, puncture, or disassemble the device. Keep it away from water and high humidity.

6. Troubleshooting

Problem	Possible Cause	Solution
Power bank not charging	Charging cable is faulty or not properly connected. Wall adapter is not working or insufficient.	Ensure the USB-C cable is securely connected to both the power bank and the power source. Try a different USB-C cable or wall adapter.
Device not charging from power bank	Device cable is faulty or not properly connected. Power bank battery is depleted. Device is incompatible.	Ensure your device's charging cable is securely connected to both the power bank and your device. Recharge the power bank. Verify device compatibility with USB-A or USB-C output.
Slow charging	Using a low-power wall adapter for the power bank. Using a non-fast charging cable for your device.	Use a higher-wattage USB wall adapter to charge the power bank. Ensure your device's cable supports fast charging if applicable.

7. Specifications

Model Number	Charge 5V
Battery Capacity	5,000 mAh
Battery Type	Lithium Polymer
Input	USB-C (10W max)
Output 1	USB-A (12W max)
Output 2	USB-C (10W max)
Dimensions (L x W x H)	3.82 x 0.67 x 5.71 inches

Weight	5.9 ounces
Special Features	Fast Charging

8. Safety Information

Please observe the following safety precautions to prevent damage to the product or injury to yourself.

- Do not expose the power bank to extreme temperatures (above 45°C or below 0°C).
- Do not expose to water, moisture, or high humidity.
- Do not disassemble, modify, or attempt to repair the device.
- Keep out of reach of children.
- Dispose of the power bank responsibly according to local regulations. Do not dispose of in household waste.
- Avoid dropping or subjecting the device to strong impacts.
- Do not use if the device is damaged, swollen, or leaking.

9. Warranty and Support

This DURACELL product is manufactured by VLC Mobile Power. For warranty information and customer support, please refer to the documentation included with your product packaging or visit the official DURACELL website. Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DH64RV4D

More documents and user manuals: **https://manuals.plus/**