Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fanbulous F-SN56BK-1X01

Fanbulous 56 Inch Chandelier Ceiling Fan with Lights and Remote

MODEL: F-SN56BK-1X01

Instruction Manual

1. Important Safety Instructions

Please read and understand all instructions before beginning installation. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- Ensure the power is turned off at the circuit breaker before installation or maintenance.
- All electrical connections must be in accordance with local codes, ordinances, or national electrical codes. If you are unfamiliar with electrical wiring, consult a qualified electrician.
- The ceiling fan must be mounted to a ceiling joist or support structure capable of supporting the fan's weight (approximately 19.66 pounds).
- Do not operate the fan with damaged blades or any visible defects.
- Keep hands, clothing, and other objects clear of the fan blades when the fan is in operation.

2. Package Contents

Verify that all components are present before proceeding with installation.

- Motor Housing Assembly
- Fan Blades (5 reversible blades)
- Crystal Light Fixture (pre-assembled)
- Remote Control with Wall Support
- Mounting Bracket
- Hardware Pack (screws, wire nuts, washers)
- Instruction Manual

Image: Overview of the Fanbulous 56 Inch Chandelier Ceiling Fan, showcasing its design and included remote control.

3. Setup and Installation

Estimated installation time: Approximately 40 minutes. The crystal part is pre-assembled for convenience.

1. **Prepare for Installation:** Turn off power at the main circuit breaker. Clear the installation area.
2. **Mounting Bracket Installation:** Secure the mounting bracket to a ceiling joist or a suitable support structure. Ensure it is firmly attached and can support the fan's weight.
3. **Wiring Connections:** Connect the fan's electrical wires to the household wiring according to the wiring diagram provided in the detailed instructions. Use appropriate wire nuts.
4. **Attach Motor Housing:** Carefully lift and attach the fan's motor housing to the mounting bracket.
5. **Install Fan Blades:** Attach the five reversible fan blades to the motor housing. Ensure all screws are tightened securely.
6. **Install Crystal Light Fixture:** The crystal light fixture comes pre-assembled. Attach it to the bottom of the motor housing.
7. **Install Bulbs:** This fan requires 3 E12 bulbs for optimal illumination (bulbs not included). Insert the bulbs into the sockets.



Image: Illustration of the easy installation process, highlighting the pre-assembled crystal light fixture being attached to the fan body.

4. Operating Instructions

The fan is operated using the included remote control.



Image: Diagram of the remote control, detailing buttons for power, light, fan speeds, rotation direction, and timer settings.

- **Power On/Off:** Press the 'ALL OFF' button to turn off both fan and light. Press the fan speed buttons (1-6) or 'Light On/Off' to activate.

- **Fan Speed Control:** Select from 6 adjustable speeds using the '1' through '6' buttons on the remote. '1' is the lowest speed (soft wind), and '6' is the highest speed (cool wind).
- **Light Control:** Press the 'Light On/Off' button to toggle the light.
- **Reversible DC Motor:** The fan features a reversible DC motor for year-round comfort.
  - **Summer Mode (Forward Rotation):** Press 'F' for downward airflow, creating a cooling effect.
  - **Winter Mode (Reverse Rotation):** Press 'R' for upward airflow, circulating warm air trapped near the ceiling.
- **Timer Function:** Set the fan to automatically turn off after 1, 2, or 4 hours using the respective timer buttons.
- **Natural Wind Mode:** Press the 'Natural Wind' button for a varying airflow that simulates a natural breeze.

Image: Visual representation of the fan's reversible function, showing downward airflow for cooling in summer and upward airflow for warm air circulation in winter.

5. Maintenance

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure power is off before cleaning.
- **Blade Cleaning:** Dust the fan blades regularly. The reversible blades feature walnut and light oak finishes; clean gently to preserve their appearance.
- **Crystal Fixture Cleaning:** Gently wipe the crystal elements with a soft, lint-free cloth to maintain their sparkle.
- **Bulb Replacement:** Always turn off power before replacing E12 bulbs. Allow bulbs to cool before handling.
- **Tighten Fasteners:** Periodically check and tighten all screws and fasteners on the fan and mounting hardware.

6. Troubleshooting

If you experience issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low or not paired.	Check circuit breaker; Verify all wire connections are secure; Replace remote batteries or re-pair remote.
Light does not work	Bulb faulty or loose; Loose wire connection; Remote control issue.	Replace bulb; Check light fixture wiring; Check remote battery.
Fan is noisy	Loose screws on fan blades or motor housing; Mounting bracket not secure; Blades unbalanced.	Tighten all screws; Ensure mounting bracket is secure; Use a balancing kit (not included) if necessary.
Remote control not working	Batteries dead or incorrectly inserted; Remote not paired with fan.	Replace AAA batteries (2 required, included); Refer to pairing instructions in the full manual.

7. Specifications

Feature	Detail
Brand	Fanbulous
Model Name	F-SN56BK-1X01
Product Dimensions	56"D x 56"W x 17.9"H
Color	Black
Style	Classic
Electric Fan Design	Ceiling Fan
Power Source	DC
Wattage	30 watts
Voltage	120 Volts
Number of Power Levels	6
Special Features	6 Adjustable Speeds, Crystal ceiling fan, Reversible DC Motor
Control Method	Remote
Included Components	Remote (2 AAA batteries included)
Indoor/Outdoor Usage	Indoor
Item Weight	19.66 pounds
Recommended Room Size	12ft x 12ft to 18ft x 18ft

Image: Detailed dimensions of the 56-inch ceiling fan and a visual guide for recommended room sizes (12ft x 12ft to 18ft x 18ft).

8. Warranty and Support

This Fanbulous ceiling fan has undergone professional inspection to ensure it meets technical standards.

- **Motor Warranty:** 5-year warranty.
- **Crystal Light Fixture Warranty:** 2-year warranty.
- **Customer Support:** 24-hour customer support is available to resolve any issues promptly.

For further assistance or to contact support, please visit the officialFanbulous Store.

© 2025 Fanbulous. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DHX6GN3Y

More documents and user manuals: **https://manuals.plus/**