Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Belleur CLJU001N

Belleur 8-in-1 Indoor Jungle Gym Instruction Manual

Model: CLJU001N

Introduction

This manual provides essential information for the safe assembly, operation, and maintenance of your Belleur 8-in-1 Indoor Jungle Gym. Please read these instructions carefully before assembly and retain them for future reference. This product is designed for children aged 1-6 years.

Important Safety Information

- **Adult Supervision Required:** Always supervise children during play.
- **Weight Capacity:** The jungle gym supports a maximum weight of 150 lbs (approximately 68 kg).
- **Material Safety:** Constructed from natural, high-quality wood with round edges and smooth surfaces to prevent scratches and scrapes.
- **Placement:** Use on a flat, stable surface indoors. Consider placing mat padding underneath for added safety.
- **Regular Inspection:** Periodically check all screws and connections to ensure they remain tight and secure. Do not use if any parts are loose or damaged.
- **Age Recommendation:** Suitable for children aged 1-6 years.



Figure 1: The Belleur 8-in-1 Indoor Jungle Gym highlighting premium quality craftsmanship and safety certifications (ASTM, CPC, CPSC, Childcare).

Product Components and Features

The Belleur 8-in-1 Indoor Jungle Gym offers multiple play features to engage children:

- **Double-Sided Board:** Functions as both a slide and a climbing rock wall.
- **Climbing Net:** A soft rope net for climbing.
- **Rope Ladder:** A flexible ladder for ascending and descending.
- **Monkey Bars:** Horizontal bars for swinging and climbing.
- **Square Swing:** A traditional swing seat.
- **Round Swing:** A circular swing seat.
- **Hanging Rings:** Two rings for gripping and hanging.
- **Upright Ladder:** A fixed ladder for climbing.



Figure 2: Visual representation of the 8-in-1 play features, demonstrating different ways children can interact with the gym.

Setup and Assembly

The Belleur 8-in-1 Indoor Jungle Gym is designed for straightforward assembly. Detailed instructions and all necessary accessories are included in the package.

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the included parts list.
2. **Follow Instructions:** Refer to the step-by-step assembly guide provided with your product. Ensure all connections are securely fastened.
3. **Tool Requirements:** Basic tools for assembly are typically included or commonly available.
4. **Final Check:** Before first use, ensure all screws are tightened and the structure is stable.



Figure 3: Example of assembly instructions and safety information provided with the product.

Operating Instructions

Encourage children to explore the various features of the jungle gym under adult supervision.

- **Sliding:** Children should sit upright on the slide and slide down feet first.
- **Climbing:** Encourage children to use both hands and feet when climbing the net, ladders, or rock wall.
- **Swinging:** Ensure children are seated properly on the swing and do not stand while swinging.
- **Monkey Bars:** Children should grip the bars firmly with both hands.



Figure 4: Children engaging with the slide and swing components of the indoor jungle gym.

Maintenance and Care

- **Cleaning:** The waterproof surface allows for easy daily maintenance. Wipe with a damp cloth and mild soap if necessary. Avoid harsh chemicals.
- **Inspection:** Regularly inspect all wooden parts for splinters, cracks, or damage. Check ropes and nets for fraying or wear.
- **Tighten Fasteners:** Periodically check and tighten all screws and bolts to maintain structural integrity.
- **Storage:** Store in a dry indoor environment to prevent wood damage.



Figure 5: Detail of the smooth, rounded corners and grooves, illustrating the thoughtful safety design for easy maintenance and child protection.

Troubleshooting

Problem	Possible Cause	Solution
Structure feels unstable or wobbly.	Loose screws or improper assembly.	Review assembly instructions and tighten all screws. Ensure the gym is placed on a level surface.
Parts appear damaged or broken.	Manufacturing defect or wear and tear.	Discontinue use immediately. Contact customer support for replacement parts or assistance.
Difficulty with assembly.	Unclear instructions or missing parts.	Carefully re-read the assembly manual. Verify all parts are present. Contact customer support if issues persist.

Product Specifications

- **Model Number:** CLJU001N
- **Brand:** Belleur
- **Recommended Age:** 1-6 years (Manufacturer recommended age: 24 months - 8 years)
- **Maximum Weight Capacity:** 150 lbs (approximately 68 kg)
- **Material:** Natural, high-quality wood
- **Item Weight:** 48 pounds (approximately 21.77 kg)
- **Package Dimensions:** 43.7 x 18.82 x 6.57 inches (approximately 111 x 47.8 x 16.7 cm)



Figure 6: Detailed dimensions of the Belleur 8-in-1 Indoor Jungle Gym.

Customer Support

Belleur is committed to providing excellent customer service. If you have any questions, concerns, or require assistance with your 8-in-1 Indoor Jungle Gym, please contact our customer support team. Refer to your purchase documentation for specific contact details.

We ensure peace of mind for you and your little ones.

© 2025 Belleur. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DHXCW86C

More documents and user manuals: **https://manuals.plus/**