Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OAKHAM HOME FlutedCabinet-2door-Gray-Set4

OAKHAM HOME Oxford Storage Cabinet Fluted Sideboard Buffet (4 Pack, Grey Oak)

Model: FlutedCabinet-2door-Gray-Set4

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your OAKHAM HOME Oxford Storage Cabinet Fluted Sideboard Buffet. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Figure 1: Assembled Oxford Storage Cabinet in Grey Oak.

Safety Information

- **Weight Limit:** Do not exceed the maximum weight capacity of 50 pounds per shelf. The overall cabinet weight capacity is not to exceed 100 pounds.
- **Anti-Tipping:** Secure the cabinet to the wall using the provided anti-tip hardware to prevent accidental tipping, especially in households with children or pets.
- **Stable Placement:** Place the cabinet on a flat, level, and stable surface to ensure proper balance and prevent wobbling.
- **Assembly:** Follow all assembly steps precisely. Do not skip steps or use unauthorized parts.



Figure 2: Rear view of the cabinet with anti-tip hardware for wall attachment.

Package Contents

Your package includes 4 units of the 2-door Oxford Storage Cabinet. Each component is labeled with stickers for easy identification. Please verify all parts are present before beginning assembly.

Specifications

Brand	OAKHAM HOME
Model Number	FlutedCabinet-2door-Gray-Set4
Color	Grey Oak
Material	Exterior Grade MDF Board, Engineered Wood (Top/Back), Aluminum (Handles)

Product Dimensions (L x W x H)	30.5" x 15.4" x 32.8" (per unit)
Number of Pieces	4
Number of Doors	2 (per unit)
Number of Shelves	1 adjustable shelf (per unit)
Weight Capacity (Shelf)	50 Pounds
Installation Type	Freestanding, Floor Mount
Required Assembly	Yes



Figure 3: Cabinet dimensions and load capacity.

Setup and Assembly

Assembly of the Oxford Storage Cabinet is designed to be straightforward, typically completed within 30 minutes per unit.

Detailed illustrated instructions are included with your package. A Phillips screwdriver is required for assembly.

Key Assembly Tips:

- **Identify Parts:** All components are labeled with stickers. Match these labels to the diagrams in the instruction manual.
- **Door Hinge Installation:** For easier installation, it is recommended to attach the cabinet doors and their hinges before securing the top panel of the cabinet. This provides better access for screwing in the four hinge screws on the inside of the cabinet.
- **Anti-Tip Hardware:** Always install the anti-tip hardware to secure the cabinet to a wall, following the instructions provided.



Figure 4: Detail of cabinet construction, highlighting 1.4-inch thick MDF, aluminum handles, and fluted panels.

Operating Instructions

Adjustable Shelves:

Each cabinet unit includes one adjustable shelf. This shelf offers 3 height options, with each adjustment point differing by 2.7 inches. To adjust the shelf height, remove the shelf, reposition the shelf pins to the desired level, and then place the shelf back

onto the pins. This allows for customization of the interior space to accommodate various items such as books, tools, or decorative objects.



Figure 5: Interior view demonstrating adjustable shelf positions and smooth hinges.

Multifunctional Use:

The Oxford Storage Cabinet is designed for versatile use across various rooms and functions. It can serve as a credenza, kitchen storage cabinet, TV console, buffet table, or a bar cabinet. Its adaptable design integrates seamlessly into living rooms, dining rooms, or entryways, providing both aesthetic appeal and practical storage.

Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean spills immediately to prevent staining or damage to the wood finish.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.

- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fading or discoloration of the wood finish.

Troubleshooting

Door Alignment Issues:

If the cabinet doors appear misaligned or have gaps after assembly, the hinges are adjustable. Refer to the detailed assembly instructions for specific guidance on adjusting the hinge mechanism. The hinges typically allow for adjustments in multiple directions (up/down, left/right, and forward/backward) to achieve perfect door alignment. Use a Phillips screwdriver for these adjustments.

Warranty and Support

For warranty information or customer support, please refer to the documentation included with your purchase or contact OAKHAM HOME customer service directly through their official channels. Keep your purchase receipt for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DJ2B84RH

More documents and user manuals: **https://manuals.plus/**