Hotdot HW-03

Hotdot Rechargeable Hand Warmers (Model HW-03)

User Manual

Introduction

The Hotdot Rechargeable Hand Warmers (Model HW-03) are designed to provide portable and consistent warmth. Featuring a 3200mAh battery, these hand warmers offer rapid heating and an extended operating time. They are equipped with an LED display for real-time temperature and battery level monitoring, and offer three adjustable heat settings. Built with an AI-powered temperature control chip, the device ensures safe and stable heating, making it suitable for various activities and environments.

What's in the Box

- Hotdot Rechargeable Hand Warmers (2 units)
- Charging Cable (USB Type-C, dual output for simultaneous charging)
- User Manual
- Magic Thermochromic Blessing Card
- Golden Bow Tie Gift Box

Setup

1. **Initial Charge:** Before first use, fully charge both hand warmers. Connect the provided dual-output USB Type-C charging cable to a compatible USB power adapter (not included) and to the charging ports on each hand warmer. The LED display will show the battery percentage during charging. A full charge typically takes approximately 3.5 hours.
2. **Inspect Device:** Ensure the device is free from any visible damage before use.



Image: The Hotdot hand warmer, illustrating its compact design and LED display.

Operating Instructions

1. **Power On/Off:** Press and hold the power button for approximately 3 seconds to turn the hand warmer on or off. The LED display will illuminate upon activation.
2. **Adjust Heat Level:** Once powered on, short press the power button to cycle through the three available heat settings. The temperature will be displayed on the LED screen. The settings are:
    - Level 1: Approximately 104°F (40°C)
    - Level 2: Approximately 113°F (45°C)
    - Level 3: Approximately 122°F (50°C)
3. **Switch Temperature Unit:** While the device is on and displaying temperature, quickly double-press the power button to switch between Fahrenheit (°F) and Celsius (°C) display modes.
4. **Check Battery Level:** When the device is off, a short press of the power button will briefly display the current

battery percentage on the LED screen.



Image: The hand warmer's LED display showing temperature and battery, with an illustration of the three heat levels.



Image: A close-up view of the hand warmer's heating surface, highlighting its rapid heat generation.

Magic Thermochromic Blessing Card

The included Magic Thermochromic Blessing Card allows for a personalized message to be revealed by heat. Write your message on the designated area, cover it with the provided magic sticker, and then apply the warmth from the hand warmer to reveal the hidden message. This feature is designed for a unique gifting experience.



Image: Step-by-step guide on how to use the thermochromic blessing card with the hand warmer.

Maintenance

- **Cleaning:** Wipe the surface of the hand warmer with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the device in water.
- **Storage:** Store the hand warmer in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Battery Care:** To prolong battery life, charge the device regularly, even if not used frequently. Avoid completely draining the battery before recharging.

Troubleshooting

Issue	Possible Cause	Solution

Issue	Possible Cause	Solution
Device does not turn on.	Low battery or device is off.	Charge the device fully. Press and hold the power button for 3 seconds.
Device is not heating.	Device is not powered on or heat level is too low.	Ensure the device is on. Short press the power button to increase the heat level.
Display is not working.	Device is off or battery is critically low.	Turn on the device. Charge the device if the battery is low.
Charging is slow or not occurring.	Faulty cable, power adapter, or connection.	Ensure the charging cable is securely connected. Try a different USB power adapter or cable.

If you encounter issues not listed here or if the problem persists after attempting the solutions, please contact customer support.



Image: Internal diagram highlighting the AI Smart Chip and integrated safety features.

Specifications

Model Name: HW-03

Brand: Hotdot

Battery Capacity: 3200 mAh

Charging Time: Approximately 3.5 Hours

Temperature Range: 104°F – 122°F (40°C – 50°C)

Material: Aluminum, Plastic

Power Source: Battery Powered

Reusability: Rechargeable

UPC: 732122384095

Item Package Dimensions: 9.17 x 6.85 x 0.83 inches

Package Weight: 0.38 Kilograms

Warranty & Support

Warranty: This Hotdot product is covered by a Lifetime Warranty, ensuring long-term reliability and customer satisfaction.

Please retain your proof of purchase for warranty claims.

Customer Support: For any questions, technical assistance, or warranty inquiries, please contact Hotdot customer support through the retailer's platform or the official Hotdot website. Refer to the contact information provided with your purchase or on the product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question