Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VEVOR MG-3570C

VEVOR MG-3570C Electric Tomato Strainer and Food Processor User Manual

Model: MG-3570C

1. Important Safety Instructions

Please read all instructions carefully before using the VEVOR Electric Tomato Strainer and Food Processor. Retain this manual for future reference.

- **Electrical Safety:** Ensure the power supply matches the voltage specified on the appliance. Do not immerse the motor unit in water or other liquids. Always unplug the appliance when not in use, before cleaning, or before assembling/disassembling parts.
- **Child Safety:** This appliance is not intended for use by children. Keep the appliance and its cord out of reach of children.
- **Handling Blades:** Blades and cutting plates are sharp. Handle them with extreme care to avoid injury.
- **Proper Use:** Use the appliance only for its intended purpose as described in this manual. Do not operate the appliance with a damaged cord or plug, or if it malfunctions or has been damaged in any manner.
- **Overheat Protection:** The unit features a built-in induction overheat protection system. If the motor overheats, the unit will automatically shut off. Allow it to cool down before resuming operation.
- **Ventilation:** Ensure adequate ventilation around the motor unit during operation.

2. Product Overview and Components

The VEVOR MG-3570C is a versatile electric food processor designed for straining tomatoes, grinding meat, stuffing sausages, and making kubbe. It features a powerful 700W pure copper motor and multiple attachments for various culinary tasks.

Main Components:

- Motor Unit (Main Body)
- Hopper/Food Tray
- Auger/Screw

- Grinding Head/Housing
- Cutting Plates (2 types for meat grinding)
- Stainless Steel Blade
- Tomato Grinding Kit (Strainer Cone, Juicer Attachment)
- Sausage Stuffer Attachments
- Kubbe Maker Attachments
- Food Pusher



Image: Overview of the VEVOR MG-3570C Electric Tomato Strainer with its various components and dimensions.

3. Setup and Assembly

Before first use, wash all detachable parts that will come into contact with food. Ensure the motor unit is unplugged.

1. **Attach Grinding Head:** Insert the grinding head into the motor unit opening and secure it by turning the locking ring clockwise until it clicks into place.

2. **Insert Auger:** Place the auger (screw) into the grinding head.
3. **Install Blade and Plate (for meat grinding):** Place the stainless steel blade onto the auger shaft, followed by the desired cutting plate. Ensure the blade's sharp edge faces outwards. Secure with the locking cap.
4. **Install Strainer Cone (for tomato straining):** For tomato straining, attach the strainer cone and juicer attachment to the grinding head.
5. **Attach Hopper:** Place the food hopper/tray onto the top of the grinding head.
6. **Position Unit:** Place the assembled unit on a stable, flat, and dry surface.



Image: Illustration of how to assemble and disassemble the VEVOR MG-3570C for use and cleaning.

4. Operating Instructions

Ensure the unit is properly assembled and plugged into a suitable power outlet.

General Operation:

- **Power On/Off:** Use the knob to turn the appliance ON or OFF.

- **Speed Settings:** The unit offers two adjustable speeds. Select the appropriate speed for your ingredients.
- **Reverse Function:** If ingredients become jammed, turn the knob to the "Reverse" (REV) position. This will rotate the auger in the opposite direction to clear blockages. Return to the OFF position before restarting in the forward direction.
- **Feeding Ingredients:** Use the food pusher to guide ingredients into the feeding port.**Never use your fingers or other utensils to push food.**

Tomato Straining:

1. Assemble the unit with the tomato grinding kit (strainer cone and juicer attachment).
2. Wash and cut tomatoes into pieces no larger than 1.57 inches (4 cm).
3. Place a collection bowl under the juice outlet and a separate bowl for pulp.
4. Turn the unit ON to the desired speed.
5. Slowly feed tomato pieces into the hopper using the food pusher.
6. Adjust the trough position as needed to direct the jam into your container.





Image: The VEVOR MG-3570C efficiently extracting tomato juice, highlighting key features like the reverse function and overheat protection.

Meat Grinding:

1. Assemble the unit with the stainless steel blade and desired cutting plate.
2. Cut meat into small pieces, removing bones, gristle, and tough tendons.
3. Place a collection bowl under the grinding head.
4. Turn the unit ON.
5. Feed meat pieces into the hopper using the food pusher.



Image: The VEVOR MG-3570C configured for meat grinding, showcasing the stainless steel blade and two interchangeable cutting plates.

Sausage Stuffing and Kubbe Making:

Refer to the specific instructions included with the sausage stuffer and kubbe maker attachments for detailed assembly and operation.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your appliance. Always unplug the unit before cleaning.

1. **Disassembly:** Disassemble all removable parts in reverse order of assembly.
2. **Washing:** Wash all detachable accessories (grinding head, auger, blades, plates, hopper, attachments) with warm, soapy water. Rinse thoroughly and dry immediately to prevent rust.
3. **Dishwasher Safety:** Some accessories are dishwasher safe. However, **do not wash the jam maker's blade or the aluminum food tray in the dishwasher**, as this may cause discoloration or damage.
4. **Motor Unit:** Wipe the motor unit with a damp cloth. Never immerse the motor unit in water.
5. **Storage:** Ensure all parts are completely dry before reassembling or storing the appliance. Store in a cool, dry place.



Image: Cleaning instructions for the VEVOR MG-3570C, illustrating which parts are dishwasher safe and how to hand wash removable accessories.

6. Troubleshooting

If you encounter issues with your VEVOR Electric Tomato Strainer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power switch off; motor overheated.	Check power connection; ensure switch is ON; allow motor to cool down if overheat protection activated.
Food is not processing or unit jams.	Ingredients too large; too much food fed at once; blockage in auger.	Cut ingredients into smaller pieces (e.g., tomatoes < 1.57"/4cm); feed food slowly; use the "Reverse" function to clear blockages.
Juice/sauce is not smooth or contains too much pulp.	Ingredients not processed thoroughly; strainer cone clogged.	Ensure ingredients are cut to appropriate size; clean the strainer cone if clogged; process ingredients multiple times if necessary.
Unit leaks during operation.	Improper assembly; seals not correctly seated.	Disassemble and reassemble all parts carefully, ensuring all connections are tight and seals are properly in place.

7. Specifications

Detailed technical specifications for the VEVOR MG-3570C Electric Tomato Strainer and Food Processor.

Feature	Specification
Model Number	MG-3570C
Rated Power	700W
Color	Black/White
Material	Stainless Steel, Aluminum, and Plastic (ABS for Main Unit)
Item Weight	10.58 Pounds (4.8 kg)
Product Dimensions (L x W x H)	11.0" x 7.1" x 8.9" (280 x 180 x 225 mm)
Product Dimensions (Juicing, with Pusher)	20.3" x 7.1" x 14.6" (515 x 180 x 370 mm)
Hopper Size	9.0" x 6.5" x 2.1" (228.5 x 164 x 53.5 mm)
Adjustable Settings	2 Speeds
Reversible Function	Yes
Motor Type	Pure Copper Motor



Image: Detailed specifications and a visual list of included accessories for the VEVOR MG-3570C.

8. Warranty and Support

For warranty information, please refer to the documentation provided with your purchase or visit the official VEVOR website. VEVOR is committed to providing quality products and customer satisfaction.

If you require technical assistance, have questions about operation, or need to report an issue, please contact VEVOR customer service through their official channels. Be prepared to provide your model number (MG-3570C) and purchase details.

VEVOR Official Website: www.vevor.com

© 2026 VEVOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DJGCFGMV

More documents and user manuals: **https://manuals.plus/**