Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OAKHAM HOME OFCD0007GY

OAKHAM HOME Fluted 7 Drawer Dresser Instruction Manual

Model: OFCD0007GY (Grey Oak, 15.4"D x 46.6"W x 32"H)

1. Important Safety Information

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- **Anti-Tip Device:** This dresser includes an anti-tip device. It is crucial to install this device to prevent serious injury or death from furniture tip-over. Always secure the dresser to a wall using the provided hardware.
- **Weight Limits:** Do not exceed the maximum weight capacity for the top surface (100 lbs) and individual drawers (25 lbs). Overloading can cause instability and damage.
- **Children Safety:** Never allow children to climb on or play with the dresser. Keep heavy items in the lowest drawers.
- **Level Surface:** Always place the dresser on a flat, level surface to ensure stability.
- **Assembly:** Assembly should be performed by at least two adults. Ensure all fasteners are securely tightened before use. Periodically check and re-tighten fasteners as needed.

2. Package Contents

Before beginning assembly, ensure all parts and hardware are present and undamaged. Refer to the detailed parts list and diagrams included in your physical assembly manual. If any parts are missing or damaged, please contact customer support.



Image: Front and back view of the dresser, illustrating its complete structure.

3. Assembly Instructions

This dresser requires assembly. Detailed, step-by-step instructions with diagrams are included in the product packaging. Please follow these instructions carefully.

- **Preparation:** Clear a spacious area for assembly. Lay out all parts on a soft, clean surface to prevent scratches.
- **Tools:** Ensure you have the necessary tools as specified in the assembly manual (typically a screwdriver and hammer).
- **Step-by-Step:** Follow the numbered steps in the provided manual precisely. Do not overtighten screws unless specified.
- **Drawer Installation:** Pay close attention to the drawer slide installation to ensure smooth operation.
- **Anti-Tip Installation:** Securely attach the anti-tip device to the dresser and a wall stud as per the instructions.

This step is critical for safety.



Image: Detailed view of the dresser's features, including the fluted panel design, smooth-gliding drawers, and stabilizing foot pads.

4. Operating Instructions

The OAKHAM HOME Fluted 7 Drawer Dresser is designed for easy and efficient storage.

- **Drawer Use:** Gently pull and push drawers using the metal handles. Avoid forcing drawers open or shut.
- **Weight Distribution:** Distribute weight evenly within drawers. Place heavier items in lower drawers to enhance stability.
- **Top Surface:** The top surface can hold up to 100 lbs. Use it for decorative items, lamps, or other light objects. Avoid placing hot items directly on the surface without protection.



Image: The dresser with multiple drawers open, demonstrating its large storage capacity for various items.

5. Maintenance and Care

Proper care will ensure the longevity and appearance of your dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Clean spills immediately with a dry cloth to prevent staining or water damage.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Humidity:** Maintain a stable humidity level in the room to prevent warping or cracking of the engineered wood.
- **Hardware:** Periodically check and tighten all screws and fasteners to ensure the dresser remains stable and secure.



Image: A detailed view highlighting the quality construction, including the 1.4-inch thick MDF, durable aluminum handles, and the distinctive fluted panel design.

6. Troubleshooting

If you encounter any issues with your dresser, refer to these common solutions:

- **Drawers are Sticking/Not Closing Smoothly:**
  - Check if the drawer slides are properly aligned and free of obstructions.
  - Ensure the drawer is not overloaded, which can cause misalignment.
  - Verify that all assembly screws for the drawer slides are tightened.
- **Dresser is Unstable/Wobbly:**
  - Ensure the dresser is on a completely flat and level surface.

- Check that all assembly fasteners are securely tightened.
- Confirm the anti-tip device is correctly installed and secured to the wall.

- **Missing or Damaged Parts:**
  - Refer to the contact information in the 'Warranty and Support' section for assistance.

7. Specifications

Feature	Detail
Brand	OAKHAM HOME
Model Name	OFCD0007GY
Color	Grey Oak
Material	Engineered Wood
Finish Type	Painted
Product Dimensions (D x W x H)	15.4" x 46.6" x 32"
Number of Drawers	7
Item Weight	132 Pounds
Mounting Type	Floor Mount
Required Assembly	Yes



Image: Dimensional diagram of the dresser, including width, depth, height, and weight capacities.

8. Warranty and Support

OAKHAM HOME is committed to providing a positive customer experience. If you have any questions about your product, including assembly, missing parts, or general inquiries, please do not hesitate to contact our friendly service team.

- **Customer Service:** Our team is available to assist you within 24 hours. Refer to your purchase documentation or the OAKHAM HOME website for specific contact details.
- **Returns:** This product is eligible for 30-day easy returns. Please consult the retailer's return policy for full details.

© 2026 OAKHAM HOME. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DJLTWL9W

More documents and user manuals: **https://manuals.plus/**