**Manuals+**
Q & A | Deep Search | Upload



## KeeKit B0DJSRQFS7

# KeeKit 7-Inch Digital Alarm Clock User Manual (Model: B0DJSRQFS7)

Comprehensive instructions for your KeeKit Digital Alarm Clock.

## Product Overview

The KeeKit 7-Inch Digital Alarm Clock is designed for home use, featuring a large LED display and multiple functionalities to enhance your daily routine. Key features include automatic time synchronization via Bluetooth, adjustable display brightness, dual alarms, and flexible power options.

- **Bluetooth Automatic Time Sync:** Eliminates manual time setting by pairing with a smartphone for daily synchronization.
- **Large Display with Adjustable Dimmer:** A 7-inch LED display ensures clear visibility, with 5 levels of brightness adjustment and an optional night mode.
- **Adjustable Volume:** Alarm volume can be set to 3 levels, suitable for various sleep depths.
- **Dual Alarm Clock:** Allows setting two distinct alarms for different schedules, with a 9-minute snooze function.
- **2 Power Supplies:** Operates via USB cable for continuous display or dry batteries for power-saving mode with a 10-second screen timeout.
- **Built-in USB Charging Port:** Conveniently charge smartphones and other devices.

## Setup

### Powering the Device

The alarm clock can be powered in two ways:

1. **USB Cable (Recommended for continuous display):** Connect the provided USB cable to the clock and a compatible USB power adapter (not included) or a USB port. The screen will remain continuously on.
2. **AAA Batteries (Power-saving mode):** Insert 3 AAA batteries (not included) into the battery compartment. In this mode, the screen will turn off after 10 seconds of inactivity to conserve power. Press any button to illuminate the screen.

Image: The KeeKit digital alarm clock displaying the time, with a smartphone connected to its side USB port for charging.

### Bluetooth Time Synchronization

To automatically set the time, use the Bluetooth sync feature:

1. Plug in the alarm clock. The time will default to 12:00, and the Bluetooth icon will flash, indicating search mode.
2. On your smartphone, enable Bluetooth and search for the device named "WA155".
3. Confirm pairing. Once connected, the Bluetooth icon on the clock will stop flashing, and the time will synchronize with your phone.

Image: A visual guide demonstrating the Bluetooth pairing process, from plugging in the clock to confirming synchronization with a smartphone.

*Note: Bluetooth connection is solely for time calibration and does not involve privacy-related information.*

## Operating Instructions

### Adjusting Display Brightness

The clock features 5 levels of brightness and an optional night mode:

- **Manual Adjustment:** Press the "DIMMER" button on the top of the clock to cycle through 5 brightness levels (High, Medium, Low, Ultra Low, Off).
- **Night Mode:** Long press the "DIMMER" button to activate or deactivate Night Mode. When active, the display brightness automatically adjusts to 3% between 7 PM and 7 AM.




Image: The alarm clock shown with its display set to various brightness levels, including high, medium, low, ultra low, and off.

### Setting Alarms

The clock supports two independent alarms:

1. Press the "ALARM1" or "ALARM2" button to select the desired alarm.
2. Use the "TIME" and "ALARM" buttons (or similar labeled buttons on the back) to set the hour and minute for the

alarm.

3. Press the corresponding alarm button again to confirm the setting.

**Snooze Function:** When an alarm sounds, press the large "SNOOZE/PAIR" button on top for an additional 9 minutes of sleep.

Image: A hand pressing the large "SNOOZE/PAIR" button on the top of the alarm clock, highlighting its snooze function and dual alarm capability.

### Adjusting Alarm Volume

The alarm volume can be adjusted to 3 levels:

- Use the "VOL" buttons (or similar labeled buttons on the back) to increase or decrease the alarm volume.
- Select a volume level appropriate for your sleep depth.

### 12H/24H Time Format

The clock supports both 12-hour and 24-hour time formats. Refer to the buttons on the back of the clock for the specific "12/24HR" button to toggle between these formats.

Image: The alarm clock displaying the time in 12-hour format (10:30) and 24-hour format (15:30) in different settings.

### Daylight Saving Time (DST)

The clock includes a DST function. Long press the "DST" button on the top or back of the clock to turn DST mode on or off, which will automatically adjust the time by one hour.

## Maintenance

To ensure optimal performance and longevity of your KeeKit Digital Alarm Clock, follow these general maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to gently wipe the display and exterior surfaces. Avoid abrasive cleaners or solvents that could damage the finish.
- **Placement:** Place the clock on a stable, flat surface away from direct sunlight, excessive heat, or moisture.
- **Battery Replacement:** If using battery power, replace AAA batteries when the display becomes dim or unresponsive. Ensure correct polarity when inserting new batteries.

- **Power Cord Care:** Handle the USB power cable carefully. Avoid bending, twisting, or placing heavy objects on it to prevent damage.

## Troubleshooting

If you encounter issues with your KeeKit Digital Alarm Clock, refer to the following common solutions:

- **Clock Not Displaying Time:**
  - Ensure the USB cable is securely connected to both the clock and a power source.
  - If using batteries, check if they are inserted correctly and have sufficient charge. Replace if necessary.
- **Time Synchronization Issues:**
  - Verify that Bluetooth is enabled on your smartphone and the clock is in pairing mode (flashing Bluetooth icon).
  - Ensure your smartphone is within close proximity to the clock during pairing.
  - If the clock loses accurate time, re-pair it with your smartphone via Bluetooth.
- **Display Too Bright/Dim:**
  - Press the "DIMMER" button to cycle through the 5 brightness levels.
  - Long press the "DIMMER" button to toggle Night Mode on/off.
- **Alarm Not Sounding:**
  - Check if the alarm is enabled (alarm icon visible on display).
  - Ensure the alarm volume is not set to the lowest level.
- **Battery Backup Not Working (Time Reset after Power Outage):**
  - Confirm that 3 AAA batteries are correctly installed in the battery compartment. These batteries are for memory retention during power outages, not for continuous display power.

## Specifications

| Feature | Detail |
|---|---|
| Brand | KeeKit |
| Model | B0DJSRQFS7 |
| Color | Black |
| Display Type | Digital |
| Product Dimensions | 6.57"W x 2.91"H |
| Power Source | USB (main), 3 AAA batteries (backup) |
| Connectivity Technology | USB, Bluetooth |
| Special Feature | Bluetooth Sync Time, Adjustable Brightness, Dual Alarm, USB Charging Port, Power Saving Mode, Night Mode |
| Item Weight | 6.6 ounces |

| Feature | Detail |
| --- | --- |
| Manufacturer | KeeKit |

Image: The KeeKit digital alarm clock with dimensions indicated, demonstrating its compact size and the presence of USB charging ports.

## Official Product Videos

### Digital Alarm Clock Large Display

Your browser does not support the video tag.

Video Description: This video showcases the large digital display of the alarm clock, highlighting its clear visibility and various features. It demonstrates the clock's functionality in a home setting.

## Warranty and Support

KeeKit is dedicated to providing quality products and customer satisfaction. For support, please refer to the following:

- **1-Year Warranty:** The product is covered by a 1-year warranty.
- **30-Day Return Guarantee:** Customers are eligible for returns within 30 days of purchase.
- **90-Day Replacement Guarantee:** A replacement guarantee is offered for 90 days.
- **24/7 Online Customer Support:** Access continuous online support for any inquiries.
- **Lifetime Technical Support Service:** Benefit from lifetime technical assistance for your product.

For further assistance, please visit the KeeKit Store or contact customer support.

© 2024 KeeKit. All rights reserved.