Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Crecolife LD1201

Crecolife LD1201 Dehumidifier

User Manual

1. Introduction

This manual provides essential information for the safe and efficient operation of your Crecolife LD1201 Dehumidifier. Please read it thoroughly before use and retain it for future reference.

2. Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Ensure the power supply matches the voltage specified on the rating label.
- Do not operate the dehumidifier with a damaged cord or plug.
- Keep the appliance away from water and other liquids.
- Do not block air inlets or outlets. Maintain at least 20 cm clearance around the unit.
- Unplug the unit before cleaning or performing any maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not use the dehumidifier in areas where flammable gases or liquids are stored.

3. Product Features

The Crecolife LD1201 Dehumidifier is designed for efficient moisture removal and improved air quality.

- **High Efficiency:** Removes up to 12 liters of water per day in areas up to 20m² (50m³).
- **Intelligent Humidity Control:** Automatically maintains desired humidity levels (30% to 80%).
- **Multiple Modes:** Features Dehumidification, Continuous Dehumidification, and Drying modes.
- **Energy Saving:** Low power consumption of 190W.
- **24-Hour Timer:** Schedule operation for convenience.
- **Quiet Operation:** Noise level below 40 dB.

- **Automatic Defrost:** Prevents ice build-up for continuous performance.
- **Child Lock:** Prevents accidental changes to settings.
- **Dual Drainage Options:** 1.6L water tank for manual emptying or continuous drainage with a 1-meter hose.



Overview of Crecolife Dehumidifier features and capabilities.



Illustration of the dehumidifier's energy-saving benefits.

4. Package Contents

Upon unpacking, please ensure all items are present and in good condition:

- Crecolife LD1201 Dehumidifier Unit
- 1.6 Liter Water Tank (pre-installed)
- 1-meter Continuous Drain Hose
- User Manual

5. Setup

5.1 Unpacking

Carefully remove the dehumidifier from its packaging. Retain the packaging for future storage or transport.

5.2 Placement

Place the dehumidifier on a flat, stable surface in the desired location. Ensure there is at least 20 cm of clear space around all sides of the unit for proper airflow. The unit is suitable for rooms up to 20m² (50m³), such as bathrooms, small basements, laundry rooms, closets, bedrooms, kitchens, and storage rooms.



Dehumidifier placed in a typical living room setting.



Dehumidifier positioned in a walk-in closet for moisture control.



Dehumidifier in a laundry room, ideal for drying clothes.

5.3 Power Connection

Plug the power cord into a grounded electrical outlet. Ensure the outlet meets the power requirements of the unit.

6. Operating Instructions

6.1 Control Panel Overview

The dehumidifier features a digital display and touch control panel for easy operation. The digital screen displays real-time humidity levels.



The main unit showing the control panel and water tank indicator.

6.2 Power On/Off

Press the Power button on the touch control panel to turn the unit ON or OFF.

6.3 Humidity Setting

In Dehumidification mode, use the humidity setting buttons to adjust the desired humidity level between 30% and 80%.

6.4 Dehumidification Modes

- **Dehumidification Mode:** The unit operates until the set humidity level is reached, then automatically shuts off.
- **Continuous Dehumidification Mode:** The unit runs continuously regardless of the humidity level. Ideal for very damp environments.
- **Drying Mode:** Designed for quick drying of clothes, providing strong dehumidification.

6.5 Timer Function

The 24-hour timer allows you to schedule the dehumidifier's operation. Press the "Timer" button in standby or operating mode to set the desired start and stop times.

6.6 Child Lock

Activate the Child Lock function to prevent accidental changes to settings. Refer to the control panel instructions for specific button combinations to engage/disengage.

7. Water Drainage

The dehumidifier offers two options for water drainage.

7.1 Manual Drainage (Water Tank)

The unit is equipped with a 1.6-liter water tank. When the tank is full, the dehumidifier will automatically shut off, and an indicator light will illuminate. Carefully remove the tank, empty the collected water, and reinsert it securely.

7.2 Continuous Drainage

For continuous operation without manual emptying, attach the provided 1-meter soft water hose to the continuous drainage port on the unit. Route the hose to a suitable drain or larger container, ensuring it is sloped downwards for proper water flow.

8. Maintenance

Regular maintenance ensures optimal performance and longevity of your dehumidifier.

8.1 Cleaning the Air Filter

The air filter should be cleaned every two weeks or more frequently depending on usage. Remove the filter, gently clean it with a vacuum cleaner or wash it with warm, soapy water. Ensure it is completely dry before reinserting.

8.2 Cleaning the Water Tank

Clean the water tank regularly to prevent mold and mildew growth. Use mild detergent and warm water, then rinse thoroughly. Dry completely before reinserting.

8.3 Automatic Defrost Function

The unit features an automatic defrost function. If frost builds up on the evaporator coils, the unit will temporarily stop

dehumidifying and run the fan to melt the frost. Do not attempt to manually defrost the unit.

8.4 Storage

If storing the unit for an extended period, ensure the water tank is empty and clean. Clean the air filter. Store the unit upright in a dry, cool place, preferably in its original packaging.

9. Troubleshooting

Refer to this table for common issues and their solutions.

Problem	Possible Cause	Solution
Dehumidifier does not turn on.	No power supply; Power cord not plugged in; Water tank full or not properly inserted.	Check power connection; Empty and reinsert water tank correctly.
No water collected.	Room humidity too low; Temperature too low (below 5°C); Air filter clogged; Unit in continuous drainage mode.	Increase target humidity; Ensure room temperature is adequate; Clean air filter; Check continuous drainage hose.
Unit is noisy.	Unit not on a level surface; Air filter clogged.	Place on a flat surface; Clean air filter.
Airflow is weak.	Air filter clogged; Air inlet/outlet blocked.	Clean air filter; Remove any obstructions.
Frost on coils.	Room temperature too low.	Automatic defrost will activate. Do not manually remove frost.

10. Specifications

Attribute	Value
Model Number	LD1201
Brand	Crecolife
Dehumidification Capacity	12 Liters/24 Hours
Applicable Area	20m² / 50m³
Power Consumption	190W
Water Tank Capacity	1.6 Liters
Noise Level	Below 40 dB
Product Dimensions (L x W x H)	19.5 x 27.5 x 45.9 cm
Item Weight	11 Kilograms
Color	White

11. Warranty and Support

Crecolife dehumidifiers are manufactured with high-quality materials and come with a**two-year warranty**. We also provide **lifetime technical support** to ensure a worry-free experience. For any inquiries or assistance, please contact Crecolife customer service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question