Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOTPEAK TF01

HOTPEAK TF01 Compressed Air Duster Instruction Manual

Model: TF01 | Brand: HOTPEAK

1. Introduction

This manual provides detailed instructions for the safe and effective operation of your HOTPEAK TF01 Compressed Air Duster. This rechargeable electric air duster is designed for various cleaning tasks, offering a powerful and eco-friendly alternative to traditional canned air. Please read this manual thoroughly before use and retain it for future reference.

2. Package Contents

Verify that all items listed below are included in your package:

- 1 x HOTPEAK TF01 Compressed Air Duster
- 3 x Nozzles (various shapes for different applications)
- 3 x Brushes (for detailed cleaning)
- 1 x USB-C Charging Cable
- 1 x User Manual



Figure 2.1: Contents of the HOTPEAK TF01 package, including the main unit, various nozzles, brushes, and charging cable.

3. Product Features

- **Powerful Motor:** Equipped with a 180,000 RPM motor, delivering 180G blowing force for effective dust removal.
- **Adjustable Speed Settings:** Three distinct speed modes (Low, Medium, High) to suit various cleaning requirements.
- **Rechargeable Battery:** Integrated lithium-ion batteries provide up to 90 minutes of runtime (on 1st gear) and support USB-C fast charging (up to 10W).
- **Versatile Nozzles & Brushes:** Includes multiple nozzles and brushes for cleaning tight spaces, delicate electronics, and larger surfaces.
- **Compact & Portable:** Lightweight and cordless design for easy handling and storage, suitable for home, office, and car use.
- **Eco-Friendly:** A reusable alternative to disposable canned air, reducing waste and long-term costs.



Figure 3.1: Illustration of the three adjustable wind speed modes (50,000 RPM, 100,000 RPM, 180,000 RPM) for varied cleaning tasks.

4. Setup

4.1 Attaching Nozzles

1. Select the appropriate nozzle for your cleaning task.
2. Align the nozzle with the blowing interface of the air duster.

3. Gently push the nozzle onto the interface until it is securely attached. The magnetic suction ensures a stable connection.




Figure 4.1: The magnetic suction feature simplifies nozzle attachment and removal.

4.2 Charging the Device

Before first use, fully charge the air duster. The device comes with 2 Lithium Ion batteries included.

1. Connect the USB-C charging cable to the charging port located at the back of the air duster.
2. Connect the other end of the USB-C cable to a compatible USB power source (e.g., computer USB port, power bank, wall adapter).
3. The battery indicator lights will illuminate to show charging status. A full charge typically takes approximately 3 hours.



Figure 4.2: The air duster supports USB-C fast charging from various sources.

5. Operating Instructions

5.1 Power On/Off

- To turn on: Press and hold the power button (located near the charging port) for 3 seconds. The device will start in 3rd gear (highest speed).

- To turn off: Press and hold the power button for 3 seconds.

5.2 Adjusting Wind Speed

Once powered on, short press the power button to cycle through the speed settings:

- **1st Gear (Low):** Suitable for delicate electronics and light dusting.
- **2nd Gear (Medium):** Ideal for general cleaning of keyboards, car interiors, etc.
- **3rd Gear (High):** Provides maximum power for stubborn debris and heavy-duty cleaning.

The indicator lights on the device will show the current speed setting and battery level.

5.3 Usage Tips

- For optimal cleaning, hold the duster a few inches away from the surface.
- Use short bursts of air for precise cleaning.
- Utilize the included brushes to dislodge stubborn dirt before blowing it away.



Figure 5.1: The air duster effectively cleans computer keyboards and other electronics.



Figure 5.2: The versatile nozzles are suitable for cleaning car interiors, including vents and tight corners.



Figure 5.3: The air duster can be used for diverse applications such as cooling, inflating, and drying pet hair.

▶ **Watch video online**
Compressed Air Duster

Video 5.1: Official product video demonstrating the HOTPEAK Compressed Air Duster in action.

6. Maintenance

- **Cleaning the Device:** Wipe the exterior of the air duster with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- **Nozzle Care:** Clean nozzles and brushes after each use to prevent debris buildup.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.

7. Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or not powered on correctly.	Ensure the device is charged. Press and hold the power button for 3 seconds to turn on.
Weak airflow.	Low battery or nozzle obstruction.	Recharge the device. Check and clear any obstructions in the nozzle or air intake. Ensure the correct speed setting is selected.
Device overheats.	Prolonged use at high speed.	Allow the device to cool down. Avoid continuous use at maximum power for extended periods. The device has an automatic cut-off if it overheats.

8. Specifications

Feature	Detail
Brand	HOTPEAK
Model Number	TF01
Motor Speed	Up to 180,000 RPM
Blowing Force	180G
Speed Settings	3 (Low, Medium, High)
Battery Type	2 Lithium Ion batteries (included)
Charging Port	USB-C (up to 10W fast charging)
Runtime (1st Gear)	Up to 90 minutes
Dimensions	1.96 x 1.96 x 5.7 inches
Item Weight	1.06 pounds
Material	Plastic

9. Safety Information

- Keep out of reach of children.
- Do not point the air duster directly at eyes, ears, or other sensitive body parts.
- Avoid using the device in wet environments or near flammable liquids/gases.
- Do not disassemble or attempt to repair the device yourself. Contact customer support for assistance.
- Use only the provided charging cable and a compatible power adapter.

10. Warranty and Customer Support

Your satisfaction is our priority. The package includes 1 air duster, 3 nozzles, 3 brushes, a USB-C cable, and a user manual. If you have any questions or issues, our dedicated support team is available 24/7 to assist you within 24 hours. For customer support, please refer to the contact information provided in your purchase documentation or visit the official HOTPEAK website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DK8SZ22Z

More documents and user manuals: **https://manuals.plus/**