Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy SW1021NERUBR

Sweetcrispy Lift Top Coffee Table User Manual

Model: SW1021NERUBR

Brand: Sweetcrispy

1. Introduction

Thank you for choosing the Sweetcrispy Lift Top Coffee Table. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Figure 1: Sweetcrispy Lift Top Coffee Table (Brown)

2. Safety Information

To ensure safe use and prevent injury or damage, please observe the following:

- Do not use the lifting mechanism with heavy objects to avoid pinch points.
- Always ensure the table is properly assembled and stable before use to prevent tipping.
- Keep small parts and assembly tools away from children.
- Do not stand or sit on the lift-top section when it is raised.
- Distribute weight evenly on the tabletop and within storage compartments.

3. Package Contents

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

Component	Quantity
Wooden Boards (various sizes)	Multiple
Left Lifter Mechanism	1
Right Lifter Mechanism	1
Wooden Legs	4
Solid Wood Foot Connectors	4
Silicone Foot Pads	4
Derrick Screws, Bolts, Eccentric Wheels	As required
Wrench, Installation Tool	1 each
Assembly Guide, Backup Screws	Included

4. Setup and Assembly

Assembly is required for this coffee table. It is recommended that two people assemble the table. All necessary tools and an assembly guide are included. For a visual guide, please refer to the official installation video below.

▶ **Watch video online**
Installation Video for Coffee Table

Video 1: Official Installation Guide for Sweetcrispy Coffee Table. This video provides step-by-step instructions for assembling your coffee table.

Assembly Steps Overview:

1. **Prepare Boards:** Insert Derrick Screws and Wooden Pins into the designated boards (3, 5, 6, 7, 8, 9) as shown in the assembly guide. Ensure pins are in inner holes.
2. **Install Lifter Mechanisms:** Attach the Left Lifter (D) to Board (7) and the Right Lifter (E) to Board (5) using the provided bolts (H).
3. **Connect Damping Rods:** Use the wrench (K) to unscrew the nut at the connection, lift the damping rod, and then re-tighten the nut. Repeat for both lifters.
4. **Assemble Main Box:** With the notched side of Board (6) facing down, install Boards (5) and (7) using Eccentric Wheels (C).
5. **Attach Top Board:** Use the wrench (J) to install Board (2) to the completed frame with bolts (I).
6. **Install Foot Connectors:** Attach the Solid Wood Foot Connectors (G) to the four corners of the bottom board using bolts (H). Ensure the four faces of the connector face outward.
7. **Attach Wooden Legs:** Tighten the four Wooden Legs (1) completely into the foot connectors.
8. **Apply Foot Pads:** Attach the Silicone Foot Pads (L) to the bottom of each wooden leg. Wait for 3 minutes for them to set completely.
9. **Install Divider Board:** Attach Board (8) to Boards (3) and (5) using Eccentric Wheels (C). Make sure the arrows on Board (9) and Board (8) point to each other.
10. **Secure Divider:** Tighten the Eccentric Wheels (C) to fix Board (8).

5. Operating Instructions

Adjustable Lift-Top Mechanism:

The coffee table features a smooth-lifting tabletop. To raise the top, gently pull it upwards from the front edge. The sturdy steel hinge mechanism will assist in lifting and holding the top at an ergonomic height, approximately 6.3 inches higher than the closed position. To lower, gently push the tabletop down until it rests flush with the base. The recessed finger-safe opening helps prevent pinching.



Figure 2: Lift-top in raised position, ideal for working or dining.

Hidden Storage Compartment:

Beneath the lift-top, a spacious main compartment is available for storing items such as blankets, books, or board games. This design ensures storage space is maintained even when the lift mechanism is in use.



Figure 3: Hidden storage compartment under the lift-top.

Side Storage Shelves:

Two additional open shelves are located on the side of the table, providing convenient access for remotes, snacks, magazines, or decorative items.



Figure 4: Open side storage shelves for easy access.

6. Maintenance

To maintain the appearance and longevity of your Sweetcrispy Lift Top Coffee Table, follow these care instructions:

- Wipe with a dry cloth to remove dust and spills.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- Protect the surface from excessive heat and moisture. Use coasters for drinks and placemats for hot items.
- Periodically check and tighten all screws and bolts to ensure stability.

7. Troubleshooting

If you encounter any issues with your coffee table, please refer to the following common solutions:

- **Wobbling:** Ensure all legs are securely tightened and the table is on a flat, even surface. Re-tighten any loose bolts.
- **Lift Mechanism Stiffness:** Check for any obstructions in the mechanism. Ensure the damping rods are properly connected and nuts are tightened as per assembly instructions.
- **Difficulty Closing Lift-Top:** Ensure no items are obstructing the closing path within the hidden compartment.

If the problem persists, please contact customer support for further assistance.

8. Specifications

Feature	Detail
Brand	Sweetcrispy
Model Name	Lift Top Coffee Tables for Living Room
Model Number	SW1021NERUBR
Product Dimensions	19.7"D x 39.37"W x 16.93"H
Maximum Weight Recommendation	200 Pounds
Color	Brown

Feature	Detail
Material	Wood
Furniture Finish	Wood
Maximum Lifting Height	6.3 Inches
Recommended Number of People for Assembly	2
Special Feature	Easy Assembly, Lift Top, Space Saving, Storage

9. Warranty and Support

No warranty is explicitly provided with this product. Please inspect the product upon arrival. If there are any shipping damages or missing parts, contact Sweetcrispy customer support within 14 days of receipt for assistance.

For any questions or concerns, our dedicated customer support team is available to assist you.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question