OKD BDC70WFP36

OKD Fireplace TV Stand User Manual

Model: BDC70WFP36

1. Product Overview

The OKD Fireplace TV Stand, model BDC70WFP36, is a 70-inch wide entertainment center designed to accommodate TVs up to 80 inches. It features a built-in 36-inch electric fireplace, sliding barn doors, and ample storage. This unit combines functional media storage with the aesthetic appeal of a farmhouse design and the warmth of an electric fireplace.

Key Features:

- **Integrated Electric Fireplace:** 36-inch unit with realistic 3D flame effects, glowing logs, and embers. Provides 5000 BTU heat output, capable of heating up to 450 sq. ft. Flame effect can operate independently of heat.
- **Remote Control:** Allows adjustment of power, flame brightness, temperature (64°F-82°F), and timer (1-8 hours).
- **Ample Storage:** Features a 6.3-inch wide open soundbar shelf, two storage cabinets with sliding barn doors, and adjustable/removable shelves within each cabinet.
- **Cable Management:** Large cutouts are provided to keep electronic wires organized.
- **Durable Construction:** Made from premium MDF and particleboard with a 1-inch thick tabletop and a 3.34-inch high wooden support base. The tabletop supports up to 150 lbs.

Dimensions:

- Overall Dimensions: 15.75"D x 70"W x 33"H
- Tabletop Weight Capacity: 150 lbs
- Shelf Weight Capacity: 30-50 lbs (depending on shelf)

Image 1.1: Detailed dimensions of the OKD Fireplace TV Stand, showing a width of 70 inches, height of 33 inches, and depth of 15.75 inches. The image also indicates the tabletop weight capacity of 150 lbs and shelf weight capacity of 30/50 lbs.

Image 1.2: Close-up view highlighting the sliding barn doors, the semi-open top shelf for a soundbar, and the adjustable/removable shelves within the storage cabinets.

2. Safety Information

Please read and understand all safety instructions before assembly and operation of this product. Failure to follow these instructions may result in electric shock, fire, property damage, or personal injury.

General Safety Precautions:

- Keep all packaging materials away from children.
- Do not allow children to climb on or play with the TV stand.
- Ensure the TV stand is placed on a flat, level, and stable surface.
- Do not exceed the maximum weight capacity for the tabletop (150 lbs) or shelves (30-50 lbs).
- Always use proper lifting techniques when moving the assembled unit due to its weight (approximately 136.7 lbs).

Electric Fireplace Safety:

- This electric fireplace is for indoor use only.
- Do not operate the fireplace if the cord is damaged or if the unit malfunctions.
- Keep combustible materials (furniture, bedding, papers, clothes, curtains) at least 3 feet (0.9 meters) from the front of the heater.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- Ensure the power outlet meets the electrical requirements of the fireplace.
- The fireplace features overheating protection. If the heater overheats, it will automatically shut off. Unplug the unit and allow it to cool before restarting.

3. Assembly Instructions

The OKD Fireplace TV Stand is designed for home assembly. It is recommended that two adults assemble this unit due to its size and weight. The product typically ships in two separate boxes, which may arrive on different days.

Before You Begin:

- **Unpack Carefully:** Remove all components from the packaging and lay them out on a soft, clean surface (e.g., a blanket or carpet) to prevent scratches.
- **Verify Parts:** Check the parts list against the included hardware to ensure all components are present. A bag of spare parts is typically included.
- **Read Instructions:** Review the step-by-step illustrated instructions thoroughly before starting assembly.
- **Tools Required:** A Phillips head screwdriver is generally sufficient. A cordless screwdriver can expedite the process but use caution to avoid overtightening.

Assembly Tips:

- Follow the numbered steps in the instruction manual precisely.
- Ensure all screws and wooden dowels are properly aligned before tightening.
- Do not overtighten cam lock screws, as the metal pieces can be fragile. Hand-tighten or use a low-torque setting on a cordless screwdriver.
- Apply wood glue (if provided, or use your own) to dowel rods for added stability.
- The electric fireplace unit is typically installed into the main console structure during assembly. Follow the specific instructions for its integration.

Image 3.1: The fully assembled OKD Fireplace TV Stand, showcasing its farmhouse design with a television placed on top and the electric fireplace operating.

4. Operating Instructions (Electric Fireplace)

The 36-inch electric fireplace provides both heat and a visual flame effect. It can be controlled via the mechanical button panel on the unit or the included remote control.

Controls:

- **Power Button:** Turns the fireplace on or off.
- **Heat Setting:** Adjusts the heat output. The unit provides 5000 BTU, heating up to 450 sq. ft. Temperature can be set between 64°F and 82°F.
- **Flame Brightness:** Adjusts the intensity of the 3D flame effect. Multiple levels of brightness are available.
- **Timer:** Sets an automatic shut-off for the fireplace, typically ranging from 1 to 8 hours.

Using the Remote Control:

Point the remote control directly at the fireplace unit. The remote allows for convenient adjustment of all functions

from a distance.

Flame Effect Only Mode:

The flame effect can be operated independently without activating the heating function, allowing for year-round ambiance.

Image 4.1: Detailed view of the 36-inch electric fireplace, showing the mechanical button panel, remote control, and icons representing features like 3D flame effect, overheating protection, CSA/UL listing, adjustable temperature, and timer.

5. Maintenance

Regular maintenance will help preserve the appearance and functionality of your OKD Fireplace TV Stand.

Cleaning the TV Stand:

- Wipe surfaces with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.

- Promptly clean up spills to prevent staining.

Electric Fireplace Care:

- Ensure the fireplace is turned off and unplugged before cleaning.
- Clean the glass front with a soft, lint-free cloth. Do not use abrasive cleaners.
- Periodically check the air intake and exhaust vents for dust or obstructions and clean as necessary to ensure proper airflow.

6. Troubleshooting

If you encounter issues with your OKD Fireplace TV Stand or electric fireplace, refer to the following common troubleshooting steps.

Assembly Issues:

- **Parts Don't Align:** Double-check the instruction manual to ensure you are using the correct parts for each step and that they are oriented correctly. Sometimes, a slight rotation of a panel can resolve alignment issues.
- **Loose Connections:** Ensure all screws, cam locks, and dowels are fully seated and tightened (without overtightening).
- **Missing Hardware:** Verify against the parts list. Contact customer support if essential parts are missing.

Electric Fireplace Issues:

- **No Power/Fireplace Not Turning On:**
  - Ensure the power cord is securely plugged into a functional electrical outlet.
  - Check the circuit breaker for the outlet.
  - Verify the power switch on the fireplace unit is in the 'ON' position.
- **No Heat Output:**
  - Confirm the heat function is activated via the control panel or remote.
  - Check if the thermostat setting is higher than the ambient room temperature.
  - If the unit recently shut off, it might be due to overheating protection. Unplug, wait 10-15 minutes, and plug back in.
- **No Flame Effect:**
  - Ensure the flame effect is turned on via the control panel or remote.
  - Check if the flame brightness setting is too low.
- **Remote Control Not Working:**
  - Replace the batteries in the remote control.
  - Ensure there are no obstructions between the remote and the fireplace sensor.

7. Specifications

Feature	Specification
Brand	OKD
Model Name	BDC70WFP36
Product Dimensions	15.75"D x 70"W x 33"H
Material	Engineered Wood
Color	Antique White
Finish Type	Powder Coated
Installation Type	Floor Mount
Power Source	Corded Electric
Heat Output	5000 British Thermal Units
Heating Coverage	450 sq ft
Ventilation Type	Vent Free
Item Weight	136.7 Pounds
Special Features	36 Inch Fireplace, Highboy TV Stand, Sliding Barn Door
Global Trade Identification Number (GTIN)	00850072932705

8. Warranty Information

This OKD Fireplace TV Stand comes with a**Limited Warranty**. For specific details regarding the terms, conditions, and duration of your warranty, please refer to the warranty card included with your product packaging or contact OKD customer support directly. Keep your proof of purchase for warranty claims.

9. Customer Support

For further assistance, missing parts, or warranty inquiries, please contact OKD customer support. You can typically find contact information on the product packaging, the brand's official website, or through your retailer.
Visit the OKD Store on Amazon for more information and product details.