Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hoggar by Okoru Pioneer Y130

Hoggar Pioneer Y130 Metal Garden Shed Instruction Manual

Brand: Hoggar by Okoru | **Model:** Pioneer Y130 (G01ME0086)

1. Introduction

This manual provides essential instructions for the assembly, operation, and maintenance of your Hoggar Pioneer Y130 metal garden shed. Please read all instructions carefully before beginning assembly or use to ensure proper installation and safe operation.

Safety Warning

This product requires a solid and level base for assembly and secure fastening. Delivery is made to the carrier's vehicle, so it is recommended to have assistance for unloading and moving the product. Do not attempt to assemble or move the product without adequate assistance to prevent injuries.

2. Setup and Assembly

The Hoggar Pioneer Y130 shed features an innovative design for simplified assembly and enhanced structural integrity. Follow these guidelines for proper setup:

- **Foundation:** Ensure the shed is installed on a solid, level base. A concrete slab or treated timber foundation is recommended. The shed does not include a floor.
- **IronCore Construction:** The revolutionary IronCore V-column construction reduces assembly time and increases structural resistance.
- **Self-Supporting Rails:** The self-supporting rails of the lower frame facilitate a more convenient assembly process, allowing for installation in multiple sessions if needed.
- **Tools and Assistance:** Gather all necessary tools as indicated in the assembly diagrams. Due to the size and weight of components, assembly with at least two people is strongly advised.



Figure 1: The Hoggar Pioneer Y130 metal garden shed, showcasing its overall design.



Figure 2: Illustration of the IronCore construction, premium doors, and double lacquered finish.



Figure 3: Interior view of the shed, demonstrating ample storage space with doors fully open.

3. Operating Instructions

Your Pioneer Y130 shed is designed for secure and convenient storage. Observe the following operational guidelines:

- **Double Reinforced Doors:** The shed features wide, double reinforced doors with hinges for smooth operation.
- **Security Lock:** An anti-theft lock with included keys is provided for securing the shed's contents. Always ensure the doors are properly closed and locked when not in use.
- **Ventilation:** The shed includes ventilation grilles without plastic components to promote air circulation and prevent condensation buildup inside.



Figure 4: Detail of the door handle and integrated lock with keys for secure closure.



Figure 5: Detail of the robust door hinge and frame construction.

4. Maintenance

Regular maintenance will ensure the longevity and appearance of your Hoggar Pioneer Y130 shed:

- **Cleaning:** Clean the shed exterior periodically with mild soap and water. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Double Lacquered Finish:** The interior and exterior walls feature a double lacquered finish for maximum durability and aesthetic appeal.
- **Inspection:** Periodically inspect all fasteners and connections to ensure they remain tight. Check for any signs of wear or damage and address them promptly.
- **Snow Load:** The robust roof design allows for superior load capacity, providing better protection against snowfall. However, heavy snow accumulation should be cleared to prevent excessive stress.

5. Troubleshooting

Should you encounter any issues with your shed, consider the following general troubleshooting steps:

- **Assembly Issues:** If parts do not align, re-check the assembly instructions carefully. Ensure all components are correctly oriented and fasteners are not overtightened prematurely.
- **Door Operation:** If doors stick or do not close properly, verify that the shed is on a level surface and that the door frame is square. Check hinges for obstructions or damage.
- **Water Leakage:** While the shed is water-repellent, ensure all panels are correctly overlapped and sealed as per assembly instructions. Verify the roof is properly installed and free of gaps.
- **Missing Parts:** If any parts are missing or damaged upon delivery, contact customer support immediately.

6. Specifications

Feature	Detail
Total Surface Area	12.46 m^2
Exterior Dimensions (W x D x H)	356 x 350 x 225 cm (3.56 x 3.5 x 2.25 meters)
Interior Dimensions (W x D x H)	345 x 345 x 225 cm
Door Size (W x H)	227 x 175 cm
Net Weight	133 kg
Packaging Weight	142.1 kg (three packages: 182x53x6 cm / 44.8 kg; 190x53x14 cm / 45.6 kg; 213x33x19 cm / 51.7 kg)
Frame Material	Zinc-plated steel frame (0.40 – 0.60 mm thickness)
Overall Material	Metal (Alloy Steel)
Water Resistance Level	Water Repellent
Color	Anthracite
Style	Modern
Manufacturer	Okoru
Model Number	G01ME0086



Figure 6: Detailed diagram illustrating the exterior and interior dimensions of the shed.

7. Warranty Information

This product is covered by a **10-year warranty against corrosion**. Please retain your proof of purchase for any warranty claims. The warranty covers manufacturing defects and material corrosion under normal use conditions.

8. Customer Support

For further assistance, technical support, or to report missing/damaged parts, please contact your retailer or the manufacturer, Hoggar by Okoru. Refer to your purchase documentation for specific contact details.
No official product videos were provided for this model.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DLBSXR9Z

More documents and user manuals: **https://manuals.plus/**