Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VEVOR GN-1200R2

VEVOR 18 Cu.Ft. Commercial Refrigerated Display Case User Manual

Model: GN-1200R2

Safety Instructions | Setup | Operation | Maintenance & Support | Troubleshooting | Specifications | Warranty

Introduction

Thank you for choosing the VEVOR 18 Cu.Ft. Commercial Refrigerated Display Case. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new appliance. Please read these instructions thoroughly before use and retain them for future reference.



Image: The VEVOR 18 Cu.Ft. Commercial Refrigerated Display Case, showcasing its capacity and design with various baked goods.

Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Ensure the power supply matches the voltage specified on the appliance's rating label.
- Do not operate the appliance with a damaged cord or plug.
- Keep ventilation openings clear of obstructions.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Only qualified personnel should perform repairs.
- Unplug the appliance before cleaning or performing maintenance.

Setup

1. Unpacking

Carefully remove all packaging materials. Inspect the display case for any shipping damage. Report any damage to your supplier immediately. The package includes 1 x Refrigerated Display Case and 1 x Instruction Manual.

2. Placement

- Place the display case on a firm, level surface capable of supporting its weight (approximately 341.72 lbs / 155 kg when empty).
- Ensure adequate ventilation around the unit. Maintain a minimum clearance of 4 inches (10 cm) from walls or other objects to allow for proper airflow.
- Avoid direct sunlight or proximity to heat sources.

3. Caster Installation

The display case is equipped with four swivel wheels for convenient mobility. Ensure they are securely locked once the unit is in its final position to prevent accidental movement.



Image: A person demonstrating the ease of moving the display case, highlighting the integrated casters.

4. Power Connection

Connect the appliance to a dedicated 110 Volt power outlet. Do not use extension cords or adapter plugs.

5. Initial Cleaning

Before first use, clean the interior and exterior surfaces with a mild detergent and warm water. Rinse thoroughly and dry completely.

Operation

1. Control Panel and Temperature Setting

The display case features a control panel for temperature adjustment. The temperature range is 2 - 8°C (35.6 - 46.4°F). Use the controls to set your desired temperature. The unit will automatically maintain this temperature.



Image: Illustration of the smart constant temperature system, demonstrating how the unit maintains a stable temperature within the set range for energy efficiency and food preservation.

2. Loading the Unit

The 18 Cu.Ft. interior includes 2 adjustable shelves. Adjust the shelf height according to the size of the items you wish to display. Ensure items do not block the internal air circulation vents.



Image: Detail of the height-adjustable shelves and their mounting slots, illustrating the flexibility for organizing various products.

3. Automatic Defogging Function

The display case is equipped with an automatic defogging function to maintain clear visibility of displayed products. This system prevents condensation on the glass surfaces.

Maintenance

Regular maintenance ensures optimal performance and longevity of your display case.

1. Cleaning

- **Interior:** Clean regularly with a mild, non-abrasive detergent and warm water. Rinse with clean water and dry thoroughly to prevent odors and bacterial growth.

- **Exterior:** Wipe down stainless steel and glass surfaces with a soft cloth and appropriate cleaner. Avoid abrasive cleaners that can scratch surfaces.
- **Glass:** The high-transparency tempered glass should be cleaned with a glass cleaner to maintain clarity. The automatic defogging system helps reduce the need for frequent cleaning of condensation.



Image: The display case with its clear, bright glass, demonstrating the effectiveness of the defogging function in maintaining product visibility.

2. Defrosting

This unit features an automatic defrost system, minimizing manual defrosting. If excessive ice buildup occurs, unplug the unit and allow it to defrost naturally, then clean and dry the interior before restarting.

3. Gasket Inspection

Regularly inspect the door gaskets for cracks or damage. Damaged gaskets can compromise cooling efficiency. Replace if necessary.

Troubleshooting

Before contacting customer support, review the following common issues and solutions:

Problem	Possible Cause	Solution
Unit not cooling	Power supply issue; thermostat set too high; door not sealed properly; condenser coil dirty.	Check power connection; adjust thermostat; ensure door is closed and gasket is intact; clean condenser coil.
Excessive noise	Unit not level; loose components; fan obstruction.	Level the unit; check for loose parts and tighten; clear any fan obstructions.
Condensation on glass	High humidity; frequent door opening; defogging function issue.	Ensure proper room ventilation; minimize door openings; contact support if defogging is not working.

If problems persist after attempting these solutions, please contact VEVOR customer support or a qualified service technician.

Specifications

Key technical specifications for the VEVOR 18 Cu.Ft. Commercial Refrigerated Display Case (Model GN-1200R2):

Feature	Detail
Model Number	GN-1200R2
Capacity	18 Cu.Ft. / 505 L
Product Dimensions (D x W x H)	47.24" x 32.28" x 47.24" (1200 x 820 x 1200 mm)
Temperature Range	2 - 8°C / 35.6 - 46.4°F
Power	670 W
Voltage	110 Volts
Cooling Type	Enhanced Direct Cooling
Defrost System	Automatic
Number of Shelves	2 (Adjustable)
Main Material	Stainless Steel + Tempered Glass
Net Weight	341.7 lbs / 155 kg



Item Model Number: GN-1200R2 Cooling Type: Enhanced Direct Cooling
Power: 670 W Energy Consumption: 6.1 kWh / 24h
Capacity: 18 Cu.Ft. / 505 L Temperature Range: 35.6℉-46.4℉ / 2℃-8℃
Main Material: Stainless Steel + Tempered Glass Net Weight: 341.7 lbs / 155 kg
Product Size: 1200 x 820 x 1200 mm / 47.2 x 32.3 x 47.2 in

Image: A detailed diagram illustrating the product dimensions and a summary of key specifications for the display case.

Warranty & Support

Warranty Information

For specific warranty details, please refer to the warranty card included with your product or visit the official VEVOR website. Keep your purchase receipt as proof of purchase for any warranty claims.

Customer Support

If you have any questions, require technical assistance, or need to report an issue, please contact VEVOR customer service. Contact information can typically be found on the VEVOR website or in your product documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DLK5VW7H

More documents and user manuals: **https://manuals.plus/**