**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Langsdom BE15

# Langsdom AirSwim Bone Conduction Headphones User Manual

Model: BE15

## 1. Introduction

The Langsdom AirSwim Bone Conduction Headphones are designed for high-performance audio in various environments, including underwater. Featuring IPX8 waterproofing, a skin-friendly silicone design for comfort, and dual Bluetooth and MP3 modes with 32GB of built-in memory, these headphones offer flexibility and a premium listening experience. This manual provides essential information for the proper use, maintenance, and troubleshooting of your AirSwim headphones.




Image: Langsdom AirSwim Bone Conduction Headphones in Grey Green color, showcasing their sleek design.

## 2. Key Features

- **IPX8 Waterproof:** Designed for full submersion, allowing use during swimming and other water activities up to 2 meters depth.
- **Skin-Friendly Silicone:** Ensures comfortable and secure fit for extended wear.
- **Dual Mode (Bluetooth & MP3):** Seamlessly switch between wireless streaming and offline playback with 32GB built-in memory. Supports MP3, WMA, WAV, APE, FLAC formats.
- **Bone Conduction Technology:** Delivers clear audio while keeping ears open to ambient sounds for safety.
- **8-Hour Battery Life:** Provides extended playtime for various activities.
- **Magnetic Charging:** Convenient and secure charging via a magnetic cable that also functions as a data cable.

Your browser does not support the video tag.

Video: A brief overview of the Langsdom AirSwim Bone Conduction Headphones, showcasing their design, IPX8 waterproof rating, 32GB built-in memory, and magnetic charging feature.

## 3. What's in the Box

- Langsdom AirSwim Bone Conduction Headphones
- Magnetic Charging Cable (also functions as a data cable)
- User Manual (this document)

## 4. Setup

### 4.1 Charging the Headphones

Before first use, fully charge your AirSwim headphones. Use the provided magnetic charging cable. Connect the magnetic end to the charging port on the headphones and the USB end to a compatible power source (e.g., computer USB port, USB wall adapter).

- **Charging Indicator:** A red light indicates charging. A blue light indicates fully charged.
- **Charging Time:** Approximately 2 hours for a full charge.

Your browser does not support the video tag.

Video: A demonstration of charging the Langsdom AirSwim headphones using the magnetic charging cable. The video also shows the headphones being worn and used in a pool, highlighting their waterproof capabilities and comfortable fit.

### 4.2 Wearing the Headphones

Place the headphones around the back of your head with the transducers resting on your cheekbones, just in front of your ears. The flexible silicone band ensures a comfortable and secure fit for various head sizes and activities.




Image: A person wearing the Langsdom AirSwim headphones, illustrating the open-ear design and how the skin-friendly silicone provides a comfortable and secure fit for extended wear.

## 5. Operating Instructions

### 5.1 Power On/Off

- **Power On:** Press and hold the Power/Mode button (middle button on the control panel) for 3 seconds until the indicator light turns on.
- **Power Off:** Press and hold the Power/Mode button for 5 seconds until the indicator light turns off.

### 5.2 Bluetooth Mode

For wireless audio streaming from your smartphone, tablet, or other Bluetooth-enabled devices.

1. Ensure headphones are powered on and in Bluetooth pairing mode (indicator light will flash blue/red).
2. On your device, go to Bluetooth settings and select "AirSwim" from the list of available devices.
3. Once connected, the indicator light will turn solid blue.

4. Use the Volume Up (+) and Volume Down (-) buttons to adjust volume.
5. Press the Power/Mode button once to Play/Pause music or answer/end calls.

### 5.3 MP3 Mode (Built-in 32GB Memory)

For offline music playback, especially useful for underwater activities where Bluetooth signals cannot transmit.

1. **Transferring Music:** Connect the magnetic charging cable to the headphones and a computer. The headphones will appear as a removable disk. Drag and drop your MP3, WMA, WAV, APE, or FLAC audio files into the headphone's storage.
2. **Switching to MP3 Mode:** With the headphones powered on, press the Power/Mode button twice quickly to switch to MP3 mode.
3. **Playback Control:** Use the Volume Up (+) and Volume Down (-) buttons to adjust volume. Press and hold Volume Up (+) for next track, and Volume Down (-) for previous track.




Image: The Langsdom AirSwim headphones highlighting their built-in 32GB memory, which allows for storing thousands of songs for MP3 playback without needing a connected phone.

## 6. Maintenance

- **Cleaning:** After use, especially after swimming, rinse the headphones with fresh water to remove chlorine or salt. Wipe dry with a soft cloth.
- **Storage:** Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Charging Port:** Ensure the magnetic charging contacts are clean and dry before charging to prevent corrosion.
- **Avoid Punctures:** Do not attempt to disassemble or puncture the headphones, as this will compromise their waterproof integrity.

## 7. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Headphones won't turn on. | Low battery. | Charge the headphones fully. |
| Cannot pair via Bluetooth. | Headphones not in pairing mode; device Bluetooth off; too far from device. | Ensure headphones are in pairing mode (flashing blue/red). Turn on device Bluetooth. Move closer to the device (within 10 meters). |
| No sound in MP3 mode. | No music files loaded; incorrect file format. | Connect to computer and transfer supported music files (MP3, WMA, WAV, APE, FLAC). |
| Sound quality is poor underwater. | Bluetooth mode used underwater; water in ears. | Switch to MP3 mode for underwater use. Ensure ears are clear of water or use earplugs for optimal sound. |
| Magnetic charging cable not connecting. | Contacts are dirty or wet. | Clean and dry the magnetic contacts on both the cable and the headphones. |

## 8. Specifications

| Feature | Detail |
|---|---|
| Model Name | AirSwim (BE15) |
| Water Resistance Level | IPX8 (up to 2 meters) |
| Connectivity Technology | Bluetooth V5.4 |
| Internal Memory | 32GB |
| Supported Audio Formats | MP3, WMA, WAV, APE, FLAC |
| Battery Life | Up to 8 hours |
| Charging Time | 2 hours |
| Material | Memory Titanium Alloy, Silicone, Plastic |
| Weight | 15.5 ounces |
| Control Type | Button Control |

## 9. Warranty and Support

Langsdom products come with a standard manufacturer's warranty. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Langsdom website. For technical support, troubleshooting assistance, or warranty claims, please contact Langsdom customer service through their official channels.

**Official Langsdom Store:** Visit the Langsdom Store on Amazon

© 2025 Langsdom. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question



**Open the live page**

**https://manuals.plus/asin/B0DMP2JD7L**

More documents and user manuals: **https://manuals.plus/**