Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK RLT100D

LEXiBOOK Disney Stitch My Sleep Companion User Manual

Model: RLT100D

Introduction

This manual provides detailed instructions for the LEXiBOOK Disney Stitch My Sleep Companion, Model RLT100D. This device combines an alarm clock, nightlight, dawn simulator, and storyteller to assist with sleep routines. Please read this manual thoroughly before use to ensure proper operation and to maximize the product's features.

Safety Instructions

- Keep the device away from water and moisture.
- Do not expose to direct sunlight or extreme temperatures.
- Use only the provided power cord.
- Do not attempt to disassemble or repair the device yourself. Contact qualified service personnel.
- Ensure the device is placed on a stable, flat surface.

Setup

1. Unboxing and Inspection

Carefully remove the Stitch Sleep Companion from its packaging. Inspect the device for any signs of damage. Ensure all components, including the power cord, are present.



Image: The LEXiBOOK Disney Stitch My Sleep Companion shown in its retail packaging.

2. Power Connection

Connect the provided power cord to the DC 5V 1.5A input port located at the back of the device. Plug the other end into a standard electrical outlet.



Image: Rear view of the Stitch Sleep Companion, highlighting the power input and various control buttons.

3. Initial Time Setting

Upon first power-up, the digital display will illuminate. Refer to the 'Operating Instructions' section for detailed steps on setting the current time and date.

Operating Instructions

1. Setting the Time and Date

1. Press the **'SET'** button (refer to the back panel image for button location).
2. Use the **'+'** and **'-'** buttons to adjust the hour, then press **'SET'** to confirm.
3. Repeat for minutes, year, month, and day.
4. The device features both analog and digital time displays.

2. Alarm Clock Function

1. Press the **'ALARM'** button.
2. Use **'+'** and **'-'** to set the desired alarm time, then press **'ALARM'** to confirm.
3. To select an alarm tone, press the **'MUSIC'** button repeatedly until your preferred melody is heard. There are 14 melodies available.
4. Adjust alarm volume using the dedicated volume control buttons on the back.

5. To activate the snooze function, press any button (except 'OFF') when the alarm sounds. Snooze duration is typically 9 minutes.

3. Nightlight and Mood Light

1. Press the **'LIGHT'** button to activate the nightlight.
2. Press again to cycle through different light modes or colors (if available).
3. The nightlight can be set to play for a duration of 15 to 120 minutes. Refer to the settings menu for adjustment.

4. Dawn Simulator (Sunrise Simulation)

1. To enable the progressive illumination feature, access the settings menu (usually by holding the **'SET'** button).
2. Select the 'Dawn Simulator' option and set the desired pre-alarm duration for the light to gradually brighten.
3. Stitch's eyes will gently open as the light brightens, mimicking a sunrise.



Image: A child waking up in bed, with the Stitch Sleep Companion nearby, illustrating the dawn simulation feature.

5. Storyteller and Melodies

1. Press the **'STORY'** button to activate the storytelling feature.
2. Use the **'+'** and **'-'** buttons to navigate through available stories or melodies.
3. The device offers 14 melodies for relaxation or gentle wake-ups, and 4 additional tunes for entertainment.



Image: An adult and child sharing a moment with the Stitch Sleep Companion, demonstrating its use as a storyteller or nightlight.

6. Nap Function

1. Press the **'NAP'** button.
2. Use **'+'** and **'-'** to set the desired nap duration, ranging from 15 to 120 minutes.
3. Press **'NAP'** again to confirm and start the nap timer.

7. Additional Features Overview



Image: The Stitch Sleep Companion with visual icons indicating its various functions: alarm clock, sleep coach, learn to read time, nightlight, mood light, and melodies.

For a visual guide and further demonstration of the product's features, you may visit the official Lexibook video page: Lexibook RLT100D Video.

Maintenance

1. Cleaning

To clean the device, gently wipe the surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these may damage the finish or internal components.

2. Storage

When not in use for extended periods, store the Stitch Sleep Companion in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to disconnect the power cord.

Troubleshooting

- **Device not powering on:** Ensure the power cord is securely connected to both the device and a working electrical outlet.
- **Alarm not sounding:** Verify that the alarm time is set correctly and the alarm function is activated. Check the alarm volume settings.
- **Display issues:** If the digital display is dim or not working, try unplugging the device for a few minutes and then reconnecting it.
- **Buttons unresponsive:** Disconnect the power, wait 30 seconds, and reconnect. If the issue persists, contact customer support.

Specifications

Feature	Detail
Brand	LEXiBOOK
Model Number	RLT100D
Color	Blue
Display Type	Digital
Special Feature	Projection Clock, Nightlight, Dawn Simulator, Storyteller
Product Dimensions	4.33"W x 6.3"H
Power Source	Corded Electric
Room Type	Kid's Room
Frame Material	Plastic
Item Weight	9.9 ounces (0.62 Pounds)
Alarm Clock	Yes
Number of Items	1
Operation Mode	Electrical
UPC	841874028116

Warranty and Support

This product is covered by a manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or visit the official LEXiBOOK website.
For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact LEXiBOOK customer service. You can find contact information on the official LEXiBOOK website or through the retailer where the product was purchased.
Visit the LEXiBOOK Store for more information:LEXiBOOK Amazon Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DMSN9RB6

More documents and user manuals: **https://manuals.plus/**