Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Maxx Action 470402

Maxx Action Deluxe Large Construction Long Hauler

Model: 470402

Brand: Maxx Action

Introduction

The Maxx Action Deluxe Large Construction Long Hauler is designed for engaging play, featuring a large truck and two construction vehicles. This set includes realistic details, lights, and sounds to enhance the play experience. This manual provides essential information for the safe and proper use of your new toy.

Key Features:

- Massive Construction Fun: This deluxe long hauler is the ultimate playset for little construction enthusiasts.
- Spacious Storage: The truck's large bed can hold multiple vehicles and construction equipment.
- Realistic Details: Immerse yourself in the world of construction with realistic details and authentic sounds.
- Two Included Vehicles: The set comes with two vehicles, a front-end loader and a dump truck, for endless play possibilities.
- Durable and Safe: Built to last, this playset is made from high-quality materials and is safe for kids.

What's in the Box

Your Maxx Action Deluxe Large Construction Long Hauler package includes the following items:

- Long Hauler Truck
- 2 Construction Vehicles (Front-end Loader and Dump Truck)

Safety Information

WARNING: CHOKING HAZARD - Small Parts. Not for children under 3 years. Adult supervision is recommended during play. Ensure all parts are securely attached before use. Do not modify the toy in any way.

Setup

Battery Installation

The Long Hauler requires 3 AA alkaline batteries for its lights and sound features. Batteries are included with the product.

1. Locate the battery compartment on the underside of the truck cab.
2. Using a Phillips head screwdriver (not included), unscrew the battery compartment cover.
3. Insert 3 new AA alkaline batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.

Note: Always use fresh batteries of the same type. Do not mix old and new batteries, or different types of batteries. Remove batteries if the toy will not be used for an extended period.

Assembly

No assembly is required for the Maxx Action Deluxe Large Construction Long Hauler. The product comes pre-assembled and ready for play after battery installation.

Operating Instructions

Lights and Sound Features

The Long Hauler truck is equipped with lights and sounds. Press the buttons located on the top of the truck cab to activate various realistic sounds and flashing lights.

Friction Motor

The Long Hauler truck features a friction motor. To operate, simply push the truck forward or backward on a flat surface, then release. The truck will continue to move on its own for a short distance.

Using the Construction Vehicles

The two included construction vehicles (front-end loader and dump truck) can be loaded onto and unloaded from the long hauler's trailer. The trailer features a ramp that can be lowered to facilitate loading and unloading. These vehicles are designed for manual play, allowing children to simulate construction tasks.

Maintenance

To ensure the longevity of your Maxx Action Deluxe Large Construction Long Hauler:

- **Cleaning:** Wipe the toy with a damp cloth to remove dust and dirt. Do not immerse the toy in water. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the toy in a cool, dry place away from direct sunlight when not in use.
- **Battery Care:** Remove batteries if the toy is to be stored for an extended period to prevent leakage.

Troubleshooting

Lights and Sounds Not Working

- **Check Batteries:** Ensure batteries are installed correctly with the proper polarity.
- **Replace Batteries:** If the batteries are old or depleted, replace them with fresh AA alkaline batteries.
- **Battery Compartment:** Make sure the battery compartment cover is securely closed.

If issues persist after checking these steps, please contact customer support.

Specifications

Brand Name	Maxx Action
Model Number	470402
Age Range Description	Toddler (Manufacturer Minimum Age: 36 months)
Item Dimensions (LxWxH)	19.3 x 4.3 x 5.8 inches
Material Type	Plastic
Power Source	Battery Powered
Battery Type	3 AA Alkaline batteries (included)
Additional Features	Lights and Sound
Operation Mode	Manual
Included Components	Long Hauler, 2 Construction Vehicles
Assembly Required	No

Media Gallery

Product Images



A child happily playing with the Maxx Action long hauler and its construction vehicles on a rug.



A child pushing the Maxx Action long hauler across a rug, demonstrating its movement.



A child interacting with the construction vehicles on the Maxx Action long hauler's trailer.



The Maxx Action long hauler with the two construction vehicles displayed separately on the floor, ready for play.



The Maxx Action Deluxe Construction Long Hauler in its retail packaging, showcasing its features like lights, sounds, and friction

motor.



An angled view of the Maxx Action Deluxe Construction Long Hauler in its retail packaging, showing the included vehicles.

Official Product Videos

▶ **Watch video online**
Maxx Action Deluxe Construction Long Hauler

Official product video demonstrating the features and play patterns of the Maxx Action Deluxe Construction Long Hauler, provided by Sunny Days Entertainment, LLC.

Warranty and Support

For warranty information or customer support regarding your Maxx Action Deluxe Large Construction Long Hauler, please refer to the contact information provided on the product packaging or visit the official Maxx Action website. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DN7SWR99

More documents and user manuals: **https://manuals.plus/**