Manuals+
Q & A | Deep Search | Upload

AutoFull AFM6

AutoFull M6 Gaming Chair User Manual

Model: AFM6 | Brand: AutoFull

1. Introduction

Welcome to the AutoFull M6 Gaming Chair user manual. This document provides essential information for the proper assembly, operation, and maintenance of your new gaming chair. Designed for ergonomic support and comfort during extended use, the AutoFull M6 features advanced functionalities such as a ventilated and heated seat, dynamic lumbar support, and highly adjustable components. Please read these instructions carefully to ensure safe and optimal performance of your chair.

Figure 1: AutoFull M6 Gaming Chair

2. Safety Information

Before using the AutoFull M6 Gaming Chair, please observe the following safety guidelines:

- Ensure the chair is used within its maximum weight capacity of 397 lbs (180 kg). Exceeding this limit may cause damage to the chair or personal injury.
- Follow all assembly instructions carefully. Improper assembly can lead to instability and potential hazards.
- When adjusting any movable parts, such as the recline, armrests, or height, do so slowly and deliberately to prevent pinching or sudden movements.
- Keep hands and fingers clear of moving parts during adjustments.
- Do not stand on the chair or use it as a step stool.
- Avoid placing heavy objects on the chair's backrest or armrests when not in use, as this may cause damage.
- Regularly inspect the chair for any loose screws, damaged parts, or signs of wear. Discontinue use if any issues are found and contact customer service.

3. Package Contents

Please verify that all components are present before beginning assembly. Refer to the assembly video for visual guidance on identifying parts.

- Backrest
- Seat Cushion (with integrated controls)
- Armrests (Left & Right)
- Chair Base (5-star)
- Casters (5x)
- Gas Lift Cylinder
- Gas Lift Cover
- Footrest Assembly
- Lumbar Support Mechanism
- Headrest Pillow
- Assembly Hardware (screws, washers, Allen wrench)
- Instruction Manual

4. Assembly Instructions

Follow these steps to assemble your AutoFull M6 Gaming Chair. It is recommended to have a clear, spacious area for assembly.

4.1. Base Assembly

1. Insert each of the 5 chair spokes into the central axis of the chair base.
2. Tighten each spoke securely with the provided 5 spoke screws using the Allen wrench.
3. Insert the casters into the assembly holes at the end of each chair leg, applying firm pressure until they click into place.
4. Insert the gas lift cylinder into the center hole of the assembled base. Place the gas lift cover over the cylinder.

4.2. Seat and Backrest Assembly

5. Lay the seat cushion face down on a soft, clean surface. Remove all pre-installed screws from the underside of the seat.
6. Retrieve the left armrest (marked 'L'). Align the armrest with the holes on the proper side of the seat cushion and install the 4 screws securely with the wrench. Repeat for the right armrest (marked 'R').
7. Align the chassis with the holes on the underside of the seat cushion. Ensure the 'FRONT' label on the chassis points towards the front of the seat. Install the 4 screws into the chassis securely with a wrench.
8. Align the 2 footrest brackets accordingly on each side of the seat cushion. Horizontal hole points forward, vertical hole points backward. Install the 2 screws for each holder securely with a wrench.
9. Remove the 2 pre-installed screws from the footrest. Align the footrest with the footrest sliders and insert it. Reinstall the 2 screws into the footrest securely with a wrench.
10. Insert the backrest into the angle adjuster, aligning the upper and lower holes. Secure the backrest with 2 screws and tighten with a wrench. Repeat for the other side.
11. Snap on the angle adjuster case, install the screws, and secure with a wrench.

4.3. Final Assembly

12. Carefully place the assembled seat onto the gas lift cylinder.
13. Attach the headrest pillow to the top of the backrest.

Your browser does not support the video tag.

Video 1: AutoFull M6 Installation Guide

This video provides a visual step-by-step guide for assembling your AutoFull M6 Gaming Chair, demonstrating each stage from unboxing to final adjustments.

5. Operating Instructions

Your AutoFull M6 Gaming Chair is equipped with multiple adjustable features to customize your comfort.

5.1. Chair Height Adjustment

- To raise the chair: Stand up and lift the lever located on the right side, beneath the seat. The chair will rise. Release the lever at the desired height.
- To lower the chair: While seated, lift the same lever. The chair will lower. Release the lever at the desired height.

5.2. Recline and Footrest

- To recline the backrest: Pull the recline lever on the left side of the seat and lean back to your desired angle (up to 160°). Release the lever to lock the position.
- To use the footrest: Pull out the footrest from beneath the seat and flip it up.
- To retract the footrest: Fold it down and push it back under the seat.

Figure 2: Chair Dimensions and Recline

5.3. Armrest Adjustment

The 360° adjustable armrests offer versatile positioning:

- Height Adjustment: Press and hold the button on the side of the armrest while lifting or lowering to adjust its height.
- Rotation: Rotate the front end of the armrest left or right to adjust the armrest angle.
- Forward/Backward Adjustment: Push the armrest pad forward or backward.
- Folding: Press the button at the front end of the armrest and lift slightly to fold the armrest up.

Figure 3: 360° Mechanical Armrests

5.4. Headrest Adjustment

The 3D ergonomic headrest can be adjusted for optimal neck and head support:

- Height Adjustment: Pull the headrest up or down to adjust its height.
- Forward/Backward Positioning: Gently pull the headrest forward to adjust its forward or backward positioning.
- Side Support: Adjust each side of the headrest to a suitable position to support your head and prevent tilting.

Figure 4: 3D Ergonomic Neck Pillow

5.5. Lumbar Support Adjustment

The AutoFull M6 features dynamic tracking lumbar support:

- Automatic Adjustment: Lift the right lever on the backrest to automatically adjust the lumbar support to your back. Release the lever to lock the lumbar support in place.
- Height Adjustment: You can continue to adjust its position by lifting it.
- Depth Adjustment: Turn the backrest knob to adjust the lumbar height.

Figure 5: 4-Axis Lumbar Glide Support

5.6. Heated and Ventilated Seat & Massage Function

The seat includes integrated controls for heating, ventilation, and massage:

- Power Connection: Connect a mobile power supply (not included) to the USB cable located in the back pocket of the chair.
- Ventilation: Press the rightmost button on the seat cushion. The indicator light will turn green, activating the ventilation function. Press the button again to adjust the ventilation intensity (three levels, decreasing sequentially until off).
- Heating: Press the second button from the right on the seat cushion. The indicator light will turn red, activating the heating function. Press the button again to adjust the heating intensity (three levels,

decreasing sequentially until off).

- Massage: Press the leftmost button on the seat cushion. The indicator light will turn blue, activating the backrest's massage function. Press the button again to adjust the massage intensity (three levels, decreasing sequentially until off). The massage function can be used in conjunction with heating or cooling.

Figure 6: Ventilated & Heated Seat Controls

Your browser does not support the video tag.

Video 2: AutoFull M6 Gaming Chair Features Overview

This video highlights the key features of the AutoFull M6 Gaming Chair, including its adjustable components and climate control functions.

Your browser does not support the video tag.

Video 3: AutoFull M6 Features Demonstration

A detailed demonstration of the AutoFull M6's features, including the heated/ventilated seat, massage, and various adjustments.

6. Maintenance

To ensure the longevity and appearance of your AutoFull M6 Gaming Chair, follow these maintenance guidelines:

- Cleaning: Wipe clean with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the leather.
- Regular Inspection: Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary.
- Moving the Chair: When moving the chair, lift it rather than dragging it to prevent damage to the casters or base.
- Avoid Direct Sunlight: Prolonged exposure to direct sunlight can cause the leather to fade or crack.

7. Troubleshooting

If you encounter any issues with your AutoFull M6 Gaming Chair, refer to the following common troubleshooting tips:

- **Chair not adjusting height:** Ensure the gas lift lever is fully engaged. If the issue persists, the gas lift cylinder may need replacement.
- **Wobbly chair:** Check all assembly screws and bolts, especially those connecting the seat to the base and the armrests. Tighten any loose fasteners.
- **Heated/Ventilated/Massage functions not working:** Verify that the USB power supply is correctly connected and adequately charged. Ensure the buttons are pressed firmly and the indicator lights are on.
- **Casters not rolling smoothly:** Check for any debris (hair, dust) caught in the casters and clean them. Lubrication may also be applied if necessary.
- **Lumbar support not adjusting:** Ensure the adjustment levers and knobs are fully engaged and not obstructed.

For further assistance, please contact AutoFull customer service.

8. Specifications

Feature	Detail
Brand	AutoFull
Model Name	AFM6
Color	Black Gold
Product Dimensions	20"D x 20"W x 50.06"H

Feature	Detail
Item Weight	75 pounds
Maximum Load Bearing	397 lbs (180 kg)
Special Feature	Ergonomic, Ventilated & Heated Seat, Lumbar Massage, 360° Adjustable Armrests, Footrest
Material	Eco-friendly high-resilience foam, Upgraded Leather
Reclining Angle	Up to 160°
Certifications	IGR, BIFMA, SGS, TUV

9. Warranty and Support

The AutoFull M6 Gaming Chair comes with a 3-year warranty, ensuring peace of mind regarding its quality and durability. For any product-related inquiries, technical support, or warranty claims, please contact AutoFull customer service. Our dedicated team is available to assist you with any questions or concerns you may have.

For more information, visit the official AutoFull store:AutoFull Store