Bewinner Bewinneratd7k9xnf6

Bewinner HiFi MP3 Player with Bluetooth 5.3 Instruction Manual

Model: Bewinneratd7k9xnf6

Product Overview

The Bewinner HiFi MP3 Player is a portable digital music player designed for high-resolution audio playback. It features Bluetooth 5.3 connectivity, a 2.4-inch HD display, and supports various lossless audio formats. This manual provides essential information for its proper use and maintenance.

Image: The Bewinner HiFi MP3 Player shown with its included USB charging cable.

Setup

1. Charging the Device

Before first use, fully charge the MP3 player. Connect the included USB cable to the player's charging port and to a standard USB power adapter (not included) or a computer's USB port. The device has a 1500mAh battery, providing up to 10 hours of continuous playback. A full charge typically takes approximately 2 hours.

Image: The MP3 player connected for charging, illustrating its long play time and battery capacity.

2. Inserting a Memory Card

The player comes with 16GB of built-in memory. To expand storage, insert a compatible storage card (up to 256GB) into the designated slot. Ensure the card is inserted correctly until it clicks into place.

3. Transferring Music Files

Music files can be transferred to the player via a computer or an OTG-compatible mobile device.

- **Computer Transfer:** Connect the MP3 player to your computer using the USB cable. The player will appear as a removable disk. Drag and drop your music files into the player's storage or the inserted memory card.
- **Mobile OTG Transfer:** For OTG-compatible mobile devices, connect the player using an OTG cable (not included). You can then transfer files directly from your mobile device.

Image: Diagrams showing the MP3 player connected to a laptop and a mobile phone for music file transfer.

Operating Instructions

1. Power On/Off and Basic Navigation

Press and hold the power button to turn the device on or off. Use the ALPS scroll control and surrounding buttons to navigate through menus, select songs, and adjust settings on the 2.4-inch HD display.

Image: Close-up of the MP3 player's retro scroll wheel design and user interface for song selection.

2. Music Playback

The player supports a wide range of audio formats, including FLAC, APE, DFF, MP3, WAV, WMA, M4A, MP2, AAC, ALAC, OGG, AIFF, and Native DSD (up to 128-bit/5.6 MHz). Select your desired track from the music library using the scroll control. The player offers both line output and headphone output ports for versatile listening options.

3. Bluetooth 5.3 Connectivity

The device features bidirectional Bluetooth 5.3 with APT-X protocol for lossless wireless audio. To connect:

1. Go to the Bluetooth settings menu on the MP3 player.
2. Enable Bluetooth and scan for devices.
3. Select your Bluetooth headphones, speakers, or other compatible device from the list to pair.

The player can also function as a Bluetooth receiver, allowing it to receive audio from other Bluetooth-enabled devices.

Your browser does not support the video tag.

Video: A demonstration of the Bewinner HiFi MP3 Player, showcasing its design and basic operation, including Bluetooth connectivity.

4. USB Amplifier / External DAC Functionality

The digital music player can be connected to a USB amplifier to serve as a digital source. Alternatively, it can function as an external decoding amplifier when connected to a smartphone or computer, enhancing their audio output quality.

Maintenance

1. Cleaning

Wipe the device with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, which may damage the screen or casing.

2. Battery Care

To prolong battery life, avoid exposing the device to extreme temperatures. Charge the device regularly and avoid completely draining the battery frequently.

3. Software Updates

The device may support automatic software updates. Check the device settings periodically for available updates to ensure optimal performance and access to new features.

Troubleshooting

- **Device not powering on:** Ensure the battery is charged. Connect to a power source and try again.
- **No sound:** Check headphone connection or Bluetooth pairing. Verify volume levels on both the player and connected audio device.
- **Files not recognized:** Ensure music files are in supported formats (FLAC, APE, DFF, MP3, WAV, WMA, M4A, MP2, AAC, ALAC, OGG, AIFF, Native DSD).
- **Bluetooth connection issues:** Ensure the player and the target device are within range. Try unpairing and re-pairing the devices.
- **Slow file transfer:** Ensure the USB cable is securely connected. For large files, transfer times may vary.

Specifications

Feature	Detail
Brand	Bewinner
Model Name	Bewinneratd7k9xnf6
Display	2.4 inch HD Screen
Bluetooth Version	5.3 (Bidirectional, APT-X protocol)
Internal Memory	16GB
Expandable Storage	Up to 256GB (via storage card)
Battery Capacity	1500mAh

Feature	Detail
Supported Audio Formats	FLAC, APE, DFF, MP3, WAV, WMA, M4A, MP2, AAC, ALAC, OGG, AIFF, Native DSD (up to 128-bit/5.6 MHz)
Output Ports	Line Output, Headphone Output

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact Bewinner customer service directly. Contact details can typically be found on the manufacturer's official website or on the product packaging.

© 2024 Bewinner. All rights reserved.