Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DUMOS DU2077GN-HJ3

DUMOS Armless Desk Chair User Manual

Model: DU2077GN-HJ3
Brand: DUMOS

Introduction

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your DUMOS Armless Desk Chair. Designed for comfort and efficiency in small spaces, this ergonomic chair features a breathable mesh back, high-density sponge cushion, and a sturdy five-star base with smooth-rolling casters. Please read this manual thoroughly before assembly and use to ensure proper function and safety.



Figure 1: DUMOS Armless Desk Chair (Green)

Safety Information

Important Safety Precautions:

- Do not exceed the maximum weight capacity of**200 pounds (90.7 kg)**. Overloading the chair can lead to instability and potential injury.
- Follow the assembly instructions carefully to ensure stability and safety. Incorrect assembly may result in product failure.
- Keep all small parts and packaging materials away from children to prevent choking hazards.
- Regularly inspect all bolts and connections to ensure they remain tight. Retighten as necessary.
- Do not stand on the chair or use it as a step stool.
- Avoid exposing the chair to direct sunlight or extreme temperatures, which can damage materials.

Package Contents

Before beginning assembly, ensure all parts are present and undamaged. Refer to the diagram below for identification.

(1) Seat with Backrest Assembly x1

(2) Gas Lift x1

(3) Five-Star Base x1

(4) Casters x5

(5) Bolts (for seat/back connection) x2

(6) Wrench x1



Figure 2: All Components Included in the Package

Assembly Instructions

Follow these steps carefully to assemble your DUMOS Armless Desk Chair. An assembly video is also provided for visual guidance.

Your browser does not support the video tag.

Video 1: The Installation of Small Home Office Desk Chair
This video demonstrates the complete assembly process for the DUMOS Armless Desk Chair, from unboxing to final setup.

1. ### Step 1: Attach Casters to Base

   Press the Casters (4) into the holes at the end of each Leg of the Five-Star Base (3). Ensure each caster is fully inserted. *Tip: Don't make the caster go vertical to the hole; it will be easier for installation if it has a little angle.*

   

   Figure 3: Attaching Casters to the Five-Star Base

2. ### Step 2: Insert Gas Lift into Base

   Insert the Gas Lift (2) into the center hole of the assembled Five-Star Base (3).

   

   Figure 4: Inserting the Gas Lift

3. ### Step 3: Connect Seat and Backrest

   Connect the Seat and Backrest Assembly (1) using the provided Bolts (5) and tighten them securely with the Wrench (6).

   

   Figure 5: Securing the Seat and Backrest

4. ### Step 4: Attach Seat Assembly to Gas Lift

   Carefully place the assembled Seat and Backrest onto the Gas Lift (2), ensuring it is centered and stable. Press down firmly to secure the connection.

   

Figure 6: Attaching Seat to Gas Lift

Operating Instructions

- **Height Adjustment:**

  To adjust the chair's height, locate the lever under the seat on the right side. While seated, pull the lever up to lower the chair. To raise the chair, stand up and pull the lever up. Release the lever at the desired height.



Figure 7: Adjustable Height Mechanism

- **360° Swivel Function:**

  The chair is designed with a 360-degree swivel function, allowing for easy rotation without moving the base. Simply rotate the seat to your desired direction.



Figure 8: 360° Swivel Casters

- **Ergonomic Backrest:**

  The Y-shaped backrest is designed to provide lumbar support, promoting a healthy sitting posture and reducing back strain during prolonged use.

Figure 9: Ergonomic Backrest Design

Maintenance

- **Cleaning:**

  Wipe clean with a damp cloth. For the seat cushion, the cover can be removed for more convenient cleaning. Allow to air dry completely before reattaching.



Figure 10: Removable Seat Mat for Easy Cleaning

- **Regular Inspection:**

  Periodically check all screws and connections to ensure they are tight. Loose connections can affect the chair's stability and safety.

- **Caster Care:**

  Keep the caster wheels free of hair, dust, and debris to ensure smooth rolling. Clean them regularly with a soft brush or cloth.

TROUBLESHOOTING

If you encounter any issues with your DUMOS Armless Desk Chair, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair is wobbly or unstable.	Loose bolts or incorrect assembly.	Ensure all bolts are securely tightened. Re-check assembly steps.
Chair does not adjust height properly.	Gas lift not properly seated or damaged.	Ensure the gas lift is fully inserted into the base and seat mechanism. If still problematic, contact customer support.
Casters do not roll smoothly.	Debris in casters or casters not fully inserted.	Clean casters of any debris. Ensure casters are fully pressed into the base legs.

Specifications

Feature	Detail
Brand	DUMOS
Model Name	Ergonomic Adjustable Swivel Rolling Task Chair
Item Model Number	DU2077GN-HJ3
Color	Green
Product Dimensions	14.96"D x 16.92"W x 29.72"H
Item Weight	11.9 pounds (5.4 kg)
Maximum Weight Recommendation	200 Pounds (90.7 kg)
Material	Foam, Sponge (for cushion)
Back Style	Solid Back (Mesh)
Arm Style	Armless
Special Feature	Adjustable Height, Ergonomic, Rolling
Furniture Base Movement	Swivel
Recommended Uses	Office, Reading
Product Care Instructions	Wipe Clean

Warranty and Support

DUMOS is committed to providing high-quality products. For any questions, concerns, or warranty claims regarding your Armless Desk Chair, please contact our customer support team.

Please refer to your purchase documentation or the DUMOS official website for specific warranty terms and contact information.

For additional support, you may visit the DUMOS Store on Amazon:DUMOS Store

© 2024 DUMOS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DPQMDFBF

More documents and user manuals: **https://manuals.plus/**