Braun BG7555

Braun Bodygroomer Series 7 BG7555

Instruction Manual

Introduction

The Braun Bodygroomer Series 7 BG7555 is designed to provide a gentle and efficient grooming experience for men. Featuring SmartLight technology and SkinGuard, it ensures thorough and comfortable hair removal across various body areas. This manual provides essential information for the safe and effective use, maintenance, and care of your device.

Key Features:

- **SmartLight Technology:** Illuminates fine hairs for a more thorough shave, ensuring no areas are missed.
- **SkinGuard Technology:** Minimizes skin irritation and cuts, providing a gentle grooming experience even in sensitive areas.
- **Precision Shaving Head:** Offers ultimate skin comfort and efficiency for a smooth shave.
- **Waterproof Design (AquaGrip):** Allows for safe and convenient use in the shower, providing maximum control.
- **Long-lasting Battery:** Powerful Li-ion battery provides up to 100 minutes of cordless runtime.

What's in the Box:

- 1 x Braun Bodygroomer
- 4 x Comb Attachments (various lengths)
- 1 x Shaving Attachment
- 1 x Shower Hanger
- 1 x Pouch
- 1 x Cleansing Brush



Image 1: The Braun Bodygroomer Series 7 BG7555 with its packaging and all included accessories, such as various comb attachments, a shaving head, a shower hanger, a pouch, and a cleaning brush.

Safety Information

Please read all safety instructions carefully before using the device. Failure to follow these instructions may result in injury or damage to the device.

- **Water Safety:** Be careful when using the device near water. Although waterproof, ensure the charging cable is disconnected before use in wet conditions.
- **Cleaning:** Clean the device thoroughly after each use to prevent the growth of bacteria and maintain hygiene.
- **Skin Contact:** Avoid excessive pressure or prolonged contact with the skin to prevent irritation or cuts, especially in sensitive areas.
- **Blade Care:** Do not use the device if the blades or foil are damaged, as this may cause skin injury. Replace damaged parts immediately.
- **Children:** Keep the device out of reach of children. This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.

Setup

Initial Charging:

1. Before first use, fully charge the Bodygroomer. Connect the charging cable to the device and plug it into a power outlet.
2. The charging indicator light will show the charging status. A full charge typically takes approximately 1 hour.
3. Once fully charged, disconnect the device from the power source.

Attaching Combs and Shaving Head:

- To attach a comb, align the comb with the grooming head and push it firmly until it clicks into place.
- To attach the precision shaving head, align it with the main unit and press down until it securely locks.
- To remove an attachment, gently pull it away from the grooming head.



Image 2: The Braun Bodygroomer Series 7 BG7555 displayed with all its accessories, including various comb attachments, the precision shaving head, and the cleaning brush, illustrating the full kit.

Operating Instructions

General Use:

1. Press the power button to turn the device on.
2. Select the desired attachment (comb for trimming, shaving head for a close shave).
3. For trimming, move the groomer against the direction of hair growth. For shaving, move it gently over the skin.
4. The SmartLight will illuminate automatically to help you see fine hairs and ensure thorough coverage.
5. After use, press the power button to turn the device off.

Using Attachments:

- **Sensitive Comb Attachment:** Use this attachment for gentle trimming, especially in sensitive areas. It prevents direct skin contact with the blade.
- **Other Comb Attachments:** Choose the appropriate comb length for your desired hair length. These are ideal for general body grooming.
- **Precision Shaving Head:** For a smooth, close shave, use this attachment without a comb. Ensure your skin is clean and dry for best results, or use with water/shaving foam for wet shaving.

Wet & Dry Use:

The Braun Bodygroomer Series 7 is 100% waterproof and can be used in the shower. The AquaGrip handle provides a secure grip even when wet. For optimal results, you may use it with water, foam, or gel.

Maintenance

Cleaning:

1. After each use, turn off the device and remove any attached comb or shaving head.
2. Rinse the grooming head and attachments under warm running water. You may use the included cleaning brush to remove trapped hairs.
3. Allow all parts to air dry completely before reassembling or storing.
4. For thorough cleaning, you can also use a mild soap solution.

Storage:

- Store the Bodygroomer and its accessories in the provided pouch to protect them from dust and damage.
- Keep the device in a cool, dry place, away from direct sunlight and extreme temperatures.
- Ensure the device is fully dry before storing to prevent mildew or damage.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully.
Device does not turn on.	Device is damaged.	Contact Braun customer service. Do not attempt to repair yourself.
Poor trimming/shaving performance.	Blades are dull or clogged with hair.	Clean the grooming head and blades thoroughly. Consider replacing the shaving head if performance does not improve.
Skin irritation after use.	Excessive pressure, dull blades, or improper technique.	Use gentle pressure. Ensure blades are clean and sharp. Use the SkinGuard or sensitive comb attachment. Shave against the grain for closer results, but with caution.
Device not charging.	Charging cable or adapter is faulty.	Check the charging cable and adapter for damage. Try a different power outlet.

Specifications

- **Model Name:** Series 7
- **Model Number:** BG7555
- **Power Source:** Battery Powered (Li-ion)
- **Battery Life:** Up to 100 minutes
- **Item Weight:** 262 Grams
- **Color:** Gray
- **Blade Material:** Stainless Steel
- **Special Features:** Illuminated (SmartLight), Skin Protection (SkinGuard), AquaGrip
- **Manufacturer:** Procter & Gamble
- **Parcel Dimensions:** 25 x 13.3 x 6.1 cm

Warranty and Support

Braun products are manufactured to meet the highest standards of quality, functionality, and design. Your Braun Bodygroomer Series 7 BG7555 comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Braun website.

Customer Support:

If you encounter any issues with your device or require further assistance, please contact Braun customer service. You can find contact information (phone numbers, email, or online support portals) on the official Braun website or in the product packaging. For more information and product registration, please visit the official Braun website:www.braun.com

© 2025 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question