Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun AIO7545

Braun ProBlade AutoSense AIO7545 All-in-One Series 7 Grooming Kit User Manual

Model: AIO7545

1. Introduction

This user manual provides comprehensive instructions for the safe and effective use of your Braun ProBlade AutoSense AIO7545 All-in-One Series 7 Grooming Kit. Please read all instructions carefully before using the appliance and retain them for future reference.
The Braun Series 7 Grooming Kit is designed for versatile grooming, including beard trimming, hair clipping, body grooming, and precision shaving, featuring ultra-sharp ProBlade technology and AutoSense for efficient performance.

2. Safety Information

WARNING:

- Use with caution on sensitive skin.
- Keep out of reach of children.
- Do not use near water sources (e.g., bathtubs, showers, sinks).
- Follow recommended cleaning and maintenance instructions.
- Store out of reach of children and pets.
- Do not use on children or infants.
- Always check the appliance, attachments, and cord for damage before use. Do not use if damaged.

3. Package Contents

Your Braun ProBlade AutoSense AIO7545 All-in-One Series 7 Grooming Kit includes the following items:

- 1x Braun Series 7 Trimmer Handle
- 1x ProBlade Trimmer Head
- 1x Precision Shaver Head
- 1x Ear & Nose Trimmer Head
- 1x SkinGuard Trimmer Head

- 7x Comb Attachments (various lengths for beard, hair, and body)
- 1x Cleaning Brush
- 1x Storage Pouch
- 1x Charging Cable/Power Adapter



Image 3.1: The Braun Series 7 Grooming Kit showing the main trimmer unit and all included attachments and accessories.



Image 3.2: An overview diagram illustrating the 12-in-1 styling capabilities and all included attachments, such as adjustable combs, precision shaver head, SkinGuard trimmer, and ear/nose trimmer.

4. Setup

4.1 Charging the Appliance

1. Ensure the appliance is switched off.
2. Connect the charging cable to the trimmer and plug the power adapter into an electrical outlet.
3. The charging indicator light will illuminate to show that the appliance is charging.
4. A full charge provides up to 120 minutes of cordless runtime. The first charge may take longer.
5. Once fully charged, disconnect the appliance from the power supply.

4.2 Attaching and Removing Heads/Combs

- To attach a head: Align the head with the trimmer body and press until it clicks into place.
- To remove a head: Gently pull the head upwards away from the trimmer body.
- To attach a comb: Slide the desired comb attachment onto the trimmer head until it locks.
- To remove a comb: Gently push the comb attachment off the trimmer head.

5. Operating Instructions

The Braun Series 7 Grooming Kit features AutoSense technology, which adapts the motor power to your beard thickness for an effortless trim.



Image 5.1: Detailed view of the ProBlade for sharp trimming, SkinGuard technology for minimizing cuts, and the precision shaver head for perfect contours.

5.1 Beard Trimming and Hair Clipping

- Attach the ProBlade trimmer head.
- Select the appropriate comb attachment for your desired length (14 length settings available, from 3 to 21 mm).
- Turn on the appliance.
- Move the trimmer against the direction of hair growth, ensuring even strokes.

5.2 Body Grooming

- For sensitive areas, attach the SkinGuard trimmer head or the sensitive comb attachment to the ProBlade head.
- Turn on the appliance.
- Gently glide the trimmer over the skin, ensuring the SkinGuard or comb attachment is flat against the skin.




Image 5.2: Illustration of using the grooming kit for body hair, highlighting the sensitive comb attachment for gentle trimming in sensitive areas.

5.3 Precision Shaving and Contouring

- Attach the precision shaver head.
- Turn on the appliance.

- Use short, gentle strokes to achieve clean edges and perfect contours.




Image 5.3: Demonstrating the use of the precision shaver head for a clean and precise shave, achieving smooth results.

5.4 Ear and Nose Trimming

- Attach the ear and nose trimmer head.
- Turn on the appliance.
- Carefully insert the trimmer into the nostril or ear canal, rotating gently to trim unwanted hair. Do not insert too deeply.




Image 5.4: Shows the ear and nose hair trimmer in use, ensuring no hair is missed, and mentions the eyebrow comb attachment for finishing touches.



Image 5.5: A composite image demonstrating the versatility of the grooming kit for different areas: beard, body, hair, and face.

6. Maintenance and Cleaning

The Braun Series 7 Grooming Kit is 100% waterproof and features an AquaGrip handle for easy cleaning under running water.

- **After each use:** Turn off the appliance and remove the trimmer head. Rinse the head and the trimmer body under warm running water.
- Use the provided cleaning brush to remove any stubborn hair clippings from the blades and combs.
- Allow all parts to air dry completely before reassembling or storing.
- For optimal performance, regularly oil the trimmer blades with a drop of light machine oil (not included).
- Store the appliance and its accessories in the provided storage pouch to protect them from damage.

7. Troubleshooting

If you encounter issues with your Braun Series 7 Grooming Kit, please refer to the following common solutions:

- **Appliance not turning on:** Ensure the battery is charged. Connect the trimmer to the charger for at least 10 minutes.
- **Reduced trimming performance:** Clean the trimmer head and blades thoroughly. Ensure no hair is stuck. The blades may need oiling.
- **Attachments not fitting:** Ensure the correct head is attached to the trimmer body before attempting to attach combs. Make sure attachments are aligned correctly.
- **Battery not charging:** Check the power adapter and cable for damage. Ensure the electrical outlet is working.

If the problem persists, please contact Braun customer support.

8. Specifications

Feature	Specification
Model Number	AIO7545

Feature	Specification
Brand	Braun
Power Source	Battery Powered (Li-ion)
Battery Runtime	Up to 120 minutes
Waterproof	100% Waterproof (AquaGrip)
Blade Material	Metal (ProBlade)
Length Settings	14 (3-21 mm)
Dimensions (L x W x H)	16 x 6.3 x 25.2 cm
Weight	323 Grams
Country of Origin	China

9. Warranty and Support

This Braun product is manufactured to the highest quality standards. For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official Braun website.
For further assistance, product registration, or to find authorized service centers, please visit the official Braun support website or contact their customer service department.
Online Support: www.braun.com/global/contact-us.html

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DQWLG36G

More documents and user manuals: **https://manuals.plus/**