Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun AIO5540

Braun AIO5540 All-in-One Series 5 Grooming Kit Instruction Manual

Model: AIO5540 | Brand: Braun

1. Important Safety Information

Please read these instructions completely before using the appliance. Keep them for future reference.

- **WARNING:** Avoid contact with blades near eyes.
- Do not use the trimmer on infants.
- This appliance is suitable for cleaning under running water.
- Do not use the appliance if it is damaged.
- Keep the appliance dry when not in use.

2. Product Overview

The Braun AIO5540 All-in-One Series 5 Grooming Kit is a versatile 9-in-1 tool designed for comprehensive head-to-toe styling. It features an ultra-sharp blade for precision and efficiency, and SkinGuard technology for sensitive areas.



Image 2.1: Braun AIO5540 Grooming Kit with main unit and accessories.

2.1 Key Features

- **9-in-1 Versatility:** Designed for beard trimming, hair clipping, and full body grooming.
- **Ultra-Sharp Blade:** Ensures precise and efficient trimming results.
- **SkinGuard Technology:** Provides maximum safety and comfort, especially for sensitive body areas.
- **14 Length Settings:** Offers precise control over styling with lengths ranging from 3-21 mm.
- **100% Waterproof with AquaGrip:** Allows for safe use and easy cleaning under running water, even in the shower.
- **Long-lasting Li-ion Battery:** Provides up to 120 minutes of cordless operation.

2.2 Included Components

The Braun AIO5540 kit includes the following items:

- 1x Trimmer unit (AIO5)
- 6x Comb attachments (various lengths for beard and hair)

- 1x SkinGuard trimmer attachment
- 1x Cleaning brush
- 1x Storage bag



Image 2.2: Detailed view of all included components.

3. Setup and Charging

3.1 Initial Charge

Before first use, fully charge the trimmer. Connect the charging cable to the trimmer and a power outlet. The charging indicator light will show the charging status. A full charge provides up to 120 minutes of cordless use.

3.2 Attaching/Detaching Comb Attachments

To attach a comb, align it with the trimmer head and push until it clicks into place. To detach, gently pull the comb away from the trimmer head. Ensure the trimmer is switched off before changing attachments.

4. Operating Instructions

The Braun AIO5540 is designed for various grooming needs. Always ensure your skin and hair are clean and dry before trimming for best results.

4.1 Beard Trimming

1. Select the desired comb attachment for your beard length (e.g., 3-11mm for short to medium beards, 3-21mm for longer beards).
2. Adjust the length setting on the comb if applicable.
3. Turn on the trimmer and move it against the direction of hair growth.
4. For precise lines and edges, remove the comb attachment and use the bare blade.





Image 4.1: Examples of various trimming applications including beard and body.

4.2 Hair Clipping

1. Attach the appropriate hair comb (e.g., 3-21mm comb).
2. Adjust the length setting.
3. Start clipping from the nape of the neck, moving upwards against hair growth.
4. Use shorter settings for fading and longer settings for the top of the head.

4.3 Body Grooming

1. For sensitive areas, use the SkinGuard trimmer attachment for maximum comfort and safety.
2. For general body hair, use the body comb attachments or the bare blade for a closer trim.
3. Move the trimmer gently over the skin, ensuring even contact.
4. The AquaGrip feature allows for safe use in the shower.





Image 4.2: Details of SkinGuard, Ultra-sharp Blade, and AquaGrip for enhanced grooming.

5. Cleaning and Maintenance

5.1 Cleaning the Trimmer Head

1. Ensure the trimmer is switched off and unplugged from the power source.
2. Remove any comb attachments.
3. Brush away hair from the trimmer head and blades using the provided cleaning brush.
4. Rinse the trimmer head and blades under warm running water. The appliance is 100% waterproof.
5. Allow the trimmer head to air dry completely before reattaching combs or storing.

5.2 Blade Lubrication

For optimal performance, it is recommended to periodically lubricate the blades with a drop of light machine oil (not included) after cleaning, especially if the trimmer feels less smooth during operation.

5.3 Storage

Store the trimmer and its accessories in the provided storage bag in a dry place, away from direct sunlight and extreme temperatures.

6. Troubleshooting

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is discharged.	Charge the trimmer for at least 1 hour.
Trimmer pulls hair or cuts poorly.	Blades are dull or clogged with hair.	Clean the trimmer head and blades. Lubricate blades if necessary. Ensure comb attachment is correctly fitted.
Trimmer does not hold a charge.	Battery life has diminished.	Contact customer service for battery replacement or service options.

7. Specifications

Model Number: AIO5540 (7500435245029)

Brand: Braun

Power Source: Battery Powered (1 Lithium-ion battery, included)

Battery Life: Up to 120 minutes cordless operation

Charging Time: Approximately 1 hour for full charge

Blade Material: Metal

Special Features: Waterproof, Ultra-sharp blade, Cordless, SkinGuard Technology

Dimensions (L x W x H): 13 x 6 x 25.2 cm

Weight: 260 Grams

Color: Black

Country of Origin: China

8. Warranty and Support

For warranty information, product registration, or customer support, please refer to the official Braun website or contact their customer service.
You can also scan the QR code on the product packaging or visit the following link for additional information and potential warranty registration:Braun Official Support Page



Image 8.1: Product packaging with QR code for support.

© 2025 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DQWW7LNZ

More documents and user manuals: **https://manuals.plus/**