Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DERCASS GX002053A

DERCASS Wood Platform Bed with Trundle and Storage Headboard - Full Size - Instruction Manual

Model: GX002053A

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your DERCASS Wood Platform Bed with Trundle and Storage Headboard. Please read all instructions carefully before assembly and retain this manual for future reference.

Safety Information

- Ensure all parts are present and undamaged before beginning assembly. Do not use if any parts are missing or broken.
- Assemble the bed on a soft, clean surface to prevent scratches.
- Tighten all bolts and screws firmly, but do not overtighten. Periodically check and re-tighten all fasteners.
- Keep small parts away from children during assembly.
- Do not allow children to climb or play on the bed or trundle without supervision.
- Use only the recommended mattress thickness (6-8 inches) for the main bed and trundle to ensure proper fit and safety.
- The bed has a weight capacity of 400 lbs. Do not exceed this limit.

Package Contents

Your DERCASS Wood Platform Bed comes in two packages. Please verify all components are present before starting assembly.

Included Components:

- Headboard with storage shelves and upholstered panels
- Platform bed frame components
- Trundle bed frame components
- Wooden slats for main bed and trundle

- Hardware (screws, bolts, nuts, Allen wrench)

Note: Mattress is not included.

Setup and Assembly

Assembly requires two adults. Please follow these steps carefully. Refer to the dimension diagram for component identification and placement.



Figure 1: Overall dimensions and component layout of the bed system.

Step 1: Assemble the Headboard

1. Identify all headboard panels and shelves.
2. Attach the side panels to the main back panel of the headboard using the provided hardware.
3. Insert the storage shelves into their designated slots within the headboard structure. Secure them with screws.
4. Attach the upholstered headboard panels to the main headboard frame. Ensure they are securely fastened.



Figure 2: Detail of the upholstered headboard section.




Figure 3: Detail of the rotatable storage board feature.

Step 2: Assemble the Main Bed Frame

1. Connect the side rails to the assembled headboard and footboard (if separate) using the appropriate bolts.
2. Ensure all connections are flush and secure.
3. Place the wooden support slats across the bed frame. Evenly space them and secure them to the side rails using the provided screws.



Figure 4: Main bed frame with slats and trundle.

Step 3: Assemble the Trundle Bed

1. Assemble the trundle frame using the designated side and end panels.
2. Attach the wheels to the bottom of the trundle frame.
3. Place the wooden support slats across the trundle frame, spacing them evenly and securing them.
4. Slide the assembled trundle under the main bed frame.




Figure 5: Trundle bed frame detail.




Figure 6: Fully assembled bed with trundle extended.

Step 4: Final Checks

- Ensure all fasteners are tight and secure.
- Verify the bed is stable and does not wobble.
- Test the trundle mechanism to ensure it slides smoothly.

Operating Instructions

Using the Trundle Bed

The trundle bed is designed to slide out from under the main bed. To use:

1. Gently pull the trundle frame from under the main bed. The wheels will facilitate smooth movement.
2. To store, push the trundle back under the main bed until it is fully recessed.

Using the Storage Headboard

The headboard features multiple shelves and a rotatable board for convenient storage and use of electronic devices.

- Use the open shelves to store books, small electronics, or decorative items.

- The rotatable board (29.8" x 8.7") can be adjusted to hold a phone or tablet for viewing while in bed. Gently pivot the board to the desired angle.

Maintenance

- **Cleaning:** Wipe the bed frame and headboard surfaces with a dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Fasteners:** Periodically check all bolts and screws to ensure they remain tight. Re-tighten as necessary to maintain stability and prevent squeaking.
- **Upholstery:** For upholstered sections, spot clean with a mild fabric cleaner if needed. Test on an inconspicuous area first.

Troubleshooting

Bed is Wobbly or Squeaks

- Ensure all bolts and screws are fully tightened.
- Check that all components are correctly aligned according to the assembly instructions.
- Verify that the bed is placed on a level surface.

Trundle Does Not Slide Smoothly

- Check for any obstructions under the main bed or in the trundle's path.
- Inspect the trundle wheels for damage or debris. Clean if necessary.
- Ensure the trundle frame was assembled correctly and is not warped.

Missing Parts or Damaged Components

- Refer to the "Package Contents" section and your original packing list.
- Contact DERCASS customer support for assistance (see "Support" section).

Specifications

Feature	Detail
Brand	DERCASS
Model Number	GX002053A
Size	Full
Color	Grey
Overall Product Dimensions	81.3"L x 65.6"W x 35.4"H
Recommended Mattress Thickness (Bed)	6-8 inches
Bed Weight Capacity	400 lbs
Material	Pine Wood + MDF
Assembly Required	Yes
Product Weight	153 lbs

Care Instructions	Wipe with Dry Cloth

Warranty

Specific warranty information for this product may vary. Please refer to the documentation included with your purchase or contact DERCASS customer support for details regarding warranty coverage.

Support

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact DERCASS customer support. Refer to your purchase receipt or the seller's information for contact details.
For general inquiries, you may visit the DERCASS brand page on Amazon:DERCASS Store on Amazon

© 2024 DERCASS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DQYLXJC1

More documents and user manuals: **https://manuals.plus/**