Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Q-Stoves ElectriQ

Q-Stoves ElectriQ 12-inch Electric Pizza Oven Instruction Manual

Model: ElectriQ | Brand: Q-Stoves

1. Introduction

The Q-Stoves ElectriQ 12-inch Electric Pizza Oven is designed for indoor use, offering a high-temperature cooking experience for pizzas and other dishes. This appliance features a full stainless steel body, triple-layer insulation, and a separate external controller for precise temperature management. It is capable of reaching temperatures up to 1000°F (500°C), allowing for rapid cooking times.

2. Important Safety Information

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure adequate ventilation around the oven during operation.

3. Product Components

The Q-Stoves ElectriQ pizza oven comes with the following components:

- ElectriQ Pizza Oven Unit
- Pizza Stone (12-inch)
- External Controller with Remote Control Panel
- Power Cord
- Door Knob
- Pizza Peel
- Carrying Strap



Figure 3.1: Exploded view of the Q-Stoves ElectriQ pizza oven components, highlighting the stainless steel body, silicone shell, individual controller, pizza stone, folding legs, and ceramic fiber insulation layer.

4. Setup Instructions

1. **Unpack the Oven:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Choose a Location:** Place the oven on a stable, flat, and heat-resistant surface. Ensure there is adequate clearance (at least 6 inches) from walls and other objects for proper ventilation. Do not place on or near flammable materials.
3. **Install Pizza Stone:** Carefully slide the pizza stone into the designated slot inside the oven.
4. **Connect Controller:** Connect the external controller to the oven unit. Ensure the connection is secure.
5. **Connect Power:** Plug the power cord into the external controller, then plug the other end into a grounded electrical outlet.
6. **Initial Burn-in (Optional but Recommended):** Before first use, operate the oven empty at maximum temperature for 15-20 minutes to burn off any manufacturing residues. Ensure the area is well-ventilated during this process.

5. Operating Instructions

5.1 Preheating the Oven

1. Turn on the external controller.
2. Set the desired temperature using the independent temperature controls for the dual heating elements. For most pizzas, a temperature of 800-1000°F (425-500°C) is recommended.
3. Allow the oven to preheat until it reaches the set temperature. This typically takes 15-20 minutes. The pizza stone must be fully heated for optimal results.

5.2 Cooking Pizza

1. Prepare your pizza on a lightly floured pizza peel.
2. Once the oven is preheated, open the oven door.
3. Carefully slide the pizza from the peel onto the hot pizza stone inside the oven. Close the door immediately.
4. Set the timer on the external controller. Pizzas typically cook in 90 seconds at high temperatures. Monitor the pizza through the viewing window.
5. When the pizza is cooked to your preference, use the pizza peel to carefully remove it from the oven.
6. Close the oven door.



Figure 5.1: Placing a pizza into the oven using the pizza peel.




Figure 5.2: Removing a cooked pizza from the oven.

5.3 Cooking Other Foods

The ElectriQ oven can also be used to cook other items such as steak, seafood, sausages, and vegetables. Adjust temperature and cooking times as needed for different foods. Always use oven-safe cookware.



Figure 5.3: The oven can be used for cooking various foods in appropriate cookware.

5.4 Video Demonstration

Your browser does not support the video tag.

Video 5.4: This video demonstrates the preparation and cooking of pizzas and other items using the Q-Stoves ElectriQ pizza oven, showcasing its ease of use and versatility.

6. Maintenance and Cleaning

6.1 Cleaning the Pizza Stone

- Allow the pizza stone to cool completely before cleaning.
- Scrape off any excess food residue with a plastic scraper or stiff brush.
- For stubborn stains, use a damp cloth with plain water. **Do not use soap or detergents** as they can be absorbed by the porous stone and affect food flavor.
- Ensure the stone is completely dry before storing or reusing.

6.2 Cleaning the Oven Exterior

- Ensure the oven is unplugged and completely cool.
- Wipe the stainless steel body with a soft, damp cloth and a mild, non-abrasive cleaner.
- Dry thoroughly with a soft cloth.
- Do not use abrasive pads or harsh chemicals, as they can damage the finish.

7. Troubleshooting

Problem	Possible Cause	Solution
Oven not heating	Power cord not properly connected; Controller not turned on; Circuit breaker tripped.	Check power connections; Ensure controller is on; Reset circuit breaker.
Pizza not cooking evenly	Oven not fully preheated; Incorrect temperature settings; Pizza placed incorrectly.	Allow sufficient preheating time; Adjust dual heating element settings; Ensure pizza is centered on the stone.
Smoke or unusual odor during initial use	Manufacturing residues burning off.	This is normal for first use. Ensure good ventilation. If excessive or persistent, discontinue use and contact support.

8. Specifications

Feature	Detail
Brand	Q-Stoves
Model Name	ElectriQ12
Model Number	ElectriQ
Product Dimensions (D x W x H)	13.5" x 16" x 9.5"
Capacity	Fits 12-inch pizza
Wattage	1550 watts
Temperature Range	Up to 1000°F (500°C)
Material	Stainless Steel
Item Weight	25 Pounds
Control Type	Knob Control (External Controller)
Power Source	Electric
Special Feature	Timer, Dual Heating Elements, Remote Control Panel

Feature	Detail
Included Components	Pizza Oven, Pizza Stone, Controller (with Remote Control Panel), Power Cord, Door Knob, Pizza Peel, Carrying Strap
UPC	658362019019

9. Warranty and Support

The Q-Stoves ElectriQ Pizza Oven is covered by a **2-year warranty** for parts in the case of non-human damage. For warranty claims, technical assistance, or any other inquiries, please contact official customer service.
Please refer to the contact information provided in your product packaging or on the official Q-Stoves website for customer support details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DR5FJZKB

More documents and user manuals: **https://manuals.plus/**