Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PORIYA ES-03

PORIYA 900W Adult Electric Scooter User Manual

Model: ES-03

1. Introduction

This manual provides essential information for the safe operation, maintenance, and troubleshooting of your PORIYA 900W Adult Electric Scooter, Model ES-03. Please read it thoroughly before your first ride to ensure optimal performance and safety.

2. Safety Information

Your safety is paramount. Always wear a helmet and appropriate protective gear. Adhere to local traffic laws and regulations. Avoid riding in wet conditions, on slippery surfaces, or at night without proper lighting.

2.1 General Safety Guidelines

- Always inspect the scooter before each ride: check brakes, tires, and battery level.
- Do not exceed the maximum load capacity of 120 KG.
- Maintain a safe distance from other vehicles and pedestrians.
- Avoid sudden turns or braking at high speeds.
- Do not operate the scooter under the influence of alcohol or drugs.

2.2 Battery Safety

- Use only the original charger provided with the scooter.
- Do not expose the battery to extreme temperatures or direct sunlight.
- If the battery is damaged or leaking, do not use it and dispose of it properly.

3. Package Contents

Upon opening the package, please verify that all components are present:

- PORIYA 900W Adult Electric Scooter (Main Body)
- Battery Pack (Pre-installed or separate)

- Power Adapter/Charger
- User Manual (This document)
- Tools (if included for assembly)

4. Setup and Assembly

Your PORIYA ES-03 scooter comes mostly pre-assembled. Follow these steps to complete the setup:

1. **Unfolding the Scooter:** Carefully lift the stem until it locks into place. Ensure the folding mechanism is securely latched.
2. **Handlebar Installation:** Attach the handlebars to the stem, ensuring they are firmly secured.
3. **Initial Charge:** Fully charge the battery before first use. Connect the charger to the charging port and then to a power outlet. The indicator light on the charger will change when fully charged.



Figure 4.1: The PORIYA ES-03 scooter is designed for easy folding and portability, as shown by a person carrying it up stairs.

5. Operating Instructions

5.1 Powering On/Off

Press and hold the power button on the display to turn the scooter on or off.

5.2 Speed Modes

The scooter features three adjustable speed modes: 15 Km/h, 30 Km/h, and 40 Km/h. Use the mode button on the display to cycle through these settings.



Figure 5.1: The PORIYA ES-03 electric scooter is suitable for daily commuting, offering power, range, and speed for urban environments.

5.3 Riding the Scooter

- Place one foot on the deck and push off with the other foot.
- Once you gain some momentum, gently press the accelerator.
- To brake, use the electronic brake and rear wheel disc brake.
- The integrated backlit LED display shows speed, mode, and charge level.



Figure 5.2: The 8.5-inch solid honeycomb tires provide stability and comfort for a smooth riding experience.

5.4 Smart App Connectivity

The scooter features an intelligent car locking system that connects to your mobile phone for enhanced security. Refer to the separate app manual or instructions for pairing and features.

6. Maintenance

6.1 Cleaning

Wipe the scooter with a damp cloth. Do not use high-pressure water jets or immerse the scooter in water.

6.2 Battery Care

- Charge the battery regularly, even if not in use, to prolong its lifespan.
- Store the scooter in a cool, dry place when not in use.
- Avoid completely draining the battery before recharging.

6.3 Tire Inspection

Regularly inspect the 8.5-inch solid honeycomb tires for any signs of wear or damage. While solid tires do not require air pressure checks, ensuring they are free from debris is important.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Scooter does not power on.	Low battery; Power button not pressed correctly.	Charge the battery; Press and hold the power button firmly.
Reduced range/speed.	Low battery; Heavy load; Uphill riding; Cold weather.	Fully charge battery; Reduce load; Ride on flat terrain; Battery performance may decrease in cold.
Brakes not effective.	Brake cable loose; Worn brake pads.	Adjust brake cable tension; Consult service for brake pad replacement.

8. Specifications

Feature	Detail
Model	ES-03
Motor Power	900W
Battery	36V 7.8Ah Lithium Battery
Max Speed	Up to 40 KM/H (Adjustable modes: 15, 30, 40 Km/h)
Max Range	30KM-50KM (depends on weight and gear)
Tire Type	8.5-inch Solid Honeycomb Tires
Brake System	Electronic Brake + Rear Wheel Disc Brake
Max Load Capacity	120 KG
Material	Aluminum Alloy
Weight	12.5 KG

9. Warranty and Support

For warranty information and customer support, please refer to the purchase documentation or contact PORIYA customer service directly. Keep your proof of purchase for warranty claims.

Manufacturer: suzhouqianmengdianzishangwuyouxiangongsi

ASIN: B0DRSMGPL5

Date First Available: 28 December 2024

© 2024 PORIYA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DRSMGPL5

More documents and user manuals: **https://manuals.plus/**