Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HZSSDTKJ Bed

HZSSDTKJ Twin Size Upholstered Daybed with Trundle, Charging Station, and LED Lights

Instruction Manual

Important Safety Instructions

Please read and understand all instructions before beginning assembly and use. Keep this manual for future reference.

- Do not use power tools for assembly unless specifically instructed, as overtightening may damage components.
- Ensure all parts are securely fastened before use. Periodically check and re-tighten fasteners.
- Do not exceed the maximum weight capacity of 330 lbs for the daybed.
- Keep small parts away from children during assembly to prevent choking hazards.
- Use only the recommended mattress thickness: 8 inches for the daybed and 4-5 inches for the trundle bed.
- Place the daybed on a flat, stable surface.

Setup

Unpacking and Parts Identification

Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Verify that all parts listed in the included assembly guide are present. If any parts are missing or damaged, contact customer support immediately.

Assembly Instructions

This daybed requires assembly. A detailed, step-by-step assembly manual with numbered parts and necessary tools is included in the packaging. Follow the instructions precisely to ensure proper construction and stability.

1. Begin by assembling the main frame components as per the provided diagrams.
2. Attach the headboard and footboard sections, ensuring all connections are secure.
3. Install the bed slats for both the main daybed and the trundle. Ensure slats are evenly spaced and firmly attached.
4. Assemble the trundle unit separately and then slide it into position under the main daybed frame.
5. Connect the LED light strip and charging station wiring according to the electrical diagram.
6. Once fully assembled, gently test the stability of the daybed and trundle before placing mattresses.



Image: Detailed dimensions of the daybed and trundle for assembly reference.



Image: Exploded view illustrating the internal structure and key dimensions of the daybed and trundle.

Operating

Using the Trundle Bed

The trundle bed is designed to slide out from underneath the main daybed. To deploy, gently pull the trundle unit forward using the integrated handle or edge. To retract, push the trundle back into its stored position until it is fully under the main bed frame.



Image: The daybed with the trundle extended, showing its functionality as an additional sleeping space.

Operating the Charging Station

The integrated charging station features 2 USB ports and 2 AC outlets. To use, ensure the daybed is connected to a wall power outlet. Plug your electronic devices into the appropriate USB or AC ports. The charging station is located on the headboard for convenient access.



Image: A detailed view of the charging station, highlighting the USB ports and AC outlets.



Image: Illustrates the placement of the charging station within the headboard design.

Controlling the LED Lights

The daybed features integrated LED lights with a remote control. Use the remote to power the lights on/off, select from 16 static colors, adjust brightness, and choose dynamic lighting modes. Ensure the LED light strip is properly connected to the power source as per assembly instructions.



Image: The daybed with its RGB LED lights active, demonstrating color options and the remote control.



Image: A close-up view of the LED light strip embedded in the headboard, providing ambient lighting.

Maintenance

Cleaning Instructions

- For general cleaning, wipe the upholstered surfaces with a damp cloth.
- For spills, blot immediately with a clean, dry cloth. Avoid rubbing, which can spread the stain.
- For wooden or metal parts, wipe with a dry cloth to remove dust.
- Do not use harsh chemicals, abrasive cleaners, or polishes, as these may damage the finish or fabric.

General Care

- Periodically check all bolts and screws to ensure they remain tight. Re-tighten as necessary.
- Avoid exposing the daybed to direct sunlight or extreme temperature changes, which can cause fading or material degradation.
- Do not drag the daybed when moving it; lift it to prevent damage to the frame or floor.

Troubleshooting

Common Issues and Solutions

Problem	Possible Cause	Solution
Daybed feels wobbly or unstable.	Loose fasteners.	Check and tighten all bolts and screws. Ensure all components are correctly aligned.

Problem	Possible Cause	Solution
Trundle bed does not slide smoothly.	Obstruction or misaligned casters.	Check for any objects blocking the trundle path. Inspect casters for damage or debris and ensure they are properly installed.
LED lights are not working.	Power connection issue or remote battery.	Ensure the daybed is plugged into a working outlet. Check the connection of the LED strip to the power adapter. Replace remote control batteries if necessary.
Charging station is not providing power.	Daybed not plugged in or internal wiring issue.	Verify the daybed's main power cord is securely plugged into a functional wall outlet. If the issue persists, contact customer support.

Specifications

Feature	Detail
Overall Product Dimensions	79.5"L x 45.3"W x 37.4"H
Size	Twin
Color	Gray
Material	Linen fabric, MDF, Plywood
Weight Capacity	330 lbs
Recommended Daybed Mattress Thickness	8 inches
Recommended Trundle Mattress Thickness	4-5 inches
Charging Station	2 USB Ports, 2 AC Outlets
LED Lights	RGB with remote control (16 static colors, brightness/speed adjust)
Assembly Required	Yes
Product Weight	119.05 LBS

Warranty Information

This product is covered by a limited manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration. Keep your proof of purchase for any warranty claims.

Customer Support

For assistance with assembly, missing parts, or any other inquiries, please contact our customer service team. Refer to the contact information provided in your product packaging or on the manufacturer's official website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DSBP21F9

More documents and user manuals: **https://manuals.plus/**