Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SANODESK 71x32 Black Frame+ Black Top

SANODESK Standing Desk User Manual

Model: 71x32 Black Frame + Black Top
Brand: SANODESK

Product Overview

The SANODESK Standing Desk is an ergonomic solution designed to enhance your home office experience. This electric height-adjustable desk allows seamless transitions between sitting and standing positions, promoting better posture and increased activity throughout your workday. Constructed with robust materials, it offers exceptional stability and durability for daily use.

- **Ergonomic Design:** Provides a reliable and comfortable rising experience.
- **Electric Height Adjustable:** Saves up to 4 custom heights for effortless transitions between 28.3 inches and 47.6 inches.
- **Exceptional Stability:** Built with an industrial-grade steel frame for robust and durable support.
- **Spacious Workspace:** The 71" x 32" desktop offers ample room for multiple monitors and work essentials.

Setup and Assembly

Your SANODESK standing desk is designed for straightforward assembly. Follow the detailed instructions provided in the manual and refer to the video guide for visual assistance. All necessary tools and embedded screw hole locations are included to simplify the process.



Image: All components of the SANODESK Standing Desk laid out for assembly, including the black desktop panels and steel frame parts.

Assembly Video Guide

▶ **Watch video online**
SANODESK Standing Desk Large Size

Video: An official SANODESK video demonstrating the assembly process and key features of the large size standing desk.

Cable Management

The desk includes sticky cord keepers to help organize cables underneath the desktop, ensuring a clean and clutter-free workspace.



Image: An underside view of the desk showing the cable management system, with wires neatly secured.

Operating Instructions

The SANODESK features an intuitive control panel for easy height adjustment and memory settings.

Control Panel Functions



Image: A close-up of the desk's control panel, highlighting the LED display, up/down arrows, and four memory preset buttons.

- **Height Adjustment:** Use the up and down arrow buttons to manually adjust the desk height. The current height is displayed on the LED screen.
- **Memory Presets:** Save up to four preferred height settings (1, 2, 3, 4). To save a height, adjust the desk to the desired level, then press and hold the desired memory button until the display confirms the setting.
- **Wide Lifting Range:** The desk adjusts from a minimum height of 28.3 inches to a maximum of 47.6 inches, accommodating various user preferences and activities.



Image: The standing desk is shown at its lowest and highest adjustable positions, illustrating its wide lifting range.

Anti-Collision Function

For safety, the desk is equipped with an anti-collision system. If the desk encounters an obstacle while adjusting its height, it will automatically stop and reverse slightly to prevent damage or injury.



Image: The anti-collision function is depicted, showing the desk stopping its downward movement upon detecting an object.

Maintenance

To ensure the longevity and optimal performance of your SANODESK, regular maintenance is recommended.

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Stability Check:** Periodically check all screws and connections to ensure they are tight. Re-tighten if necessary to maintain the desk's exceptional stability.
- **Motor Care:** Keep the motor area free from dust and debris. Avoid placing heavy objects directly on the motor housing.



Image: A person is shown sitting on the edge of the desk, illustrating its robust and wobble-free stability.

Troubleshooting

If you encounter any issues with your SANODESK, refer to the following common solutions:

- **Desk Not Moving:** Ensure the power cord is securely plugged into both the desk and a working power outlet. Check for any obstructions underneath or around the desk that might trigger the anti-collision system.
- **Uneven Movement/Wobbling:** Verify that all assembly screws are properly tightened. Ensure the desk is placed on a flat, level surface. Adjust the foot pads if necessary to compensate for uneven flooring.
- **Memory Presets Not Working:** Re-program the memory settings by adjusting the desk to the desired height and then pressing and holding the corresponding memory button until confirmed.

Specifications

Brand	SANODESK
Product Dimensions	71"D x 32"W x 28.3"H
Color	Black Frame+ Black Top
Style	Modern
Base Material	Alloy Steel
Top Material Type	Wood
Height Range	28.3 inches - 47.6 inches
Maximum Load Capacity	198 lbs (approx.)
Motors	2 High-Performance Motors

Warranty and Support

The SANODESK Standing Desk comes with a **Limited Warranty**. For specific warranty details or technical support, please refer to the documentation included with your product or visit the official SANODESK website.
Manufacturer: SANODESK

© 2025 SANODESK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DSBZVHHN

More documents and user manuals: **https://manuals.plus/**