Fanbulous F-TY48XX-1X0X

Fanbulous 48-Inch Flush Mount Ceiling Fan User Manual

Model: F-TY48XX-1X0X

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Fanbulous 48-Inch Flush Mount Ceiling Fan. Please read this manual thoroughly before installation and use to ensure safe and efficient operation.

Figure 1: Fanbulous 48-Inch Black Flush Mount Ceiling Fan

Safety Information

Always follow basic safety precautions when installing and operating electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Ensure power is disconnected at the circuit breaker before installation or servicing.
- All wiring must be in accordance with national and local electrical codes.
- Consult a qualified electrician if you are unsure about wiring or installation.
- Mount the fan only to an outlet box marked "Acceptable for Fan Support of 35 lbs (15.9 kg) or less" and use the mounting screws provided with the outlet box.
- Do not insert objects into the path of the fan blades.
- This fan is designed for indoor use. While suitable for covered patios, it is not waterproof and should be protected from direct exposure to wind and rain.

Package Contents

Verify that all components are present before beginning installation:

- Ceiling Fan Motor Assembly
- 5 Fan Blades (Dual-sided: Black and Wood Grain)
- Remote Control with Wall Mount Bracket
- Mounting Hardware (screws, anchors, etc.)
- User's Manual

Figure 2: Included Components

Setup & Installation

The Fanbulous 48-Inch Flush Mount Ceiling Fan is designed for easy installation, typically taking non-professionals about

one hour to complete. Detailed instructions are provided to guide you through each step.

Key Installation Features:

- **Flush Mount Design:** This fan mounts snugly against the ceiling, making it ideal for rooms with lower ceilings (7-10 feet height recommended) and reducing wobbling.
- **Pre-assembled Components:** Many parts come pre-assembled to simplify the process.

Figure 3: Easy Installation Process

Your browser does not support the video tag.

Video 1: Overview of the 48-Inch Flush Mount Ceiling Fan, demonstrating its features and quiet operation. This video provides a visual guide to the fan's design and functionality, including its 6-speed settings, reversible function, and remote control capabilities.

Operating Instructions

Your Fanbulous ceiling fan comes with a multifunctional remote control for convenient operation from anywhere in the room.

Remote Control Functions:

- **Power On/Off:** Instantly turn the fan on or off.
- **6-Speed Control:** Adjust airflow from a gentle breeze (Level 1-2) to a powerful cool wind (Level 5-6). This offers finer control than traditional 3-speed fans.
- **Timer Settings:** Set the fan to automatically turn off after 1, 2, or 4 hours.
- **Forward/Reverse Rotation:**
  - **Summer Mode (Forward):** Blades rotate counter-clockwise to create a downward airflow, providing a direct cooling breeze.
  - **Winter Mode (Reverse):** Blades rotate clockwise to gently circulate warm air upward, helping to redistribute heat in the room.
- **Quiet DC Motor:** Operates at noise levels below 30 decibels, ensuring a peaceful environment.

Figure 4: Multifunctional Remote Control



Figure 5: Reversible Airflow for Seasonal Comfort

Dual-Sided Blades:

The fan features dual-sided blades with a matte black finish on one side and a wood grain finish on the other, allowing you to choose the aesthetic that best suits your room's decor.

Figure 6: Dual-Sided Blade Options

Maintenance

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Use a soft, damp cloth to clean the fan blades and motor housing. Do not use abrasive cleaners or solvents.
- **Blade Inspection:** Periodically check that all blade screws are tight. Over time, they may loosen, causing the fan to wobble.
- **Motor Lubrication:** The DC motor is permanently lubricated and does not require additional oiling.

Troubleshooting

If you experience issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control not paired.	Check circuit breaker; Ensure all wires are securely connected; Refer to remote pairing instructions in the manual.
Fan wobbles	Loose blade screws; Unbalanced blades; Improper mounting.	Tighten all blade screws; Use the balancing kit (if included) to balance blades; Ensure mounting bracket is securely installed.
Remote control not working	Dead batteries; Remote not paired; Obstruction between remote and receiver.	Replace batteries (2 AAA batteries required); Re-pair the remote control with the fan receiver; Ensure clear line of sight.
Fan is noisy	Loose screws; Motor issue; Blades hitting an obstruction.	Check and tighten all screws; Ensure no wires or objects are touching the blades; Contact customer service if noise persists.

Specifications

Feature	Detail
Brand	Fanbulous
Model Name	F-TY48XX-1X0X
Color	Black
Electric Fan Design	Ceiling Fan
Power Source	DC
Style	Modern
Product Dimensions	48"D x 45.98"W x 10.24"H
Room Type	Living Room, Bedroom, Patio
Special Feature	Manual
Recommended Uses	Living Room, Bedroom, Patio
Noise Level	30 dB
Wattage	30 watts

Feature	Detail
Blade Length	21 Inches
Voltage	120 Volts
Indoor/Outdoor Usage	Indoor (Note: Not waterproof, avoid direct wind/rain)
Control Method	Remote
Number of Power Levels	6
Item Weight	10.17 pounds
Batteries Required	Yes (2 AAA batteries included)

Warranty & Support

Fanbulous is committed to providing excellent customer service. For any questions, issues, or warranty claims, please contact our support team.

- **Customer Service:** Available 24 hours to ensure prompt resolution of any issues.
- **Online Support:** Visit the Fanbulous Store on Amazon for additional resources and contact information.

© 2025 Fanbulous. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question