Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

let'me HT-F8-BK

let'me 13 Inch Bladeless Desk Fan User Manual

Model: HT-F8-BK

Product Overview

The let'me 13 Inch Bladeless Desk Fan (Model HT-F8-BK) offers a safe, quiet, and efficient cooling solution for personal spaces. Its innovative bladeless design ensures safety for children and pets, while touch controls provide easy access to multiple settings. This compact fan is ideal for desks, nightstands, and offices, providing a refreshing breeze with added ambient lighting.

Key Features:

- **Bladeless Design:** Provides smooth airflow, safe for children and pets.
- **Touch Control:** Effortlessly adjust settings with a responsive touch panel.
- **3 Speed Airflow:** Choose from low, medium, or high fan speeds for personalized comfort.
- **106° Oscillation:** Wide-angle oscillation distributes air evenly across your space.
- **Night Light Function:** Integrated LED light with three brightness levels for ambient lighting.
- **Compact Size:** Standing 13 inches tall, it fits perfectly on desks, nightstands, or office spaces.
- **Quiet Operation:** Operates at a low noise level (45 Decibels), suitable for quiet environments.
- **USB-C Powered:** Requires a USB cable and adapter for operation, ensuring stable performance.

Setup Instructions

1. Unboxing and Package Contents

Carefully remove all components from the packaging. Ensure the following items are present:

- let'me 13 Inch Bladeless Desk Fan
- USB-C to USB-A Cable
- USB Power Adapter
- User Manual

Image: Package contents of the let'me Bladeless Desk Fan, showing the fan, USB-C cable, power adapter, and user manual.

2. Power Connection

The fan is powered via a USB-C cable and requires a standard USB power adapter (included). It is not cordless and must be plugged in for operation. For optimal performance, use the provided adapter and cable.

1. Insert the USB-C end of the cable into the USB-C port located on the back of the fan.
2. Connect the USB-A end of the cable into the provided USB power adapter.
3. Plug the USB power adapter into a standard wall outlet.

Image: Detailed view of the USB-C plug-in connection on the fan.

Your browser does not support the video tag.

Video: This video demonstrates the unboxing and initial power connection of the let'me Bladeless Table Fan, showing how to connect the USB-C cable and adapter for operation.

Operating Instructions

1. Power On/Off and Speed Control

The fan features a touch-sensitive control panel on its base. The digital display will show the current fan speed.

1. **Power On:** Press the **Power button** ( ) once to turn on the fan at speed level 1.
2. **Adjust Speed:** Press the **Power button** repeatedly to cycle through speed levels 1, 2, and 3.
3. **Power Off:** After speed level 3, pressing the **Power button** again will turn the fan off.

Image: The fan's touch control panel with power, oscillation, and light buttons, and a digital display showing the current speed.

Your browser does not support the video tag.

Video: This video demonstrates the power on/off and speed control functions of the let'me Bladeless Desk Fan, showing how to cycle through the three fan speeds using the touch button.

2. Oscillation Function

The fan offers a 106° auto-oscillation feature to distribute airflow across a wider area.

1. **Activate Oscillation:** Press the **Oscillation button** ( ) once to start the fan oscillating.
2. **Deactivate Oscillation:** Press the **Oscillation button** again to stop the oscillation at its current position.



Image: The let'me Bladeless Desk Fan demonstrating its 106-degree wide oscillation feature.

3. Night Light Function

The fan includes a night light with three adjustable brightness levels.

1. **Turn On Light:** Press the **Light button** ( ) once to turn on the night light at its lowest brightness.
2. **Adjust Brightness:** Press the **Light button** repeatedly to cycle through the three brightness levels.
3. **Turn Off Light:** After the highest brightness level, pressing the **Light button** again will turn the night light off.

Image: The fan's night light feature displaying three dimmable brightness levels, suitable for a bedroom or nursery.

Maintenance

Regular cleaning helps maintain the fan's performance and longevity.

- **Cleaning the Exterior:** Wipe the exterior surfaces of the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Cleaning Air Inlets/Outlets:** Use a soft brush or a vacuum cleaner with a brush attachment to gently remove dust from the air inlet grilles and the bladeless air outlet.
- **Storage:** If storing the fan for an extended period, ensure it is clean and dry. Store it in a cool, dry place away from direct sunlight.

Caution: Do not immerse the fan in water or any other liquid. Ensure the fan is unplugged before cleaning.

Troubleshooting

Refer to the table below for common issues and their solutions.

Symptom	Possible Cause	Solution
Fan does not turn on.	Not properly connected to power source.	Ensure the USB-C cable is securely connected to the fan and the power adapter, and the adapter is plugged into a working outlet.
Weak airflow.	Fan speed set too low; Air inlets/outlets are blocked.	Increase the fan speed using the power button. Check and clean any dust or obstructions from the air inlets and outlets.
Oscillation not working.	Oscillation function not activated.	Press the oscillation button to activate the feature.
Night light not working or blinking.	Light function not activated; Power supply issue.	Press the light button to turn on or adjust brightness. Ensure stable power supply.
Unusual noise during operation.	Obstruction in the fan mechanism; Fan not on a stable surface.	Turn off and unplug the fan. Check for any foreign objects. Place the fan on a flat, stable surface.

Specifications

Feature	Detail
Brand	let'me
Model Name	HT-F8-BK
Color	Black
Electric Fan Design	Table Fan
Power Source	Corded Electric (USB)
Product Dimensions	4.9"D x 4.9"W x 13"H
Special Features	3 Speeds Optional, Bladeless, LED Light, Oscillating, Touch Control

Feature	Detail
Noise Level	45 Decibels
Wattage	6 watts
Voltage	5 Volts
Indoor/Outdoor Usage	Indoor
Control Method	Touch
Number of Power Levels	3
Item Weight	2.14 pounds

Warranty and Support

let'me is committed to providing high-quality products and excellent customer experience. This product comes with a standard warranty covering manufacturing defects under normal use. Please refer to the warranty terms provided in the included user manual for specific details regarding coverage and duration.

Contact Support: If you have any questions, encounter issues, or require assistance with your let'me Bladeless Desk Fan, please contact our customer service team. We aim to provide a satisfactory solution within 12 hours.

Email: LM-service@outlook.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DSZF1NTS

More documents and user manuals: **https://manuals.plus/**