Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Yalissey YS251180-KH

Yalissey Outdoor Lounge Chairs Instruction Manual

Model: YS251180-KH

Product Overview

Thank you for choosing the Yalissey Outdoor Lounge Chairs. This manual provides essential information for the safe assembly, operation, and maintenance of your new lounge chairs. Please read all instructions carefully before use to ensure proper functionality and longevity of the product.



Image: A pair of Yalissey Outdoor Lounge Chairs with khaki cushions, set in an outdoor environment.

Safety Information

Adherence to these safety guidelines is crucial for preventing injury and damage to the product.

- Assembly is required. Read all instructions carefully before beginning assembly.
- Keep fingers clear of moving parts when adjusting the backrest to avoid pinching.
- Do not exceed the maximum weight capacity of**400 pounds** per chair.
- Keep food and drinks away from the chair cushions to prevent spills and stains.
- Store the chairs in a dry, protected area when not in use, especially during adverse weather conditions, to prevent damage.

Assembly Instructions

Assembly of the Yalissey Outdoor Lounge Chairs is required. Please ensure all components are present before starting. While assembly instructions are included with the product, careful attention to diagrams and step-by-step guidance is recommended for a smooth process.

1. Unpack all components and verify against the included parts list.
2. Lay out all hardware and tools.
3. Follow the step-by-step diagrams provided in the physical instruction manual to connect the frame components.
4. Secure all fasteners tightly, but do not overtighten until all parts are aligned.
5. Once the frame is assembled, place the cushions onto the chairs.
6. Ensure the non-slip silicone base of the cushions is properly positioned to prevent movement.

If you encounter any difficulties during assembly, refer to the detailed diagrams in your product's included manual or contact customer support.

Operating Instructions

Adjusting the Backrest

The lounge chairs feature a 5-position adjustable backrest, allowing you to customize your comfort for various activities such as lounging, reading, or sunbathing. To adjust the backrest:

1. Gently lift the backrest to disengage it from its current position.
2. Move the backrest to your desired angle.
3. Ensure the backrest securely locks into one of the five available positions before applying your weight.



Image: A visual representation of the five adjustable backrest positions, illustrating different relaxation modes.

Using the Convenient Side Table

Each lounge chair includes a built-in side table. This feature provides a convenient surface for placing items such as your phone, magazines, or beverages while you relax. Simply place your items on the table surface as needed.

Maintenance

Regular maintenance will help preserve the appearance and functionality of your Yalissey Outdoor Lounge Chairs.

Cleaning the Frame

The frame is constructed from rust-resistant steel with a galvanized surface and powder coating. To clean:

- Wipe down the rattan and metal frame with a soft cloth dampened with mild soap and water.
- Rinse thoroughly with clean water to remove any soap residue.

- Dry completely with a clean, dry cloth to prevent water spots and maintain the finish.



Image: Cross-section view of the frame, highlighting the metal core, galvanized layer, and powder coating for durability.

Cushion Care

The cushions are made from 180G polyester fabric with a PA coating, designed to be splash-resistant and fade-resistant.

- For minor spills, blot immediately with a clean, dry cloth.
- For general cleaning, spot clean with mild soap and water.
- Allow cushions to air dry completely before storage or reuse.
- The cushion covers are removable for easier cleaning.



Image: Detailed view of the handwoven PE rattan, showcasing its texture and craftsmanship.

Storage

To prolong the life of your lounge chairs, especially the cushions, store them in a dry, covered area when not in use for extended periods or during inclement weather.

Troubleshooting

This section addresses common issues you might encounter with your lounge chairs.

Chair Instability

- **Issue:** The chair feels wobbly or unstable.
- **Solution:** Check all bolts and fasteners to ensure they are securely tightened. Ensure the chair is placed on a flat, even surface.

Cushions Sliding

- **Issue:** Cushions do not stay in place.
- **Solution:** The cushions are designed with a non-slip silicone base. Ensure the cushions are correctly positioned on the chair frame, with the non-slip base making full contact.

Difficulty Adjusting Backrest

- **Issue:** The backrest is stiff or difficult to adjust.
- **Solution:** Ensure no debris is obstructing the adjustment mechanism. Apply a small amount of silicone lubricant to the moving parts if necessary, ensuring it does not come into contact with the rattan or cushions.

Specifications

Key specifications for the Yalissey Outdoor Lounge Chairs (Model YS251180-KH):

- **Brand:** Yalissey
- **Model Name:** YS251180-KH
- **Color:** Khaki
- **Material:** Rattan (frame), Foam (seat fill), Polyester (upholstery)
- **Product Dimensions (D x W x H):** 76.8" x 25.4" x 11.5"
- **Item Weight:** 74.5 Pounds (per set of 2)
- **Maximum Weight Recommendation:** 400 Pounds
- **Reclining Position Count:** 5
- **Included Components:** Cushions
- **Indoor/Outdoor Usage:** Outdoor



Image: Detailed dimensions of the lounge chair, including length, width, and height.

Warranty and Support

Your satisfaction is important to us. For any questions regarding delivery, product features, materials, or installation instructions, please contact our customer service team.

- **Return Policy:** The product is eligible for a refund or replacement within 30 days of purchase.
- **Customer Service:** Our professional after-sales team provides email replies within 24 hours on weekdays.

For further assistance, please refer to the contact information provided with your purchase documentation.

© 2024 Yalissey. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DT3N962Y

More documents and user manuals: **https://manuals.plus/**