Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Xyvaly 1400D10G

Xyvaly 1400D10G 12-Gun Biometric Safe Instruction Manual

Model: 1400D10G

1. Introduction

Thank you for choosing the Xyvaly 1400D10G 12-Gun Biometric Safe. This manual provides essential information for the safe and proper assembly, operation, and maintenance of your new gun safe. Please read all instructions carefully before use and retain this manual for future reference.

2. Safety Information

WARNING: Always fix the gun safe to the wall using the provided bolts before use. Never leave the gun safe unattended while unlocked. Be aware that the alarm sound may startle you or others when the wrong code is entered 5 times in a row.

- Keep all keys and access codes in a secure location away from the safe and out of reach of children.
- Ensure the safe is installed on a stable, level surface.
- Do not store flammable materials or liquids inside the safe.
- Regularly check the battery level of the electronic lock.

3. Product Overview & Features

The Xyvaly 1400D10G Biometric Safe is designed to securely store your firearms with convenient access options and customizable interior space.

Key Features:

- **Large and Adjustable Space:** Exterior dimensions: 55.2” (H) X 15.2” (D) X 21” (W). Stores 10-12 rifles/shotguns. Features two removable shelves and a partition for customizable storage.
- **Various Quick Access Methods:** Fingerprint unlock (up to 30 fingerprints), 3-12 digit password, and emergency key access.
- **Fixed Anti-Theft Design:** Constructed from cold-rolled steel with four 20mm diameter locking bolts. Includes expansion bolts for wall mounting.

- **Alarm and Mute Function:** An alarm sounds after 5 consecutive incorrect code entries. Press 11# to toggle between mute and alarm modes.
- **Product Details:** Removable partition, height-adjustable gun rack, four pistol pouches, handgun bag, and LED auxiliary lighting.



Figure 1: Xyvaly 12-Gun Safe with dimensions (Height: 55.2", Width: 21", Deep: 15.2") and illustration of firearm storage capacity.



Figure 2: Detailed view of the safe's interior features including quick access lock, removable shelves, gun rack, pistol pouches, and built-in pegboards.

4. Package Contents

Verify that all items listed below are included in your package:

- 1 x Rifle gun safe (requires assembly)
- 2 x Emergency keys
- 3 x Removable gun racks
- 1 x External Battery Box
- 4 x Expansion bolts
- 1 x Instruction Manual
- 1 x Gloves
- 1 x Screwdriver

5. Assembly Instructions

The Xyvaly 1400D10G gun safe requires assembly. Follow these steps carefully:

1. Unpack all components and verify against the package contents list.
2. Assemble the main body of the safe according to the diagrams in the included instruction manual.
3. Install the removable shelves and gun racks as desired. The pegboard design allows for flexible placement.
4. Attach the pistol pouches to the inside of the door.
5. **Secure Mounting:** Before using the safe, it is crucial to fix it to a wall or floor using the provided four expansion bolts. This prevents unauthorized removal of the safe.



Figure 3: Illustration of the wall mounting process using expansion bolts for enhanced security.

6. Operating Instructions

6.1 Access Methods

Your safe offers three ways to access your firearms:

1. **Fingerprint Unlock:** Register your fingerprints following the detailed instructions in the included manual. Place your registered finger on the scanner for quick access. The safe supports up to 30 unique fingerprints.
2. **Password Unlock:** Set a 3-12 digit password. Enter your code on the keypad and turn the handle to open.
3. **Emergency Key:** In case of battery failure or forgotten codes, use one of the provided emergency keys to manually open the safe.



Figure 4: Visual guide to the three secure access methods for the Xyvaly 12-Gun Safe.

6.2 Alarm and Mute Function

- **Alarm Activation:** If an incorrect code is entered 5 times consecutively, the safe's alarm will sound.
- **Mute/Alarm Mode Toggle:** To switch between mute mode (no sound feedback for key presses) and alarm mode (sound feedback and alarm activation), press '11#' on the keypad.



Figure 5: Explanation of the safe's alarm system and how to switch between mute and alarm settings.

6.3 External Battery Box

If the internal batteries of the electronic lock run out, you can use the provided external battery box. Connect it to the designated port on the keypad to temporarily power the lock and gain access.

▶ **Watch video online**

Gun Cabinet Password Setting

Video 1: Demonstrates the process of setting the password for the gun safe's electronic lock.

7. Customization & Storage

The interior of your Xyvaly safe is designed for maximum flexibility:

- **Removable Shelves:** Two shelves can be adjusted or removed to accommodate firearms of various lengths or other valuables.

- **Adjustable Gun Rack:** The gun rack is height-adjustable, allowing you to optimize space for rifles and shotguns with or without scopes.
- **Pistol Pouches:** Four pistol pouches are included for convenient storage of handguns or other small items.

8. Maintenance

- Keep the safe clean by wiping it with a soft, dry cloth. Avoid abrasive cleaners.
- Regularly check the battery level of the electronic lock and replace batteries as needed to ensure continuous functionality.
- Inspect the locking bolts and hinges periodically for any signs of wear or damage.

9. Troubleshooting

If you encounter any issues with your Xyvaly 1400D10G safe, please refer to the detailed troubleshooting section in your included instruction manual. Common issues often relate to battery replacement or incorrect code entry. If problems persist, please contact customer support.

10. Specifications

Feature	Detail
Brand	Xyvaly
Model Name	1400D10G
Product Dimensions	15.2"D x 21"W x 55.2"H
Item Weight	76.3 Pounds
Material	Alloy Steel
Lock Type	Electronic, Key
Mounting Type	Floor Mount
Assembly Required	Yes

11. Warranty & Support

For warranty information or technical support, please refer to the contact details provided in your product packaging or visit the Xyvaly official website. Customer support is available to assist with any questions or concerns regarding your safe.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DT98VDNF

More documents and user manuals: **https://manuals.plus/**