Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DUMOS ADM-25L02-GY

DUMOS L-Shaped Computer Desk Instruction Manual

Model: ADM-25L02-GY

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your DUMOS L-Shaped Computer Desk, Model ADM-25L02-GY. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The DUMOS L-Shaped Computer Desk, Model ADM-25L02-GY, set up in a modern gaming environment.

Safety Information

- **Anchoring:** Always anchor the desk to the wall to prevent tipping. This is especially important in high-traffic areas or where the desk might be subjected to accidental impacts.
- **Weight Limit:** Do not exceed the maximum weight limit of 200 lbs (90.7 kg) on the desk surface. Distribute weight evenly.
- **Assembly:** Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- **Placement:** Place the desk on a level surface to ensure stability.
- **Children:** Keep small parts and packaging materials away from children during assembly to prevent choking hazards.

Package Contents

Before assembly, verify that all components listed below are present. If any parts are missing or damaged, please contact DUMOS customer support.

- Wooden Deskboards (L-shaped sections)
- Metal Frame Components (legs, support bars, X-shaped frames)
- Side Fabric Storage Bag
- CPU Stand (bottom bracket)
- Headphone Hook
- Assembly Hardware (screws, bolts, nuts, washers)
- Assembly Tools (Allen wrench, screwdriver)
- Instruction Manual (this document)

Setup and Assembly

The DUMOS L-Shaped Computer Desk is designed for quick and simple assembly. All necessary tools are included. It is recommended to assemble the desk with two people.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface (e.g., a blanket or carpet) to prevent scratches.
2. **Identify Parts:** Refer to the included parts list and diagrams to identify each component.
3. **Assemble Metal Frame:** Attach the metal legs and support bars according to the diagrams. Ensure all connections are finger-tightened initially.
4. **Attach Deskboards:** Place the wooden deskboards onto the assembled frame. Align the pre-drilled holes and secure them with the provided screws.
5. **Install CPU Stand:** Attach the CPU stand (bottom bracket) to the desired side of the desk. The desk features a reversible design, allowing the longer section and CPU stand to be configured on either the left or right side.
6. **Attach Side Fabric Storage Bag and Headphone Hook:** Secure the fabric storage bag and headphone hook to the designated locations on the desk frame.
7. **Final Tightening:** Once all components are in place, systematically tighten all screws and bolts using the provided tools. Do not overtighten.
8. **Positioning:** Carefully move the assembled desk to its desired location. Ensure it is level and stable.



Image: Illustration demonstrating the reversible design of the L-shaped desk, allowing for left or right-hand configuration.



Image: Technical drawing displaying the dimensions of the DUMOS L-Shaped Computer Desk, including desktop lengths, height, and CPU stand measurements.

Operating Instructions

The DUMOS L-Shaped Computer Desk offers a versatile and spacious workspace for various activities.

- **Workspace Utilization:** The large 50" W x 41.33" D surface provides ample room for multiple monitors, a laptop, keyboard, mouse, and other peripherals.
- **Reversible Design:** The desk can be assembled with the longer section and CPU stand on either the left or right side to best suit your room layout and preferences.
- **Storage:** Utilize the side fabric storage bag for documents, books, or small accessories. The bottom bracket serves as a dedicated CPU stand, keeping your computer off the floor.
- **Headphone Hook:** Use the integrated headphone hook to keep your headphones easily accessible and your desk clutter-free.



Image: Detailed view highlighting the waterproof desktop, the robust X-shaped metal frame, and the practical side fabric storage bag.

Maintenance

Proper care will ensure the longevity and appearance of your DUMOS L-Shaped Computer Desk.

- **Cleaning:** The smooth, friction-resistant desktop is easy to clean. Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** Immediately wipe up any spills to prevent water damage or staining.
- **Fasteners:** Periodically check all screws and bolts for tightness. Re-tighten as needed to maintain stability.
- **Avoid Extreme Conditions:** Do not expose the desk to extreme temperatures, humidity, or direct sunlight for prolonged periods, as this may cause warping or discoloration.

Troubleshooting

If you encounter any issues with your DUMOS L-Shaped Computer Desk, refer to the following common solutions:

Issue: Desk feels wobbly or unstable.
Solution: Ensure the desk is placed on a level surface. Check all assembly screws and bolts and tighten them securely. If the issue persists, verify that all frame components are correctly aligned according to the assembly instructions.

Issue: Parts do not align during assembly.
Solution: Loosen all screws slightly, realign the components, and then gradually tighten them. Sometimes, tightening one screw too much before others can cause misalignment. Refer to the assembly diagrams to ensure correct orientation of parts.

Issue: Missing or damaged parts.
Solution: Do not proceed with assembly. Contact DUMOS customer support immediately with your product model number and a description of the missing or damaged part. Provide proof of purchase if requested.

Specifications

Brand	DUMOS
Model Number	ADM-25L02-GY
Model Name	L Shaped Computer Desk
Product Dimensions (D x W x H)	43.3" x 50" x 30" (110 cm x 127 cm x 76.2 cm)
Color	Grey
Material Type	Wood (MDF), Metal
Maximum Weight Recommendation	200 lbs (90.7 kg)
Special Feature	Reversible Design, Side Fabric Storage Bag, CPU Stand, Headphone Hook
Assembly Required	Yes (Tools Included)
UPC	709688401047

Warranty Information

The DUMOS L-Shaped Computer Desk comes with a**Limited Warranty**. Specific terms and duration of the warranty may vary. Please refer to the warranty card included in your package or contact DUMOS customer support for detailed information regarding warranty coverage, claims, and service.
This warranty typically covers manufacturing defects in materials and workmanship under normal use. It does not cover damage resulting from improper assembly, misuse, abuse, accidents, modifications, or normal wear and tear.

Customer Support

For any questions, assistance with assembly, missing parts, or warranty inquiries, please contact DUMOS customer support.

- **Online Support:** Visit the official DUMOS website or the DUMOS store on Amazon for FAQs and contact options.
- **Email:** Refer to your product packaging or included documentation for customer service email addresses.
- **Phone:** Refer to your product packaging or included documentation for customer service phone numbers.

When contacting support, please have your product model number (ADM-25L02-GY) and proof of purchase readily available.

© 2026 DUMOS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DTGQ69BH

More documents and user manuals: **https://manuals.plus/**