Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

APBEAMLighting FS8821

APBEAMLighting 23 Inch Black and Gold Ceiling Fan with Light Instruction Manual

Model: FS8821

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your APBEAMLighting 23 Inch Black and Gold Ceiling Fan with Light. Please read this manual thoroughly before installation and use to ensure safe and efficient operation.

Safety Information

Always follow basic safety precautions when installing and operating electrical appliances. Failure to do so may result in fire, electric shock, or personal injury.

- Ensure power is disconnected at the circuit breaker before installation or servicing.
- All wiring must be in accordance with national and local electrical codes.
- Consult a qualified electrician if you are unsure about the installation process.
- Do not operate the fan with damaged wiring or if it is not functioning properly.
- Keep hands, hair, and clothing away from moving fan blades.

What's in the Box

Verify that all components are present before beginning installation:

- Instruction Manual
- Remote Control
- Mounting Hardware
- LED Light Kit
- Ceiling Fan Unit with Retractable Blades



Figure 1: Included components of the ceiling fan package.

Setup and Installation

Installation of this ceiling fan is designed to be straightforward. For detailed visual guidance, an installation video is available online. Ensure you have a Phillips screwdriver and two AAA batteries (not included for the remote) before starting.

Dimensions and Room Suitability

The fan's compact design makes it suitable for various room sizes, particularly smaller spaces. Refer to the diagram below for precise dimensions.



Figure 2: Product dimensions and room size reference (6 sq ft to 80 sq ft).

Installation Steps (Summary)

1. **Prepare for Installation:** Turn off power at the main circuit breaker.
2. **Mount the Bracket:** Secure the mounting bracket to the ceiling junction box.
3. **Wire the Fan:** Connect the fan's electrical wires to the household wiring according to the wiring diagram in the full instruction manual.
4. **Attach the Fan Unit:** Secure the fan unit to the mounting bracket.
5. **Install Light Kit:** Connect and secure the LED light kit.
6. **Restore Power:** Turn on power at the main circuit breaker.

Operating Instructions

Your ceiling fan can be controlled via the included remote control or a dedicated mobile application.

Control Methods



Figure 3: Three ways to control your fan: Wall Switch (not included), APP Control, and Remote Control.

- **Remote Control:** The primary method for adjusting fan speed, light settings, and timer. Insert two AAA batteries (not included) into the remote.
- **APP Control:** Download the dedicated mobile application to control all fan and light functions from your smartphone.
- **Wall Switch:** A standard wall switch (not included) can be used for basic on/off functionality.

Fan Functions

- **Retractable Blades:** The fan features 3 brown ABS blades that retract when the fan is off, giving it the appearance of a standard light fixture. The blades extend when the fan is turned on.
- **6-Speed Settings:** Adjust airflow from a gentle breeze (1-2 gear for relaxation) to powerful circulation (5-6 gear for fast heat dissipation).



Figure 4: Fan speed settings and their recommended uses.

- **Forward and Reversible Function:**
    - **Forward Mode (Cooling Airflow):** Blades rotate counter-clockwise to push air downwards, creating a cooling effect for summer use.
    - **Reverse Mode (Better Air Circulation):** Blades rotate clockwise to pull air upwards, circulating warm air trapped near the ceiling for winter use.



Figure 5: Forward and Reverse fan modes.

Light Functions

- **Dimmable LED Lighting:** Adjust brightness from 5% to 100% to suit your preference.
- **3 Color Temperatures:** Switch between Warm Light (3000K), Natural Light (4500K), and White Light (6500K).



Figure 6: Adjustable color temperature and brightness settings.

Smart Features

- **Timing Setting:** Set the fan and light to automatically shut off after 1, 4, or 8 hours. These timers operate independently.
- **Memory Function:** The fan remembers the last setting for light temperature, light brightness, and fan rotation direction. This function activates after the fixture has been on for at least 10 seconds.



Figure 7: Memory function retains previous settings.

Maintenance

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Dust the fan blades and light fixture regularly with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Blade Inspection:** Periodically check the retractable blades for any obstructions or damage.
- **Tighten Screws:** Ensure all mounting screws remain tight.
- **Light Source:** The LED light source is integrated and designed for long life. Do not attempt to replace individual LEDs.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Fan does not operate.	No power supply; loose wiring; remote control battery low/dead.	Check circuit breaker; ensure all connections are secure; replace remote batteries.
Light does not turn on.	Loose wiring; LED light kit issue; remote control battery low/dead.	Check wiring connections; replace remote batteries. If issue persists, contact support.
Fan makes unusual noise.	Loose screws; blades unbalanced; motor issue.	Tighten all screws; ensure blades are properly seated; contact support if noise persists.
Remote control not working.	Batteries dead or incorrectly inserted; remote not paired.	Replace batteries (2x AAA); refer to the full manual for remote pairing instructions.

Specifications

Feature	Detail
Brand	APBEAMLighting
Model Number	FS8821
Color	Black and Gold
Material	Iron
Product Dimensions	17"L x 13"W x 6"H (Overall)
Item Weight	6.6 pounds (approx. 3 Kilograms)
Power Source	AC
Wattage	24 watts
Light Source Type	LED
Brightness	1680 Lumen
Color Temperature	3000K, 4500K, 6500K (Adjustable)
Control Method	Remote Control, APP Control
Special Features	Adjustable Color Temperature, Color Changing, Dimmable, Lightweight, Timer, Retractable Blades, Reversible Fan
Room Type Suitability	Living room, bedroom, dining room, kitchen, office, entryway, nursery, garage, RV

Warranty

This APBEAMLighting product comes with a Limited Warranty. Please refer to the warranty card included in your packaging or contact customer support for specific terms and conditions.

Customer Support

For further assistance, technical support, or warranty claims, please contact APBEAMLighting customer service. Refer to the contact information provided in your product packaging or visit the official APBEAMLighting website.

Online Resources:

- Product Page: Amazon Product Page
- Brand Store: APBEAMLighting Store

© 2025 APBEAMLighting. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DTPNHBV9

More documents and user manuals: **https://manuals.plus/**