Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

APBEAMLighting FS8858

APBEAMLighting 28 Inch Retractable Ceiling Fan with Light (Model FS8858) User Manual

Model: FS8858 | Brand: APBEAMLighting

Introduction

This manual provides detailed instructions for the safe and efficient operation, installation, and maintenance of your APBEAMLighting 28 Inch Retractable Ceiling Fan with Light, Model FS8858. Please read this manual thoroughly before installation and use, and retain it for future reference.



Image: The APBEAMLighting 28 Inch Retractable Ceiling Fan with Light, featuring a sleek black finish and brown retractable blades, illuminated in a room setting.

Safety Information

Always follow basic safety precautions when installing and operating electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Ensure power is disconnected at the circuit breaker before installation or maintenance.
- All wiring must be in accordance with national and local electrical codes.
- Consult a qualified electrician if you are unsure about wiring or installation.
- Mount the fan to a ceiling outlet box marked "Acceptable for Fan Support of 35 lbs (15.9 kg) or less" and use the mounting screws provided with the outlet box.
- Do not bend the blade holders during installation, balancing, or cleaning.
- Avoid placing objects in the path of the rotating blades.
- This product is designed for indoor use only.

Package Contents

Verify that all components are present and undamaged before beginning installation:

- Mounting Hardware
- Instruction Manual
- Remote Control
- Shade
- Ceiling Fan Unit (with retractable blades and integrated LED light)

Setup and Installation

Follow these steps for proper installation. For visual guidance, refer to the installation video provided below.

Installation Steps:

1. **Prepare for Installation:** Turn off power at the circuit breaker. Ensure the mounting surface is structurally sound to support the fan's weight.
2. **Mount the Bracket:** Secure the mounting bracket to the ceiling outlet box using the provided screws.
3. **Wiring Connections:** Connect the fan's electrical wires to the household wiring according to local electrical codes. Typically, this involves connecting ground, neutral, and live wires.
4. **Attach the Fan Unit:** Carefully lift the fan unit and attach it to the mounting bracket. Secure all screws.
5. **Blade Assembly (if separate):** For this model, the retractable blades are integrated. Ensure they are free to move.
6. **Final Checks:** Double-check all connections and ensure the fan is securely mounted. Restore power.

▶ **Watch video online**
Installation reference video, the actual blades are brown

Video: An installation reference video demonstrating the setup process for a similar retractable ceiling fan. Note: The actual blades for this model are brown.



Image: Detailed view of the fan's components, highlighting the rugged lampshade, the durable ABS high-strength blades, and the invisible fan design when blades are retracted.

Operating Instructions

Your APBEAMLighting ceiling fan can be controlled via the included remote control or a compatible mobile application.

Remote Control and App Functions:



Image: The remote control and a smartphone showing the mobile application interface, illustrating the three ways to control the fan and light (wall switch not included).

- **Power On/Off:** Use the "ON/OFF" button on the remote or the power icon in the app to turn the fan and light on or off.
- **Light Control:**
  - **Color Temperature:** Adjust between 3000K (Warm Light), 4500K (Natural Light), and 6500K (White Light) using the dedicated buttons on the remote or the app interface.
  - **Brightness Adjustment:** Customize brightness from 10% to 100% using the dimmer buttons on the remote or the slider in the app.

- **Memory Function:** The fan remembers the last light temperature, brightness, and fan rotation direction settings.



Image: Visual representation of the three adjustable color temperatures (Warm, Natural, White) and the 10-100% brightness adjustment feature of the integrated LED light.



Image: The fan's memory function, which retains the last settings for light temperature, brightness, and fan rotation direction.

- **Fan Speed:** Select from 6 different wind speeds for optimal comfort.
    - **1-2 Speed:** Relax and comfortable breeze.
    - **3-4 Speed:** Natural wind for ventilation and cooling.
    - **5-6 Speed:** Strong wind for fast heat dissipation.



Image: Diagram showing the 6 wind speed settings, categorized into soft, natural, and strong wind for various comfort levels.

- **Reversible Function:** Use the F/R button on the remote or the app to change the fan's rotation direction.
    - **Forward Mode (Downdraft):** Cools in summer by pushing air downwards.
    - **Reverse Mode (Updraft):** Warms in winter by circulating warm air upwards.



Image: Illustration of the fan's reversible function, demonstrating downdraft for cooling and updraft for better air circulation.

- **Timer Function:** Set the fan to automatically turn off after 1, 4, or 8 hours using the timer buttons on the remote or the app.

▶ **Watch video online**
28 Inch Retractable Ceiling Fan with Light and Remote

Video: A product overview video demonstrating the features of the 28 Inch Retractable Ceiling Fan with Light and Remote, including light and fan controls.

Maintenance

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Use a soft, damp cloth to clean the fan blades and light fixture. Do not use abrasive cleaners or solvents.
- **Tighten Fasteners:** Periodically check all screws and fasteners to ensure they are secure.

- **Lubrication:** The fan's motor is permanently lubricated and does not require additional oiling.

Troubleshooting

If you encounter issues with your ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; loose wire connections; remote control battery low.	Check circuit breaker; ensure all wires are securely connected; replace remote control battery.
Light does not work	Loose wire connection; LED driver issue.	Check light wiring; contact customer support if LED driver is suspected.
Fan is noisy	Loose screws; blades unbalanced; motor issue.	Tighten all mounting screws; ensure blades are properly installed and balanced; contact customer support if motor noise persists.
Remote control not working	Battery low or incorrectly inserted; remote not paired.	Replace battery, ensure correct polarity; follow pairing instructions (refer to remote control section).

Specifications

Feature	Detail
Brand	APBEAMLighting
Model Number	FS8858
Product Dimensions	28"L x 28"W x 11.4"H
Color	Black and Brown
Material	Alloy Steel, Iron (Shade)
Style	Modern
Light Source Type	LED
Wattage	24 watts (Light)
Brightness	1680 Lumen
Color Temperature	3000K / 4500K / 6500K (Adjustable)
Control Method	App, Remote Control
Fan Speeds	6 Speeds
Special Features	Adjustable Color Temperature, Color Changing, Energy Efficient, Lightweight, Timer, Reversible Airflow

Feature	Detail
Indoor/Outdoor Usage	Indoor
Mounting Type	Ceiling Mount (Flush Mount)
Noise Level	Below 35dB (Silent DC motor)



Image: Detailed dimensions of the fan, including overall width, light diameter, and height, along with a room size reference for optimal placement.

Warranty and Support

This APBEAMLighting product comes with a limited warranty. For specific details regarding warranty coverage, please refer to the warranty card included in your package or contact APBEAMLighting customer support.
For technical assistance, troubleshooting, or to inquire about replacement parts, please visit the official

APBEAMLighting website or contact their customer service department.

APBEAMLighting Store: Visit Store

© 2025 APBEAMLighting. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DTPNPHYT

More documents and user manuals: **https://manuals.plus/**