Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRAUSI i27

TRAUSI Wireless Earbuds User Manual

Model: i27
Brand: TRAUSI

1. Introduction

Thank you for choosing the TRAUSI i27 Wireless Earbuds. These Bluetooth 5.4 headphones are designed to provide a superior audio experience with features like clear sound, noise-cancelling microphone, fast charging, and a comfortable, secure fit. They are ideal for sports, workouts, and daily use.



Image: TRAUSI i27 Wireless Earbuds in their charging case, showcasing their sleek design.

2. What's in the Box

- i27 Wireless Earbuds (2 units)
- User Manual

- Wireless Charging Case
- Type-C Cable (1 unit)
- S, M, L Eartips (3 pairs)

3. Setup

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The charging case features a Type-C port for quick charging. A 10-minute quick charge provides 2 hours of playback, and a full charge for the case takes approximately 1.5 hours. The LED percentage display on the case indicates the power status.



Image: The charging case displaying battery levels for both earbuds and the case itself.



Image: The charging case with earbuds, illustrating the digital battery display.

3.2 Instant Pairing

The earbuds utilize Bluetooth 5.4 for fast and stable connections. To pair, simply take the earbuds out of the charging case. They will automatically power on and enter pairing mode. Open the Bluetooth settings on your device (smartphone, tablet, laptop) and select "i27" from the list of available devices. Once connected, they will automatically reconnect to the last paired device when removed from the case.



Image: A smartphone displaying its Bluetooth settings, with the "i27" earbuds listed for pairing.

3.3 Comfortable Fit

The i27 earbuds feature a soft, ultra-light earhook design for a secure and comfortable fit. Three sizes of silicone eartips (S/M/L) are included to ensure personalized comfort and optimal sound isolation. Choose the size that best fits your ear canal for the most secure and comfortable experience.




Image: A person wearing one of the earbuds, demonstrating the secure fit, alongside an illustration of the different eartip sizes available.

4. Operating Instructions

4.1 Smart Touch Controls

The earbuds are equipped with intuitive touch controls for easy management of music and calls. Refer to the table below for specific functions:

Action	Function
Single Tap	Play/Pause music, Answer/End call
Double Tap (Left Earbud)	Previous Track
Double Tap (Right Earbud)	Next Track

Action	Function
Triple Tap (Left Earbud)	Volume Down
Triple Tap (Right Earbud)	Volume Up
Long Press (2 seconds)	Activate Voice Assistant (Siri/Google Assistant), Reject call



Image: Visual representation of the touch control functions on the earbud.

4.2 Call Management

The built-in noise-cancelling microphone ensures clear calls even in noisy environments. Use the touch controls as described above to answer, end, or reject calls.

5. Maintenance

5.1 Cleaning

Regularly clean the earbuds and charging case with a soft, dry cloth. Avoid using abrasive materials or harsh chemicals. Ensure charging contacts are free of debris.

5.2 Water Resistance (IPX7)

The i27 earbuds are IPX7 waterproof certified, meaning they can resist sweat, rain, and splashes. They are perfect for workouts and outdoor activities. **Note:** They are not suitable for submersion in water (e.g., swimming or showering).



Image: An earbud with water droplets, visually representing its IPX7 waterproof capability.

6. Troubleshooting

- **Earbuds not pairing:** Ensure both earbuds are fully charged. Place them back in the case, close the lid, wait a few seconds, then open the lid and try pairing again. Make sure Bluetooth is enabled on your device.
- **Only one earbud working:** Place both earbuds back in the charging case, close the lid, and then take them out again. This should reset their connection.
- **No sound:** Check the volume level on your device and on the earbuds. Ensure the earbuds are properly connected to your device via Bluetooth.
- **Charging case not charging:** Ensure the Type-C cable is securely connected to both the case and a power source. Check the power source.

7. Specifications

Feature	Detail
Model Name	i27

Feature	Detail
Connectivity Technology	Wireless (Bluetooth 5.4)
Bluetooth Range	Up to 15 meters (50 feet)
Water Resistance Level	IPX7 Waterproof
Earbud Playtime (Single Charge)	Up to 6 hours
Total Playtime with Charging Case	Up to 54 hours
Charging Case Battery Capacity	400 mAh
Charging Case Charging Time	1.5 hours (Type-C)
Control Type	Touch Control
Microphone	Noise-Cancelling Mic
Compatible Devices	iPhone, Android, Cellphones, Desktops, Laptops, Tablets, All Smart Devices with Bluetooth

8. Official Product Video

Watch the official product video for a visual guide on the TRAUSI i27 Wireless Earbuds.

Your browser does not support the video tag.

Video: An official product video showcasing the features and usage of the TRAUSI i27 Wireless Earbuds.

9. Warranty and Support

For warranty information and customer support, please refer to the official TRAUSI website or contact their customer service directly. Keep your purchase receipt for any warranty claims.

© 2025 TRAUSI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DV36SH5C

More documents and user manuals: **https://manuals.plus/**