Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SANSUI 32" FHD WebOS Smart TV

SANSUI 32 inch LED Smart TV User Manual

Model: 32" FHD WebOS Smart

Introduction

This manual provides detailed instructions for setting up, operating, and maintaining your SANSUI 32 inch LED Smart TV. Featuring a frameless design, FHD 1080P resolution, HDR10, Dolby Vision, and Dolby Atmos sound, this TV offers a rich entertainment experience powered by WebOS Hub. It supports Google Play, Apple HomeKit, Airplay, Wi-Fi, and Bluetooth 5.0.



Image: SANSUI 32 Inch FHD Smart WebOS TV highlighting key features.

What's in the Box

Before you begin, please ensure all items are present:

- SANSUI 32 inch LED Smart TV
- Remote Control
- Power Cable
- Stand (2 pieces)
- User Manual (this document)

Setup

1. Attaching the Stand

1. Carefully place the TV face down on a soft, clean surface to prevent screen damage.
2. Align each stand piece with the corresponding slots on the bottom of the TV.
3. Secure the stands using the provided screws.

2. Connecting Peripherals

Your SANSUI Smart TV offers versatile connectivity options:

- **HDMI:** Connect up to three HDMI devices (e.g., gaming consoles, Blu-ray players, cable boxes) to the HDMI 2.0 ports. One port supports ARC for audio return.
- **USB:** Two USB 2.0 ports are available for connecting USB storage devices to play media files.
- **AV Input:** Connect older devices using the Audio Video port.
- **RF Antenna Input:** Connect your antenna for digital TV channels.
- **RJ45:** For a wired internet connection.
- **Digital Optical Audio Output:** Connect to external sound systems.



Image: Convenient Connection ports on the SANSUI TV.

3. Power On and Initial Setup

After connecting all necessary cables, plug the power cable into an electrical outlet. The TV will power on and guide you through the initial setup process, including language selection, network connection, and channel scanning.

Operating Your TV

Remote Control Overview

The included remote control provides effortless navigation and access to all TV functions. It features dedicated streaming buttons for popular apps and supports voice commands.



Image: Effortless Control with Remote.



Image: Detailed Remote Control Functions.

WebOS Hub: Your Entertainment Center

The WebOS Hub provides a user-friendly interface to access your favorite streaming services, live TV, and connected devices. Navigate using the remote's directional pad and select options with the 'OK' button.



Image: Smart Platform Your Entertainment Hub.

Picture and Sound Settings

Optimize your viewing experience with various picture and sound modes:

- **Picture Modes:** Choose from Standard, Vivid, Sports, Movie, Game, and Energy Saving modes to suit your content.
- **HDR10 & Dolby Vision:** Experience stunning realism with enhanced contrast, clarity, and vivid colors.
- **Dolby Atmos Sound:** Immerse yourself in rich, cinematic audio with dual 8W speakers. Sound styles include User, Standard, Vivid, Movie, and Music.



Image: Stunning Realism in Every Frame with HDR.



Image: Dolby Atmos Immersive Sound, All Around You.

Screen Mirroring and Smart Home Integration

The TV supports Apple Airplay and Miracast for effortless screen mirroring from your devices. You can also integrate your TV into your smart home ecosystem using LG ThinQ or Apple Home for hands-free control.



Image: Miracast & Airplay Effortless Screen Mirroring.



Image: Smartly Control Your Smart Home.

Bluetooth Connectivity

Easily pair your wireless headphones or other Bluetooth 5.0 devices for a personalized audio experience.



Image: Bluetooth Easily Pair your Wireless Headphones.

Maintenance

Cleaning Your TV

To maintain the clarity and longevity of your screen:

- Always unplug the TV before cleaning.
- Use a soft, lint-free cloth to gently wipe the screen. For stubborn marks, slightly dampen the cloth with water or a screen-specific cleaning solution (never spray directly onto the screen).
- Wipe the TV frame and stand with a dry, soft cloth.
- Avoid using abrasive cleaners, waxes, or solvents.

Software Updates

Your SANSUI Smart TV may receive periodic software updates to improve performance and add new features. Ensure your TV is connected to the internet to receive these updates automatically or check for them manually through the TV's settings menu.

Troubleshooting

If you encounter issues with your TV, refer to the following common problems and solutions:

Problem	Possible Solution
No Power	Ensure the power cable is securely plugged into both the TV and a working electrical outlet. Try a different outlet.
No Picture / Black Screen	Check the input source (HDMI, AV, etc.) is correctly selected. Ensure connected devices are powered on. Try restarting the TV.
No Sound	Check the volume level and ensure mute is not activated. Verify external audio systems are connected correctly and powered on.
Remote Control Not Working	Replace the batteries in the remote. Ensure there are no obstructions between the remote and the TV's IR sensor.
Wi-Fi Connection Issues	Restart your router and modem. Ensure the TV is within range of your Wi-Fi network. Re-enter the Wi-Fi password.

Specifications

Feature	Detail
Screen Size	32 Inches
Display Technology	LED
Resolution	1080p (1920x1080)
Refresh Rate	60 Hz
Aspect Ratio	16:9
Special Features	Built-In Speaker, Sleep Timer, Bezel-Less Design, HDR10, Dolby Vision, Dolby Atmos
Connectivity	Bluetooth 5.0, Dual-band Wi-Fi, 3x HDMI 2.0 (1x ARC), 2x USB 2.0, AV Input, RJ45, Digital Optical Audio Output, RF Antenna Input
Operating System	WebOS Hub
Product Dimensions (D x W x H)	8.08" x 28.34" x 18.58" (with stand)
Item Weight	7.17 Pounds
Power Consumption	56 Watts

Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official SANSUI website. You can also contact SANSUI customer service for assistance.

© 2025 SANSUI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DV3V8W3G

More documents and user manuals: **https://manuals.plus/**