Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ADIMO BGX-M/D-45(L)

ADIMO Fireproof Safe Box User Manual

Model: BGX-M/D-45(L) | Brand: ADIMO

1. Product Overview

The ADIMO Fireproof Safe Box is designed to provide secure storage for your valuables and important documents, offering robust protection against fire and theft. Constructed from durable alloy steel, this safe features a dual-lock mechanism, an advanced alarm system, and a fire-resistant design to ensure peace of mind.

Key features include:

- **Certified Fire Protection:** Tested to withstand temperatures up to 1200°F (650°C) for 30 minutes.
- **Dual Safety Alerts:** Alarm triggers on three incorrect password attempts or severe impact.
- **Durable Construction:** Reinforced alloy steel with heavy-duty 1-inch live-lock bolts and recessed inner hinges.
- **Dual Lock Mechanism:** Combines a digital keypad with a physical key for flexible access.
- **Spacious Interior:** 1.8 cubic feet capacity with a removable shelf for organized storage.
- **Wall-Mountable Design:** Includes pre-drilled holes and expansion screws for secure installation.



Figure 1: ADIMO Fireproof Safe Box with its door open, revealing the spacious interior and the included fireproof document bag. The digital keypad and key lock are visible on the door.

2. Setup Instructions

2.1 Unboxing and Initial Inspection

Carefully remove the safe from its packaging. Inspect the safe for any signs of damage during transit. Ensure all components listed in the packing list are present, including the safe, keys, fireproof bag, and expansion screws.

2.2 Battery Installation

The digital keypad requires four (4) AA batteries (not included). Locate the battery compartment on the inside of the safe door, typically behind a cover. Insert the batteries, ensuring correct polarity. Close the battery compartment cover

securely.

▶ **Watch video online**

ADIMO Large Heavy Duty Home Safe for Cash

Video 1: This video demonstrates the process of installing batteries into the digital keypad and using both the digital code and physical key to open the ADIMO safe. It also shows the interior light and adjustable shelves.

2.3 Mounting the Safe (Optional)

For enhanced security, the safe can be mounted to a wall, floor, or shelf. Four pre-drilled holes are located at the back of the safe. Use the provided expansion screws to secure the safe to a solid surface. Ensure the mounting location is stable and can support the weight of the safe and its contents.



Figure 2: The ADIMO Fireproof Safe Box positioned discreetly under a nightstand in a bedroom, demonstrating its compact size and suitability for home use.



Figure 3: The ADIMO Fireproof Safe Box situated beside a desk in an office environment, highlighting its utility for securing business documents and valuables.

3. Operating Instructions

3.1 Opening the Safe with Digital Keypad

1. Enter your pre-programmed 6-digit code on the digital keypad.
2. Press the '#' key to confirm. The display will show "OPEN".
3. Within 5 seconds, turn the knob clockwise to open the safe door.

3.2 Opening the Safe with Physical Key

In case of forgotten code or battery depletion, the safe can be opened using the physical key.

1. Locate the keyhole cover on the safe door. Remove the cover.
2. Insert the key into the keyhole and turn it counter-clockwise.
3. Turn the knob clockwise to open the safe door.

3.3 Setting/Changing the Digital Code

1. With the safe door open, press the red reset button located on the inside of the door.
2. The keypad will beep, and the display will show "PROG".
3. Enter your new 6-digit code.
4. Press the '#' key to confirm. The display will show "GOOD".
5. Test the new code with the door open before closing it.

3.4 Alarm System

The safe is equipped with an alarm system that activates under specific conditions:

- **Incorrect Password:** If three consecutive incorrect password attempts are made, the alarm will sound.
- **Impact/Tampering:** The alarm will also trigger if the safe experiences severe impact or tampering attempts.

To silence the alarm, enter the correct digital code or use the physical key to open the safe.

4. Maintenance

4.1 Battery Replacement

Replace the AA batteries in the digital keypad approximately once a year, or when the low battery indicator appears on the display. Always use new, high-quality alkaline batteries.

4.2 Cleaning

Clean the exterior of the safe with a soft, damp cloth. Avoid using abrasive cleaners or solvents that could damage the finish. The interior felt lining can be gently vacuumed if needed.



Figure 4: A close-up view of the anti-scratch blanket mat, designed to protect valuables from scratches inside the safe.

5. Troubleshooting

Problem	Possible Cause	Solution
Keypad not responding.	Dead batteries.	Replace batteries with new AA alkaline batteries.
Safe won't open with code.	Incorrect code entered; batteries low.	Re-enter code carefully. If still fails, replace batteries. Use physical key if necessary.

Problem	Possible Cause	Solution
Alarm sounds unexpectedly.	Multiple incorrect code entries; physical impact.	Enter correct code or use physical key to disarm. Avoid strong impacts to the safe.
Forgotten digital code.	Code forgotten.	Use the physical key to open the safe. Reset the digital code following section 3.3.

6. Specifications

Feature	Detail
Brand	ADIMO
Model Number	BGX-M/D-45(L)
Product Dimensions	14.2"D x 12.2"W x 20.1"H
Lock Type	Key, Digital Keypad
Color	Black
Capacity	1.8 Cubic Feet
Material	Alloy Steel
Special Features	Alarm System, Fireproof
Mounting Type	Wall Mount or Freestanding
Item Weight	56.2 Pounds
Included Components	Fireproof Safe box, Keys, Fireproof Waterproof Safe Bag

7. Warranty and Support

ADIMO provides an exclusive warranty for this product. For detailed warranty information, technical support, or any inquiries regarding your safe, please contact ADIMO customer service. Contact information can typically be found on the product packaging or the official ADIMO website.

ADIMO is dedicated to providing reliable products and excellent customer support. Our team is available to assist you with any questions or concerns.

© 2025 ADIMO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DWF5MDVL

More documents and user manuals: **https://manuals.plus/**