Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JOYROOM JR-W17

JOYROOM Qi2 3-in-1 Wireless Charging Station (Model JR-W17) User Manual

Model: JR-W17

1. Product Overview

The JOYROOM Qi2 3-in-1 Wireless Charging Station is designed to efficiently charge your iPhone, Apple Watch, and AirPods simultaneously. Featuring Qi2 certification, it provides fast and secure magnetic wireless charging for compatible devices. Its foldable design makes it ideal for both home and travel use.



Image 1.1: The JOYROOM Qi2 3-in-1 Wireless Charging Station, showcasing its ability to charge an iPhone, Apple Watch, and AirPods simultaneously. The included 30W power adapter and 60W USB-C cable are also visible.

2. Package Contents

Please verify that all items are present in the package:

- 1 x JOYROOM Qi2 3-in-1 Wireless Charging Station
- 1 x 30W Fast Charger Adapter
- 1 x 60W USB-C Charging Cable
- 1 x User Manual (This document)

3. Setup Guide

1. **Connect the Power Adapter:** Insert the 60W USB-C charging cable into the USB-C port on the back of the charging station.
2. **Plug into Power:** Connect the other end of the USB-C cable to the included 30W Fast Charger Adapter, then plug the adapter into a wall outlet.
3. **Indicator Lights:** The charging station will illuminate briefly, indicating it is powered on and ready for use.

> **Important:** For optimal charging performance, always use the included 30W power adapter and 60W charging cable.

4. Operating Instructions

4.1 Charging Your iPhone

The charging station features a magnetic charging pad for iPhones. Ensure your iPhone is compatible with MagSafe (iPhone 12 series and newer) or has a MagSafe-compatible case.

1. **Positioning:** Place your iPhone onto the upright magnetic charging pad. The magnets will align your device automatically for optimal charging.
2. **Charging Confirmation:** Your iPhone screen will display the charging animation, confirming that charging has begun. The station delivers up to 15W fast wireless charging for compatible iPhones.



Image 4.1: Demonstrates the magnetic alignment feature, showing an iPhone being placed on the charging pad.

4.2 Charging Your Apple Watch

The dedicated Apple Watch charging module provides stable 3W charging.

1. **Placement:** Gently place your Apple Watch onto the magnetic charging puck.

2. **Charging Confirmation:** The watch display will indicate that charging is active.



Image 4.2: An Apple Watch charging on its dedicated module, illustrating the precise fit.

4.3 Charging Your AirPods

The base of the charging station includes a wireless charging area for your AirPods case, delivering 5W charging.

1. **Placement:** Place your AirPods charging case onto the designated flat charging area on the base.
2. **Charging Confirmation:** The indicator light on your AirPods case will show its charging status.

4.4 Foldable Design

The charging station features a foldable design for portability and versatile use.

- **Upright Mode:** Use the station in its upright position for charging and viewing your iPhone in portrait or landscape mode.
- **Flat Mode:** Fold the station flat for compact storage or travel.



Image 4.3: The charging station in its folded state, demonstrating its compact design for travel.

5. Maintenance

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the surface of the charging station. Avoid using abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the charging station in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Handling:** Handle the device with care. Avoid dropping or subjecting it to strong impacts.

6. Troubleshooting

- **Device Not Charging:**
  - Ensure the charging station is properly connected to the included 30W power adapter and a working wall outlet.
  - Verify that your device (iPhone, Apple Watch, AirPods) is correctly placed on its respective charging area.
  - For iPhones, ensure you are using a MagSafe-compatible phone case or no case at all, as thick or non-MagSafe cases can interfere with magnetic alignment and charging efficiency.
  - Remove any metal objects or credit cards from between your device and the charging surface.
  - Try restarting your device.
- **Slow Charging:**
  - Confirm you are using the original 30W power adapter and 60W USB-C cable provided with the charging station. Using lower-wattage adapters can result in slower charging speeds.
  - Ensure your device is centered on the charging pad for optimal power transfer.
  - Close unnecessary background applications on your device.
- **Apple Watch Not Holding Securely:**
  - Ensure the Apple Watch is placed flat and centered on the magnetic puck.
  - Remove any protective cases or bands that might prevent full contact with the charging surface.
- **AirPods Case Feels Warm During Charging:**
  - It is normal for wireless charging to generate some heat. However, if the case becomes excessively hot, remove it from the charger and allow it to cool. Ensure the case is placed correctly on the charging area without obstruction.
- **Bright Indicator Lights:**
  - The charging station has indicator lights that show its status. If these lights are disruptive in a dark environment (e.g., bedroom), consider repositioning the charger or placing a small, non-obstructive object in front of the lights.

7. Specifications

Feature	Detail
Model Number	JR-W17
Brand	JOYROOM
Input Voltage	5 Volts
Output Wattage (iPhone)	Up to 15W (Qi2 Certified)

Output Wattage (Apple Watch)	3W
Output Wattage (AirPods)	5W
Connector Type	USB Type C
Compatible Devices	iPhone (12-16 series), Apple Watch (S1-S9/SE/Ultra 1&2), AirPods (4/3/2/Pro/Pro 2)
Special Features	3-in-1 Charging, Fast Wireless Charger, MagSafe Compatible, Multi-Device Charging, Qi2 Certified, Foldable Design
Color	Black
Item Weight	10.8 ounces
Package Dimensions	7.72 x 5.16 x 1.26 inches

8. Warranty and Support

JOYROOM products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or customer service, please refer to the contact details provided on the official JOYROOM website or the product packaging.

You may also visit the JOYROOM Store on Amazon for additional product information and support resources.

© 2025 JOYROOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DX73ZHX9

More documents and user manuals: **https://manuals.plus/**