Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

APBEAMLighting QXF9012-01

APBEAMLighting 48-Inch Tiffany Rustic Retractable Ceiling Fan User Manual

Model: QXF9012-01 | Brand: APBEAMLighting

1. Important Safety Information

Please read and understand this entire manual before attempting to assemble, operate, or install the product. Failure to do so could lead to electric shock, fire, or other injuries.

- Ensure all electrical connections comply with local codes, ordinances, and the National Electric Code (NEC).
- Consult a qualified electrician if you are unfamiliar with electrical wiring.
- Before installation, disconnect power by turning off the circuit breakers at the main fuse box.
- Use only replacement parts specified by the manufacturer.
- Do not bend the fan blades during installation or cleaning.
- Ensure the installation site allows for a minimum clearance of 7 feet from the floor to the blade trailing edge.
- The outlet box and support structure must be securely mounted and capable of reliably supporting a minimum of 35 lbs (15.9 kg).

2. Package Contents

Verify that all components listed below are included in your package. If any parts are missing or damaged, contact customer service immediately.

- Ceiling Fan Motor Assembly with Light Kit
- Retractable Fan Blades (4 pieces)
- Canopy
- Downrods (12.5cm and 25cm)
- Mounting Bracket
- Remote Control with Wall Mount
- Mounting Hardware (screws, wire nuts, washers)
- Instruction Manual

3. Specifications

Feature	Specification
Model Name	QXF9012-01
Brand	APBEAMLighting
Size	48 Inch Diameter (with blades extended)
Color	Black
Number of Blades	4 (Retractable)
Motor Type	DC Motor
Wind Speeds	6
Light Type	Dimmable LED
Color Temperature	3000K (Warm), 4500K (Natural), 6000K (Cool)
Brightness Range	4400lm to 4800lm
Voltage	120 Volts (AC)
Wattage	40 watts
Control Method	Remote Control
Downrod Lengths	12.5cm (approx. 4.9 inches), 25cm (approx. 9.8 inches)
Noise Level	As low as 30dB
Room Coverage	Up to 18ft x 18ft (15m²-25m²)

Dimensions: 19"D x 19"W x 6"H (when blades are retracted). Item Weight: 19.06 pounds.



Figure 3.1: Product Dimensions and Details

4. Installation Instructions (Setup)

Professional installation is recommended. Ensure power is disconnected at the circuit breaker before beginning installation.

4.1 Pre-Installation

- Unpack the fan and check for any damage. Retain all packaging materials until installation is complete.
- Ensure the ceiling joist or support structure can hold the fan's weight.
- Select the appropriate downrod (12.5cm or 25cm) based on your ceiling height.

4.2 Mounting the Fan

1. Attach the mounting bracket to the ceiling outlet box using the provided screws and washers. Ensure it is securely fastened.
2. Feed the electrical wires from the outlet box through the center hole of the mounting bracket.

4.3 Wiring

1. Connect the fan's wires to the household wires according to the wiring diagram in the detailed instruction manual. Typically, black to black (live), white to white (neutral), and green/bare copper to green/bare copper (ground).
2. Secure connections with wire nuts.

4.4 Attaching the Downrod and Fan Body

1. Insert the chosen downrod into the fan motor assembly and secure it with the provided pin and screw.
2. Carefully lift the fan assembly and hang it from the mounting bracket using the hanger ball.

4.5 Blade and Light Kit Installation

1. Attach the retractable fan blades to the designated slots on the fan motor assembly.
2. Connect the light kit wiring to the fan motor wiring.
3. Secure the light kit to the fan motor assembly.

4.6 Canopy Installation

1. Slide the canopy up against the ceiling, covering the mounting bracket and wiring connections.
2. Secure the canopy with the provided screws.

For a visual guide, refer to the official installation video available online.

▶ **Watch video online**
Black Vintage Retractable Ceiling Fan Product Display

Video 4.1: Black Vintage Retractable Ceiling Fan Product Display. This video demonstrates the fan's features and may assist with understanding the installation process.

5. Operating Instructions

The fan and light functions are controlled via the included remote control.

5.1 Remote Control Functions



Figure 5.1: Remote Control Layout and Functions

- **ALL OFF:** Turns off both the fan and light.
- **Light ON/OFF:** Toggles the light on or off.
- **Fan Speeds (1-6):** Adjusts the fan speed from 1 (lowest) to 6 (highest).
- **Fan Stop:** Stops the fan.
- **Color Temperature Switch:** Cycles through 3000K (Warm), 4500K (Natural), and 6000K (Cool) light.
- **Color Temperature +/-:** Fine-tunes the color temperature.
- **Brightness +/-:** Adjusts the light brightness from 10% to 100% (4400lm to 4800lm).
- **Forward/Reverse:** Changes the fan blade rotation direction.
- **Nightlight:** Activates a low-brightness light setting.
- **Natural Wind:** Simulates natural breeze by varying fan speed.
- **Timer (2H/4H):** Sets the fan to turn off automatically after 2 or 4 hours.

5.2 Dimmable LED Light

The integrated LED light offers three color temperatures and adjustable brightness. Use the remote control to select your preferred setting.



Figure 5.2: Adjustable Color Temperature and Brightness

5.3 Reversible DC Motor

The reversible DC motor allows for year-round use. In summer, the downward airflow creates a cooling effect. In winter, the upward airflow helps circulate warm air trapped near the ceiling, improving heating efficiency.



Figure 5.3: Reversible Function for Summer and Winter

5.4 Memory Function

The fan features a memory function that retains your last used fan speed and light brightness settings, eliminating the need to readjust them each time you turn the fan on.

6. Maintenance

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure power is off before cleaning.
- **Blade Care:** The retractable blades are designed for durability. Avoid bending or applying excessive force to them.
- **Tightening Screws:** Periodically check all screws on the fan body and mounting hardware to ensure they are tight. Loose screws can cause noise or wobbling.
- **Light Source:** The LED light source is integrated and designed for long life. If replacement is ever needed, contact customer support.

7. Troubleshooting

If you experience issues with your ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low or not paired.	Check circuit breaker; Verify all wire connections are secure; Replace remote battery or re-pair remote.
Light does not work	Loose wire connections; LED driver issue; Remote control battery low or not paired.	Check light kit wiring; Contact customer support if LED driver is suspected; Replace remote battery or re-pair remote.

Problem	Possible Cause	Solution
Fan wobbles	Loose mounting screws; Unbalanced blades; Downrod not seated correctly.	Tighten all mounting screws; Ensure blades are securely attached; Re-seat downrod in mounting bracket.
Excessive noise	Loose screws; Fan rubbing against ceiling; Motor issue.	Check and tighten all screws; Ensure proper clearance from ceiling; Contact customer support if motor noise persists.
Remote control not responding	Low battery; Not paired with fan; Obstruction between remote and receiver.	Replace remote battery; Follow pairing instructions in the full manual; Ensure clear line of sight.

If the problem persists after attempting these solutions, please contact APBEAMLighting customer support.

8. Warranty and Support

APBEAMLighting products are manufactured to high-quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. For specific warranty details, including duration and coverage, please refer to the warranty card included with your purchase or visit the official APBEAMLighting website.

For technical assistance, troubleshooting, or to inquire about replacement parts, please contact APBEAMLighting customer support. Have your model number (QXF9012-01) and purchase date ready when contacting support.

Contact Information: Please refer to your product packaging or the official APBEAMLighting website for the most current customer support contact details.

© 2026 APBEAMLighting. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DXBPWSL9

More documents and user manuals: **https://manuals.plus/**