Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

APBEAMLighting QXF9012-01

APBEAMLighting 48-inch Retractable Ceiling Fan User Manual

Model: QXF9012-01

Introduction Safety Instructions Package Contents Installation Guide Operating Instructions Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for purchasing the APBEAMLighting 48-inch Retractable Ceiling Fan with Dimmable LED Light. This manual provides detailed instructions for the safe installation, operation, and maintenance of your new ceiling fan. Please read this manual thoroughly before installation and retain it for future reference.
This ceiling fan features a unique retractable blade design, integrated dimmable LED lighting with adjustable color temperature, a quiet DC motor with 6 speeds, and a reversible function for year-round comfort. It is designed to enhance the comfort and aesthetic of various indoor spaces such as bedrooms, living rooms, and dining rooms.

2. Important Safety Instructions

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these basic precautions:

- Read all instructions before installing and operating this fan.
- All wiring must be performed by a qualified electrician and comply with national and local electrical codes.
- Disconnect power at the main circuit breaker or fuse box before beginning installation or performing any maintenance.
- Ensure the installation site allows the fan blades to rotate without obstruction and provides a minimum clearance of 7 feet (2.1 meters) from the floor to the blade trailing edge.
- The outlet box and support structure must be securely mounted and capable of reliably supporting a minimum of 35 lbs (15.9 kg). Use only UL Listed outlet boxes marked "ACCEPTABLE FOR FAN SUPPORT."
- Do not operate the fan with damaged blades or any visible defects.
- Avoid placing objects in the path of the fan blades.
- Do not attempt to repair or replace parts unless specifically instructed in this manual. Contact qualified service personnel for repairs.

3. Package Contents

Carefully unpack your ceiling fan and inspect the contents to ensure all parts are present and undamaged. Refer to the

diagram below for component identification.



Figure 3.1: Product Dimensions and Key Components

This image illustrates the overall dimensions of the 48-inch retractable ceiling fan, including the 19-inch diameter light fixture and the 48-inch span when blades are extended. It highlights key components such as the DC Silent Motor, Retractable Blades, Sturdy Canopy, and Glass Lampshade. Two downrods, measuring 4.9 inches (12.5cm) and 9.8 inches (25cm), are included for adjustable height installation.

- Ceiling Fan Motor Assembly
- Light Kit with Glass Lampshade
- Retractable Fan Blades (pre-attached or separate)
- Canopy and Mounting Bracket
- Downrods (12.5cm and 25cm)
- Remote Control with Wall Mount
- Hardware Pack (screws, washers, wire nuts)
- Instruction Manual

4. Installation Guide

Professional installation is recommended. If you are performing a DIY installation, ensure you have the necessary tools and follow all safety precautions.

4.1 Pre-Installation Steps

1. **Turn off Power:** Disconnect power at the circuit breaker or fuse box to prevent electrical shock.
2. **Prepare Mounting Location:** Ensure the ceiling outlet box is securely mounted and rated for fan support.
3. **Select Downrod Length:** Choose between the 12.5cm or 25cm downrod based on your ceiling height and desired fan clearance.

4.2 Mounting the Fan

1. Attach the mounting bracket to the ceiling outlet box using the provided screws and washers.
2. Feed the electrical wires from the outlet box through the center hole of the mounting bracket.
3. Assemble the downrod to the fan motor assembly, ensuring all screws are tightened.
4. Carefully lift the fan assembly and hang it onto the mounting bracket hook (if applicable) or secure it directly to the bracket.

4.3 Electrical Connections

1. Connect the fan's electrical wires to the household wiring according to the wiring diagram provided in the detailed installation instructions (refer to the separate instruction sheet included in your package). Typically, this involves connecting live, neutral, and ground wires.
2. Ensure all wire connections are secure using wire nuts.

4.4 Final Assembly

1. Secure the canopy to the mounting bracket, covering the wiring connections.
2. Attach the light kit and glass lampshade to the fan motor assembly.
3. Ensure all components are firmly attached before restoring power.



Figure 4.1: Installed APBEAMLighting Retractable Ceiling Fan

This image displays the APBEAMLighting 48-inch retractable ceiling fan installed in a bedroom setting, showcasing its vintage white finish, the decorative light fixture, and the retractable blades in an extended position. A remote control is also visible, indicating its functionality.

5. Operating Instructions

Your APBEAMLighting ceiling fan is controlled by the included remote control. Ensure the remote has batteries installed (not included) and is within range of the fan.



Figure 5.1: Remote Control Functions

This image illustrates the layout of the remote control, detailing buttons for: ALL OFF, Light ON/OFF, Fan Speeds (1-6), Fan Stop, Color Temperature Switch, Color Temperature +/-, Brightness +/-, Nightlight, Natural Wind, and Timer functions (2H/4H).

5.1 Remote Control Functions

- **Power ON/OFF:** Press the 'ALL OFF' button to turn off both fan and light. Individual ON/OFF buttons are available for light.
- **Fan Speed Control:** Buttons '1' through '6' adjust the fan speed from low (1-2) to high (5-6).
- **Fan Stop:** Press the 'Fan Stop' button to turn off the fan.
- **Light ON/OFF:** Press the 'Light ON/OFF' button to toggle the light.
- **Color Temperature Adjustment:** Use 'Color Temperature Switch' to cycle through 3000K (Warm White), 4000K (Neutral White), and 6500K (Cool White). Use 'Color Temperature +/-' for fine-tuning.
- **Brightness Adjustment:** Use 'Brightness +/-' buttons to dim or brighten the light from 10% to 100%.
- **Reversible Motor:** Press the 'F/R' button to change the fan's rotation direction. Forward mode (counter-clockwise) provides cooling airflow in summer. Reverse mode (clockwise) pushes warm air down in winter for better heat distribution.
- **Timer Function:** Set the fan to turn off automatically after 2 or 4 hours using the '2H' or '4H' buttons.
- **Nightlight:** Activates a low-brightness light setting.
- **Natural Wind:** Simulates natural breeze by varying fan speeds.



Figure 5.2: Retractable Fan Blades in Operation

This image demonstrates the retractable fan blades. When the fan is off, the blades retract, making the unit appear as a chandelier. When the fan is activated, the blades extend to provide airflow. The image also shows the light operating independently and the fan operating independently.



Figure 5.3: Adjustable Color Temperature and Brightness

This image illustrates the dimmable LED light feature, showing the light output at different color temperatures (3000K, 4000K, 6500K) and indicating the adjustable brightness range from 10% to 100%.



Figure 5.4: Reversible Motor Function

This image visually explains the reversible motor function. In summer, the fan operates in forward mode to create a cooling downdraft. In winter, it operates in reverse mode to circulate warm air downwards, improving heating efficiency.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

6.1 Cleaning

- **Before Cleaning:** Always turn off the power to the fan at the circuit breaker before cleaning.
- **Fan Blades:** Wipe the fan blades with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish or blades.
- **Light Fixture:** Clean the glass lampshade with a mild glass cleaner and a soft cloth. Ensure the lampshade is dry before restoring power.
- **Motor Housing:** Dust the motor housing with a soft brush or cloth.

6.2 General Care

- Periodically check all screw connections on the fan and downrod to ensure they are secure.
- The LED light source is integrated and not user-replaceable. If the LED light fails, contact customer support.

7. Troubleshooting

If you experience issues with your ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low or not paired.	Check circuit breaker/fuse; Verify all wire connections are secure; Replace remote batteries or re-pair remote.
Light does not work	No power to the light; Loose wire connections; LED driver issue.	Check circuit breaker/fuse; Verify light kit wiring; Contact customer support if LED driver is suspected.
Fan makes noise	Loose screws; Canopy rubbing ceiling; Blades unbalanced.	Tighten all screws; Adjust canopy clearance; Ensure blades are securely attached.
Remote control not working	Low batteries; Obstruction between remote and receiver; Remote not paired.	Replace batteries; Ensure clear line of sight; Refer to pairing instructions (if applicable, usually automatic).

8. Specifications

Feature	Detail
Brand	APBEAMLighting
Model Name	QXF9012-01
Color	Vintage White
Electric Fan Design	Ceiling Fan
Power Source	AC/DC
Style	Farmhouse
Product Dimensions	19"D x 19"W x 6"H (Light Fixture), 48" (Fan Span)
Room Type	Bedroom, Living Room, Dining Room
Special Feature	Adjustable Color Temperature, Dimmable, Timer, Retractable Blades, Reversible Motor
Recommended Uses	Indoor
Noise Level	30 Decibels (DC Motor)
Wattage	40 watts

Feature	Detail
Finish Type	Metal
Speed	6 levels, up to 220 RPM
Switch Type	Remote Control
Motor Type	DC
Installation Type	DIY (Professional installation recommended)
UPC	733241251688
Item Weight	19.05 pounds

9. Warranty and Support

APBEAMLighting products are manufactured to high-quality standards and are warranted against defects in materials and workmanship. For specific warranty details, please refer to the warranty card included with your product or contact APBEAMLighting customer service.

Customer Support

If you have any questions, require technical assistance, or need to report a missing or damaged part, please contact APBEAMLighting customer support through the retailer where the product was purchased or visit the official APBEAMLighting website for contact information.
Please have your model number (QXF9012-01) and purchase date available when contacting support.

© 2025 APBEAMLighting. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DXBRLWPJ

More documents and user manuals: **https://manuals.plus/**